#### FOREWORD

To the best of our knowledge, the illustrations, technical information, data and descriptions in this issue were correct at the time of going to print. The right to change prices, specifications, and equipment and maintenance instructions at any time without notice is reserved as part of FORD policy of continuous development and improvement for the benefit of our customers.

No part of this publication may be reproduced, stored in a data processing system or transmitted in any form, electronic, mechanical, photocopy, recording, translation or by any other means without prior permission of Ford Motor Company. No liability can be accepted for any inaccuracies in this publication, although every possible care has been taken to make it as complete and accurate as possible.

# FORD FIESTA B299 2010.75MY

# **Body and Paint**

### SECTION TITLE

5

GROUP

Body and Paint	
Body System - General Information	
Front End Body Panels	
Body Closures	
Interior Trim and Ornamentation	
Exterior Trim and Ornamentation	
Rear View Mirrors	
Seating	
Glass, Frames and Mechanisms	501-11
Instrument Panel and Console	
Handles, Locks, Latches and Entry Systems	
Wipers and Washers	
Bumpers	
Safety Belt System	501-20A
Supplemental Restraint System	
Body Repairs - General Information	
Body Repairs - Vehicle Specific Information and Tolerance Checks	501-26
Front End Sheet Metal Repairs	
Roof Sheet Metal Repairs	
Side Panel Sheet Metal Repairs	
Rear End Sheet Metal Repairs	
Paint - General Information	501-36
Frame and Mounting	
Uni-Body, Subframe and Mounting System	502-00
on body, cabitanto and mounting cyclonitinitianitinitianitianitianitiani	

# **SECTION 501-00 Body System - General Information**

### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **DESCRIPTION AND OPERATION**

Body (Overview)	501-00-2
General	501-00-2
A- and B-pillar reinforcement	501-00-2
Bumpers and radiator grille	501-00-3
	501-00-4

### DESCRIPTION AND OPERATION

Body – Overview

### General


At introduction the following vehicle variants are initially available:

- 3-door and
- 5-door.

The equipment level can be chosen from the following:

- Ambiente (standard equipment level),
- Trend (medium equipment level),
- Ghia (high equipment level),
- Titanium (high equipment level),
- Sport (high equipment level).

# A- and B-pillar reinforcement




The A- and B-pillar reinforcement is made of the highest strength boron steel.

These sheet metal parts can only be replaced as a complete unit during repairs and that section repairs are not possible.

Special installation and removal requirements must be observed during repairs. Special tools are also required. Relevant instructions are available in the current service literature.

### DESCRIPTION AND OPERATION

### Bumpers and radiator grille




ltem	Description			
1	Front bumper.			
2	Fog lights			
3	Air deflector			
4	Rear bumper.			
5	Rear fog lamp			
6	Cover, bumper			

The bumpers are painted in the body color as standard for all vehicle variants.

The bumper cover is only available in grey.

### **DESCRIPTION AND OPERATION**

### **Trailer towbar**



Item	Description
1	Module, trailer towbar
2	Towbar socket

At introduction, a removable towbar is made available for the vehicle.

If the vehicle is delivered from the factory with a towbar, then this is equipped with a 13-pin socket.

For aftermarket installation, both a variant with a 13-pin socket and also a variant with a 7 pin socket are available in service.

The fundamental difference between the two variants:

• The 7-pin version does not support deactivation of the parking aid (if it is installed in the vehicle).

The trailer towbar module is connected to constant positive at the passenger compartment fuse box (terminal 30, fuse 23).

For the 13-pin version, the trailer towbar module is connected with the parking aid module. As soon as a connector is inserted into the socket, the rear parking aid is deactivated.

Item	Description				
3	Hand wheel for locking ball neck				
4	Removable ball neck				

# **SECTION 501-02 Front End Body Panels**

### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS				PAGE

#### **REMOVAL AND INSTALLATION**

Cowl Panel Grille	501-02-2
Fender Splash Shield	501-02-3

### **REMOVAL AND INSTALLATION**

# Cowl Panel Grille

### **General Equipment**


Two Leg Puller

### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

1. A CAUTION: Make sure that the motor is in the park position.

General Equipment: Two Leg Puller Torque: <u>24 Nm</u>



### Installation

1. A CAUTION: Make sure that the motor is in the park position.

To install, reverse the removal procedure.

2. Refer to: Windshield Wiper Blade and Pivot Arm Adjustment (501-16 Wipers and Washers, General Procedures).


### **REMOVAL AND INSTALLATION**

# Fender Splash Shield


### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Wheel and Tire (204-04 Wheels and Tires, Removal and Installation).
- 2. If equipped.







### Installation

1. To install, reverse the removal procedure.

# **SECTION 501-03 Body Closures**

### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS


PAGE

#### **GENERAL PROCEDURES**


Front Door Alignment	501-03-2
Rear Door Alignment	501-03-11
Hood Alignment	501-03-14
Liftgate Alignment	501-03-20


# Front Door Alignment

# Inspection



### Adjustment







**4.** On driver's side:




5. On driver's side: Loosen: <u>1 turn(s)</u>




6. On front passenger's side:




7. On front passenger's side: Loosen: <u>1 turn(s)</u>




- 8. 1. Loosen: <u>1 turn(s)</u>
  - 2. If equipped. Loosen: <u>1 turn(s)</u>







 10. 1. Torque: <u>25 Nm</u>
 2. If equipped. Torque: <u>12 Nm</u>



**11.** On driver's side: Torque: <u>25 Nm</u>




**12** On front passenger's side: Torque: <u>25 Nm</u>




# Inspection






# Adjustment

**14.** Loosen: <u>1 turn(s)</u>



15.




### 16. Torque: <u>20 Nm</u>




# **Rear Door Alignment**

# Inspection




### Adjustment


18.



### 19. Loosen: <u>1 turn(s)</u>




- **20.** 1. Loosen: <u>1 turn(s)</u>
  - 2. If equipped. Loosen: <u>1 turn(s)</u>
  - Torque: <u>25 Nm</u>
     If equipped. Torque: <u>12 Nm</u>



**21.** Torque: <u>25 Nm</u>










### Adjustment

23. Loosen: <u>1 turn(s)</u>






25. Torque: <u>20 Nm</u>



# Hood Alignment

### Check


**26.** 1. 3.9 mm ± 1.5 mm 2. 0.1 mm ± 1.5 mm




**28**.


### Adjustment


27. Loosen: <u>1 turn(s)</u>






#### 29. Loosen: 1 turn(s)





32 Torque: <u>12 Nm</u>



33. Check the area for paintwork damage and repair if necessary.






35.


# **GENERAL PROCEDURES**

34. Torque: 20 Nm



### Check


- **36.** 1. 1 mm ± 1.5 mm
  - 2. 4.5 mm ± 2 mm
  - 3. 6 mm ± 1.5 mm




# Adjustment


38.


**37.** On both sides. Loosen: <u>1 turn(s)</u>






#### 39. Loosen: 1 turn(s)










42 On both sides. Torque: 25 Nm




43. Check the area for paintwork damage and repair if necessary.

45.

# **GENERAL PROCEDURES**


44. Torque: <u>20 Nm</u>



# Liftgate Alignment

### Check

- **46.** 1. 2 mm ± 1.5 mm
  - 2. 4.2 mm ± 1.5 mm
  - 3. 6.2 mm ± 2 mm




### Adjustment

47. Loosen: <u>1 turn(s)</u>



48. Loosen: 1 turn(s)









**51.** Torque: <u>11 Nm</u>



- **52** Check the area for paintwork damage and repair if necessary.
- 53. Torque: <u>24 Nm</u>




### Check

**54.** 1. 6.7 mm ± 1.5 mm 2. 2.3 mm ± 1.5 mm


### 501-03-22

# **GENERAL PROCEDURES**



# Adjustment


3-door




56.

3-door and 5-door


57.




**58.** On both sides. Loosen: <u>1 turn(s)</u>




59. Loosen: <u>1 turn(s)</u>








61.




62 On both sides. Torque: <u>48 Nm</u>



63. Torque: <u>24 Nm</u>




64.




3-door

65.



5-door

66.



# **SECTION 501-05 Interior Trim and Ornamentation**

### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **REMOVAL AND INSTALLATION**


A-Pillar Trim Panel	501-05-2
B-Pillar Trim Panel — 5-Door	501-05-3
C-Pillar Trim Panel — 4-Door	501-05-5
C-Pillar Trim Panel — 5-Door	501-05-8
Front Door Trim Panel	501-05-10
Loadspace Trim Panel — 4-Door	501-05-12
Loadspace Trim Panel — 5-Door	501-05-16
Liftgate Trim Panel	501-05-20
Rear Door Trim Panel	501-05-21
Rear Quarter Trim Panel	501-05-23
Headliner — 4-Door	501-05-25
Headliner — 5-Door	501-05-31

# **REMOVAL AND INSTALLATION**

# A-Pillar Trim Panel

### Removal

1. 1. If equipped.



### Installation

**1.** To install, reverse the removal procedure.


1.

# **REMOVAL AND INSTALLATION**


# B-Pillar Trim Panel — 5-Door

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.



#### 2. Torque: <u>40 Nm</u>



3.	
E105032	


### Installation

# C-Pillar Trim Panel — 4-Door


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.


1. Torque: <u>45 Nm</u>



2.








#### Installation

# C-Pillar Trim Panel — 5-Door


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

1. Torque: <u>40 Nm</u>



2.



### Installation

# Front Door Trim Panel


#### **General Equipment**

Flat-bladed screwdriver

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

1. General Equipment: Flat-bladed screwdriver General Equipment: Interior Trim Remover




#### **General Equipment**

Interior Trim Remover TORX screwdriver

#### Vehicles with manual windows







Vehicles with power windows

4. General Equipment: Interior Trim Remover







#### All vehicles

5. 1. If equipped.


General Equipment: TORX screwdriver General Equipment: Interior Trim Remover



### Installation

# Loadspace Trim Panel — 4-Door


### Removal







4.

# **REMOVAL AND INSTALLATION**











6.




#### Installation

# Loadspace Trim Panel — 5-Door


### Removal






4.

## **REMOVAL AND INSTALLATION**










6.



 7.

## Installation

# Liftgate Trim Panel

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

1. E107803



## Installation

**1.** To install, reverse the removal procedure.



2.

# **Rear Door Trim Panel**

#### **General Equipment**

Interior Trim Remover

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

1.



Vehicles with manual windows

2.




3. General Equipment: Interior Trim Remover



Vehicles with power windows

4. General Equipment: Interior Trim Remover



## Installation

# Rear Quarter Trim Panel


#### **General Equipment**

Flat-bladed screwdriver


#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

1. General Equipment: Flat-bladed screwdriver




2.






**4.** Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).



6. Torque: <u>40 Nm</u>



### Installation

# Headliner — 4-Door


#### **General Equipment**

Flat-bladed screwdriver


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- 1. On both sides.
  - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 2. Move the front seats backwards and fully recline the front seats backrests.





**4.** On both sides. Torque: <u>45 Nm</u>




5. On both sides.










**8.** General Equipment: Flat-bladed screwdriver













Vehicles with roof opening panel





All vehicles 13. Support the headliner.




15. CAUTIONS:

A Take extra care not to damage the wiring

## **REMOVAL AND INSTALLATION**

**14. NOTE:** This step is not necessary when installing a new component.



**16. NOTE:** This step is not necessary when installing a new component.

**NOTE:** Note the position of each component before removal.



### Installation

**1. NOTE:** Make sure that these components are installed to the noted removal position.


Using a suitable adhesive, bond the roof wiring harness to the headliner.

Headliner — 5-Door


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- 1. On both sides.
  - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).



3.





**4.** On both sides. Torque: <u>40 Nm</u>




5. On both sides.












9. If equipped.



10. If equipped.





11. If equipped.




12 If equipped.

13. If equipped.





15.



**16. NOTE:** This step is only necessary when installing a new component.



**17. NOTE:** This step is only necessary when installing a new component.

**NOTE:** Note the position of each component before removal.

## Interior Trim and Ornamentation

### **REMOVAL AND INSTALLATION**



### Installation

**1. NOTE:** Make sure that the components are installed to the position noted before removal.

# **SECTION 501-08 Exterior Trim and Ornamentation**

#### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

PAGE


#### DESCRIPTION AND OPERATION

Exterior Trim (Component Location)	501-08-2
Exterior Trim (System Operation and Component Description)	501-08-3
System Operation	501-08-3
Component Description	501-08-3
Windshield strip	501-08-3
Roof strip	501-08-3
Trim strip - front door window	501-08-3
Sticker - front door window	501-08-3
Trim strip - rear door window	501-08-4
Sticker - rear door window	501-08-4
Trim strip - rear side window (4-door)	501-08-4
Trim strip - rear side window (5-door)	
Lettering - luggage compartment lid (4-door)	501-08-4
Lettering - tailgate (5-door)	501-08-5
Emblem - luggage compartment lid (4-door)	501-08-5
Emblem - tailgate (5-door)	501-08-5
Trim strip - luggage compartment lid (4-door)	501-08-5
Trim strip - tailgate (5-door)	501-08-6
Variant sign - luggage compartment lid (4-door)	501-08-6
Variant sign - tailgate (5-door)	501-08-6
S-sign - luggage compartment lid (4-door)	501-08-7
S-sign - tailgate (5-door)	501-08-7
REMOVAL AND INSTALLATION	

Rear S	poiler	501-08-8
		001 00 0

# **DESCRIPTION AND OPERATION**

# Exterior Trim – Component Location



ltem	Description
1	Windshield strip
2	Sticker - front door window
3	Roof strip
4	Trim strip - front door window
5	Trim strip - rear door window
6	Trim strip, rear side window
7	Sticker - rear door window

Item	Description
8	Lettering - tailgate / luggage compartment lid
9	Emblem - tailgate / luggage compartment lid
10	Trim strip - tailgate / luggage compartment lid
11	Variant signs - tailgate / luggage compartment lid

# Exterior Trim – System Operation and Component Description


# **System Operation**

Depending on the way in which they are attached, the components can either be reused or need to be replaced.

Components which are attached with adhesive take should be detached with a plastic wedge.

# **Component Description**

#### Windshield strip



The trim strip comes in two parts. Part 1 is inserted in part 2 and can be pulled out to the top.

Part 2 is glued and only becomes accessible once the windshield has been removed.

Both parts will need to be replaced with new ones after the old ones have been removed.


#### Roof strip



The trim strip is glued.

A new trim strip will need to be fitted after the old one has been removed.


#### Trim strip - front door window



The trim strip is a push-fit.


The trim strip can be reused after it has been removed.

#### Sticker - front door window



The sticker comes in two parts and a new one will need to be fitted after the old one has been removed.


#### Trim strip - rear door window



The trim strip is a push-fit.


The trim strip can be reused after it has been removed.

#### Sticker - rear door window



The sticker comes in two parts and a new one will need to be fitted after the old one has been removed.






The trim strip is glued.

A new trim strip will need to be fitted after the old one has been removed.

#### Trim strip - rear side window (5-door)



The strip is secured with adhesive tape.

A new trim strip will need to be fitted after the old one has been removed.

# Lettering - luggage compartment lid (4-door)



The lettering is retained with adhesive tape.

A new replacement will needed after the old one has been removed.

The lettering must be horizontally centered.

### Lettering - tailgate (5-door)



There are different positions on the vehicle depending on the vehicle specification. Before replacing, determine the dimensions from this or a similar vehicle and fit accordingly.

The lettering is retained with adhesive tape.

A new replacement will needed after the old one has been removed.

The lettering must be horizontally centered.

#### Emblem - luggage compartment lid (4-door)



The emblem is secured with adhesive tape.

A new one will need to be fitted after the old one has been removed.


#### Emblem - tailgate (5-door)



The emblem is secured with adhesive tape.


A new one will need to be fitted after the old one has been removed.

# Trim strip - luggage compartment lid (4-door)



The trim strip is a push-fit. It can be re-used after removal.


#### Trim strip - tailgate (5-door)



The trim strip is a push-fit.

It can be re-used after removal.

# Variant sign - luggage compartment lid (4-door)



There are different variant signs and positions on the vehicle depending on the vehicle specification. Before replacing, determine the dimensions from this or a similar vehicle and fit accordingly.

The sign is secured with adhesive tape.

A new one will need to be fitted after the old one has been removed.

The variant sign must be horizontally centered.

#### Variant sign - tailgate (5-door)




There are different variant signs and positions on the vehicle depending on the vehicle specification. Before replacing, determine the dimensions from this or a similar vehicle and fit accordingly.

The sign is secured with adhesive tape.

A new one will need to be fitted after the old one has been removed.

The variant sign must be horizontally centered.

S-sign - luggage compartment lid (4-door)



The sign is secured with adhesive tape.

A new one will need to be fitted after the old one has been removed.

### S-sign - tailgate (5-door)



There are different positions on the vehicle depending on the vehicle specification. Before replacing, determine the dimensions from this or a similar vehicle and fit accordingly.

The sign is secured with adhesive tape.

A new one will need to be fitted after the old one has been removed.


1.

# **REMOVAL AND INSTALLATION**

# **Rear Spoiler**

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.



2.



#### Installation

# **SECTION 501-09 Rear View Mirrors**

#### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **DIAGNOSIS AND TESTING**

Rear View Mirrors	501-09-2
Inspection and Verification	501-09-2
Rear View Mirrors — Vehicles With: Double Locking	501-09-4
-	501-09-4
REMOVAL AND INSTALLATION	
Exterior Mirror	501-09-5

# **Rear View Mirrors**

Refer to Wiring Diagrams Section 501-09, for schematic and connector information.

### **Inspection and Verification**

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical and electrical damage.

#### **Visual Inspection Chart**

Mechanical	Electrical
Exterior mirror(s)	Fuse(s)
	<ul><li> Loose or corroded connector(s)</li><li> Switch</li></ul>

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 4. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart.

Symptom	Possible Sources	Action
The exterior mirrors are inoper- ative	Exterior mirror control switch	CARRY OUT the Exterior Mirror Control Switch Component Test. REFER to the Wiring Diagrams.
	Circuit(s).	• REFER to the wiring diagrams.
A single exterior mirror is inop- erative	Exterior mirror control switch.	CARRY OUT the Exterior Mirror Control Switch Component Test. REFER to the Wiring Diagrams.
	<ul><li>Exterior mirror motor(s).</li><li>Circuit(s).</li></ul>	• REFER to the wiring diagrams.
A single exterior mirror does not function with switch logic	Exterior mirror control switch.	CARRY OUT the Exterior Mirror Control Switch Component Test. REFER to the Wiring Diagrams.
	<ul><li>Exterior mirror motor(s).</li><li>Circuit(s).</li></ul>	REFER to the wiring diagrams.
The heated exterior mirror is inoperative	<ul> <li>Heated rear window control switch.</li> </ul>	CARRY OUT the Heated Rear Window Control Switch Component Test. REFER to the Wiring Diagrams.
	<ul> <li>Heated rear window relay.</li> <li>Heated exterior mirror element(s).</li> <li>Circuit(s).</li> </ul>	REFER to the wiring diagrams.
The power folding mirrors do not operate	Generic electronic module     (GEM).	CARRY OUT the GEM Self- Test.
		REFER to: Generic Electronic Module (GEM) (419-10 Multi- function Electronic Modules, Diagnosis and Testing).

Symptom	Possible Sources	Action
	Exterior mirror control switch.	CARRY OUT the Exterior Mirror Control Switch Component Test. REFER to the Wiring Diagrams.
	Circuit(s).	• REFER to the wiring diagrams.
The power folding mirrors do not operate correctly	Generic electronic module     (GEM).	CARRY OUT the GEM Self- Test.
		REFER to: Generic Electronic Module (GEM) (419-10 Multi- function Electronic Modules, Diagnosis and Testing).
	Exterior mirror control switch.	CARRY OUT the Exterior Mirror Control Switch Component Test. REFER to the Wiring Diagrams.
	<ul><li> Power fold mirror motor(s).</li><li> Circuit(s).</li></ul>	REFER to the wiring diagrams.

5. If the cause is not visually evident, verify the symptom and refer to the Ford approved diagnostic tool to diagnose the system.

# Rear View Mirrors — Vehicles With: Double Locking

Refer to Wiring Diagrams Section 501-09, for schematic and connector information.

#### **General Equipment**

Ford diagnostic equipment

#### Inspection and Verification

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical and electrical damage.

#### **Visual Inspection Chart**

Mechanical	Electrical
Exterior mirror(s)	<ul> <li>Fuse(s)</li> <li>Relay</li> <li>Electrical connector(s)</li> <li>Switch</li> <li>Generic electronic</li> </ul>

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 4. If the cause is not visually evident, verify the symptom and refer to the diagnostic tab within the Ford diagnostic equipment.

# **Exterior Mirror**


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Front Door Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 2.



3. Torque: <u>13 Nm</u>



### Installation

# **SECTION 501-10 Seating**

### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **DESCRIPTION AND OPERATION**

Seats (Overview)	501-10-2
Overview of components	501-10-2
Manually adjustable lumbar supports	501-10-3
	501-10-3
	501-10-3

#### **DIAGNOSIS AND TESTING**

Seats	501-10-4
Inspection and Verification	501-10-4

#### **REMOVAL AND INSTALLATION**

Front Seat	(40 100 0;	
	40 100 4;	
	40 101 0)	501-10-5
Front Seat Cushion Cover	(40 105 0)	501-10-7
Front Seat Cushion Heater Mat	(33 401 0;	
	33 401 4)	501-10-10
Front Seat Cushion	(40 104 0)	501-10-11
Front Seat Backrest Cover	(40 108 0)	501-10-12
Rear Seat Cushion		501-10-16
Rear Seat Backrest		501-10-17
Rear Seat Backrest Latch		501-10-18
Seat Occupant Sensor		501-10-21

#### DISASSEMBLY AND ASSEMBLY

Front Seat Backrest	501-10-22
Rear Seat Cushion	501-10-28
Rear Seat Backrest	501-10-30

# Seats – Overview


# **Overview of components**



ltem	Description
1	Backrest trim cover
2	Front seat cushion cover
3	Seat frame
4	Head restraint adjustment.
5	Head restraint guide
6	Manually adjustable lumbar supports
7	Front belt buckle
	Refer to: Safety Belt System (501-20 Safety Belt System, Description and Operation).

Item	Description
8	Seat occupancy sensor, passenger side
9	Front seat cushion heating mat
10	Seat height adjustment lever
11	Side airbag
	Refer to: Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (501-20 Supplemental Restraint System, Description and Operation).
12	Folding backrest lever

#### Manually adjustable lumbar supports



The manually adjustable lumbar support is adjusted using a hand-wheel on the side of the backrest The hand-wheel is connected with a cable to a flexible plate mounted behind the backrest squab. As the hand-wheel rotates, the plate is distorted and is forced to bow toward or away from the seat squab. The manual adjustment system means the lumbar support can be adjusted with a great deal of accuracy.


#### Seat occupancy sensor, passenger side



Pay attention to the following when removing, installing or renewing the passenger side occupancy sensor:

• The seat occupancy sensor is glued to the seat cushion. It is available as an individual spare part and can be renewed separately.

#### Front seat cushion heating mat



Item	Description
1	Front seat cushion heating mat
2	Seat heating module

The following components can be replaced separately or as a unit:

- · Front seat cushion heating mat
- Seat heating module

# Seats

#### **General Equipment**

Ford diagnostic equipment

#### **Inspection and Verification**

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical and electrical damage.

#### Visual Inspection Chart

Electrical
• Fuse
<ul><li>Wiring harness</li><li>Electrical</li></ul>
Connector(s)
Switch

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 4. If the cause is not visually evident, verify the symptom and refer to the Ford diagnostic equipment to diagnose the system.

# Front Seat(40 100 0; 40 100 4; 40 101 0)

#### Removal


#### WARNINGS:


- The supplemental restraint system (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.
- Make sure that the vehicle electrical system is fully depowered and no other power source is connected.
- Wear safety goggles.

**NOTE:** Removal steps in this procedure may contain installation details.

- Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).
- **2.** Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

3.










#### Installation

1. Torque: 35 Nm



# Front Seat Cushion Cover(40 105 0)


#### **General Equipment**


Hog Ring Plier

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Front Seat (501-10 Seating, Removal and Installation).
- 2. If equipped.






4.




### 5. 4. If equipped.



#### Installation

- **1.** To install, reverse the removal procedure.
- 2. General Equipment: Hog Ring Plier




# Front Seat Cushion Heater Mat(33 401 0; 33 401 4)

#### Removal

- **1.** Refer to: Front Seat Cushion Cover (501-10 Seating, Removal and Installation).
- 2. A CAUTION: Touching the adhesive surface will impair rebonding.


**NOTE:** Note the position of the component before removal.



Installation

**1.** 1. **NOTE:** This step is only necessary when installing a new component.

**NOTE:** Make sure that these components are installed to the noted removal position.



**2.** Refer to: Front Seat Cushion Cover (501-10 Seating, Removal and Installation).

# Front Seat Cushion(40 104 0)

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Front Seat Cushion Cover (501-10 Seating, Removal and Installation).
- 2. If equipped.
  - Refer to: Front Seat Cushion Heater Mat (501-10 Seating, Removal and Installation).
- 3. If equipped.

Refer to: Seat Occupant Sensor (501-10 Seating, Removal and Installation).

#### Installation

# Front Seat Backrest Cover(40 108 0)

#### **General Equipment**


Flat-bladed screwdriver

Hog Ring Plier

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

**1.** Refer to: Front Seat (501-10 Seating, Removal and Installation).




3. General Equipment: Flat-bladed screwdriver







4. General Equipment: Flat-bladed screwdriver




5. If eqipped.




6.




7.






9.



11.

# **REMOVAL AND INSTALLATION**






E100401

#### Installation

- 1. To install, reverse the removal procedure.
- **2. NOTE:** This step is only necessary when installing a new component.

**NOTE:** Use the original seat backrest cover as a template.


3. General Equipment: Hog Ring Plier



# **Rear Seat Cushion**

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.



#### Installation

# **Rear Seat Backrest**


#### **General Equipment**

Flat-bladed screwdriver

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.


#### 1. Torque: 40 Nm



**2.** General Equipment: Flat-bladed screwdriver



**3.** General Equipment: Flat-bladed screwdriver



Installation

# Rear Seat Backrest Latch


#### **General Equipment**


Flat-bladed screwdriver

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
- 2. Torque: <u>40 Nm</u>






4. General Equipment: Flat-bladed screwdriver



 General Equipment: Flat-bladed screwdriver Torque: <u>23 Nm</u>




## Installation

# Seat Occupant Sensor

Removal

- **1.** Refer to: Front Seat Cushion Cover (501-10 Seating, Removal and Installation).
- 2. If equipped.

Refer to: Front Seat Cushion Heater Mat (501-10 Seating, Removal and Installation).



#### Installation

# DISASSEMBLY AND ASSEMBLY

# Front Seat Backrest


## Disassembly


**NOTE:** Removal steps in this procedure may contain installation details.

- If equipped.
   If equipped.
- **1.** Refer to: Front Seat Backrest Cover (501-10 Seating, Removal and Installation).
- 2.




## **DISASSEMBLY AND ASSEMBLY**






5. NOTE: Note the position of the electrical connectors.


# DISASSEMBLY AND ASSEMBLY



6. Torque: <u>6 Nm</u>



7. If equipped. Torque: <u>3 Nm</u>




- 8. If equipped.
- <image>


9. If equipped.

3-door

10.




11.



All vehicles

12 Torque: <u>35 Nm</u>



## Assembly

**13.** To install, reverse the removal procedure.

## **Rear Seat Cushion**


#### **General Equipment**

Hog Ring Plier


#### Disassembly

**1.** Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).

#### 2.




3.



## Assembly

- 4. To install, reverse the removal procedure.
- 5. General Equipment: Hog Ring Plier



## **Rear Seat Backrest**

#### **General Equipment**

Flat-bladed screwdriver


#### Disassembly

**NOTE:** Removal steps in this procedure may contain installation details.


#### **General Equipment**

Hog Ring Plier	
Webbing Retainer	


- **1.** Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
- 2. General Equipment: Flat-bladed screwdriver




3. General Equipment: Flat-bladed screwdriver




**4. NOTE:** If the safety belt webbing retracts further than the safety belt webbing stop, a new safety belt retractor must be installed.




5. Torque: <u>35 Nm</u>




6. Torque: <u>35 Nm</u>



7.







3. Torque: <u>40 Nm</u>

### DISASSEMBLY AND ASSEMBLY


- 9. 1. Torque: <u>23 Nm</u>
  - 2. Torque: <u>23 Nm</u>



#### Assembly

**10.** To install, reverse the removal procedure.

#### 11. General Equipment: Hog Ring Plier



## **SECTION 501-11 Glass, Frames and Mechanisms**

#### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **DESCRIPTION AND OPERATION**

Glass, Frames and Mechanisms (Overview)	501-11-2
Driver's door switch unit	501-11-2
Switches - passenger door and rear doors	501-11-2
Window regulator motors	501-11-3
Service instructions	501-11-3
Diagnostic Information	501-11-3

#### **DIAGNOSIS AND TESTING**

Glass, Frames and Mechanisms	501-11-4
Inspection and Verification	501-11-4
Component Tests	501-11-5
Glass, Frames and Mechanisms — Vehicles With: Double Locking	501-11-7
Inspection and Verification	501-11-7
Component Tests	501-11-7

#### **REMOVAL AND INSTALLATION**

Front Door Window Glass	501-11-8
Rear Door Window Glass	501-11-12
Liftgate Window Glass	501-11-14
Rear Quarter Window Glass	501-11-17
Rear Window Glass	501-11-28
Front Door Window Regulator Motor	501-11-35
Rear Door Window Regulator Motor	501-11-36
Front Door Window Regulator	501-11-37
Rear Door Window Regulator	501-11-41
Windshield Glass	501-11-45

#### **DESCRIPTION AND OPERATION**


## Glass, Frames and Mechanisms - Overview

The function is based on that of the Fiesta 2002.25.

The main difference is the adoption of **automatic operation with anti-trap protection on the driver side**. To do this, the switch for the driver's door window on the driver's door switch unit is designed as a **two-stage switch**.

In addition, the window regulator motor on the driver's door is provided with two Hall sensors. The Hall sensors detect the speed of the window regulator motor and therefore recognize any obstruction as the window rises.

#### Driver's door switch unit



ltem	Description	
Α	4-way switch unit	
В	2-way switch unit	
1	Rear window disable switch	

In total there are six driver door switch units available:

- Two 4-way switch units:
  - one for LHD (left-hand drive),
  - one for RHD (right-hand drive).
- Four 2-way switch units:
  - one for LHD with three doors,
  - one for LHD with five doors,
  - one for RHD with three doors,
  - one for RHD with five doors.

Because of the shape of the components, it is not possible to mix up the switch units for LHD and RHD vehicles.

#### NOTE:

• The **2-way switch units** for the **3-door and the 5-door** variants are identical on the outside. They must not however be mixed up as the software in the switch unit is matched to the particular type of window and frame. The part number suffix is used to determine which switch unit is correct for the vehicle.

## Switches - passenger door and rear doors




These doors are equipped with a simple switch for the window regulator motors.

This switch only has a simple up and down function (no anti-trap protection).

**Note:**The window regulator motors in the rear doors can be deactivated using the disable switch in the driver's door switch unit.

#### DESCRIPTION AND OPERATION

#### Window regulator motors



Item	Description	
1	Rear left-hand door window regulator motor	
2	Window regulator motor, driver's side	
3	Window regulator motor, passenger's side	
4	Rear right-hand door window regulator motor	
5	Driver's door switch unit	

**NOTE:** If a window regulator is operated at the same time from the driver's door switch unit and from the respective simple switch, the relevant window stops immediately.

Each window regulator motor can be controlled from the driver's door switch unit.

In addition, the motors for the passenger's door and the rear doors (when equipped) can be controlled using the corresponding simple switches on the doors.

#### Service instructions

After the battery has been disconnected or the driver's door switch unit has been changed, the window regulator motor in the driver's door must be reprogrammed (see current service literature).

#### **Diagnostic Information**

The switch unit and the window regulator motors are not connected to the communication network. The system cannot therefore be diagnosed using the DLC (data link connector).

## Instructions if there is a operating concern with the driver's door window regulator motor:

- After the window regulator motors have been deactivated, they continue to turn for a short time. During "Ignition ON" the switch unit detects the run-on phase via the Hall sensors.
- If however the ignition is switched off while the driver's door window regulator motor is operating, the power supply of the **Hall sensors** is immediately interrupted. The **run-on phase** of the window regulator motor then can no longer be detected.
- In order to maintain the power supply for this situation, the driver's door switch unit is protected by an additional fuse F26 (in the engine compartment fuse box).
- If the fuse fails the driver's door window regulator motor will no longer operate.

## Instruction if there is a malfunction of both front window regulator motors:

• Both window regulator motors are protected in common by fuse F25 (passenger compartment fuse box).

## Instruction if there is a malfunction of both rear window regulator motors:

 Both window regulator motors are protected in common by fuse F31 (passenger compartment fuse box).

## Glass, Frames and Mechanisms

Refer to Wiring Diagrams Section 501-11, for schematic and connector information.

## Inspection and Verification

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical or electrical damage.

#### **Visual Inspection Chart**

Electrical
• Fuse(s)
<ul> <li>Electrical connector(s)</li> <li>Switch(es)</li> <li>Circuit(s)</li> </ul>
•

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 4. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart.

	Symptom	Possible Sources	Action
All po ative	ower windows are inoper-	Driver power window control switch.	CARRY OUT the Driver Power Window Control Switch Component Test in this procedure.
		Circuit(s).	• REFER to the wiring diagrams.
	igle power window is inop- ve - driver side	<ul> <li>Driver power window control switch.</li> </ul>	CARRY OUT the Driver Power Window Control Switch Component Test in this procedure.
		<ul><li>Power window motor.</li><li>Circuit(s).</li></ul>	REFER to the wiring diagrams.
	igle power window is inop- ve - passenger side	Driver power window control switch.	CARRY OUT the Driver Power Window Control Switch Component Test in this procedure.
		<ul> <li>Passenger power window control switch.</li> </ul>	CARRY OUT the Passenger Power Window Control Switch Component Test in this procedure.
		<ul><li>Power window motor.</li><li>Circuit(s).</li></ul>	• REFER to the wiring diagrams.
	one-touch down window is erative	<ul> <li>Driver power window control switch.</li> </ul>	CARRY OUT the Driver Power Window Control Switch Component Test in this procedure.
The ative	defrost system is inoper-	<ul> <li>Heated rear window control switch.</li> </ul>	CARRY OUT the Heated Rear Window Control Switch Component Test in this procedure.

#### Symptom Chart

Symptom	Possible Sources	Action
	<ul> <li>Heated windshield control switch.</li> </ul>	CARRY OUT the Heated Windshield Control Switch Component Test in this procedure.
	Rear Window Heater Relay.	CARRY OUT the Rear Window Heater Relay Component Test in this procedure.
	Generic electronic module     (GEM).	CARRY OUT the Generic     Electronic Module Self-Test.
		REFER to: Generic Electronic Module (GEM) (419-10 Multi- function Electronic Modules, Diagnosis and Testing).
	Heated rear window grid wire.	CARRY OUT the Heated Rear Window Grid Wire Component Test in this procedure.
	<ul><li>Heated windshield grid wire.</li><li>Circuit(s).</li></ul>	• REFER to the wiring diagrams.
The defrost system will not shut off automatically	<ul> <li>Heated rear window control switch.</li> </ul>	CARRY OUT the Heated Rear Window Control Switch Component Test in this procedure.
	<ul> <li>Heated windshield control switch.</li> </ul>	CARRY OUT the Heated Windshield Control Switch Component Test in this procedure.
	Rear Window Heater Relay.	CARRY OUT the Rear Window Heater Relay Component Test in this procedure.
	Generic electronic module     (GEM).	CARRY OUT the Generic     Electronic Module Self-Test.
		REFER to: Generic Electronic Module (GEM) (419-10 Multi- function Electronic Modules, Diagnosis and Testing).

#### **Component Tests**

#### **Heated Rear Window Switch**

- 1. Remove the heated rear window switch.
- 2. Measure the resistance between pins 1 and 2 of the switch while operating the switch.
- 3. The resistance should be less than 5 ohms when the switch is in the ON position and greater than 10,000 ohms when in the OFF position.
- 4. If the resistances are not as specified, INSTALL a new heated rear window switch.

#### **Rear Window Heater Relay**

- 1. Remove the heated rear window relay.
- 2. Using a jumper wire, connect one end to terminal 1 of the relay. Connect the other end to ground.
- 3. Using a second jumper wire, connect one end to terminal 2 of the relay.

- Connect one lead of an ohmmeter to terminal 3 of the relay. Connect second lead to terminal 5 of the relay. Observe the resistance.
- 5. Momentarily tap the unconnected end of the second jumper wire to the battery power. An audible click should be heard and the resistance on the ohmmeter should drop to zero.
- 6. If the relay does not click and the resistance does not drop to zero, INSTALL a new relay.

#### Heated Rear Window Grid Wire Test

- 1. Using a bright lamp inside the vehicle, visually inspect the wire grid from the outside. A broken grid conductor will appear as a brown spot.
- 2. Start the engine and set the heated rear window switch to ON, the indicator light should illuminate.
- 3. Work inside the vehicle with a 12 volt DC voltmeter. Contact the broad red-brown strips on the rear window, positive lead to the battery side and the negative lead to ground side. The meter reading should be 10-12 volts. A lower voltage reading indicates a loose heated rear window ground wire connection at the heated rear window ground wire screws.
- 4. Contact a ground point with the negative lead of the meter. The voltage reading should not change.
- 5. With the negative lead of the meter grounded, touch each grid line of the heated rear window at its midpoint with the positive meter lead. A reading of approximately six volts indicates that the line is good. A reading of zero volts indicates that the line is broken between the midpoint and the B+ side of the grid line. A reading of 12 volts indicates that the circuit is broken between the midpoint of the grid line and ground.
- 6. Install a new heated rear window using the procedures as described under the general procedures if necessary.

## Glass, Frames and Mechanisms --- Vehicles With: Double Locking

Refer to Wiring Diagrams Section 501-11, for schematic and connector information.

#### **General Equipment**

The Ford diagnostic equipment

#### **Inspection and Verification**

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical or electrical damage.

#### **Visual Inspection Chart**

Mechanical	Electrical
Door window seal	Fuse(s)
Door window frame	<ul> <li>Electrical connector(s)</li> </ul>
	<ul> <li>Switch(es)</li> </ul>
	<ul> <li>Window regulator motor</li> </ul>
	Circuit(s)

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 4. If the cause is not visually evident, verify the symptom and refer to the diagnostic tab within the Ford diagnostic equipment.

#### **Component Tests**

## Liftgate Window Glass Heated Grid Wire Test

- 1. Using a bright lamp inside the vehicle, visually inspect the liftgate window glass heated grid wire from the outside of the vehicle. A broken liftgate window glass heated grid wire will appear as a brown spot at the break point.
- 2. Run the engine at idle.
- 3. Set the heated liftgate window glass control switch and the headlamp switch to ON. The heated liftgate window glass control switch should be illuminated.
- 4. Working inside the vehicle with a multimeter, contact the multimeter positive lead to the liftgate window glass heated grid supply side and contact the multimeter negative lead to the liftgate window glass heated grid ground side.

A multimeter voltage reading of between 10-13 volts is expected. A lower voltage reading indicates a loose liftgate window glass heated grid ground wire connection at the liftgate window glass heated grid ground screw.

- 5. With the negative lead of the multimeter grounded, touch each liftgate window glass heated grid wire at its midpoint with the positive lead. The multimeter should show a voltage reading of approximately six volts indicating that the liftgate window glass heated grid wire is OK. A multimeter voltage reading of zero volts indicates that the liftgate window glass heated grid wire is broken between the midpoint and the battery side of the liftgate window glass heated grid wire. A multimeter voltage reading of 12 volts indicates that the liftgate window glass heated grid wire is broken between the midpoint of the liftgate window glass heated grid wire and ground.
- 6. INSTALL a new liftgate window glass (as required).
  - REFER to: Liftgate Window Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).

## Front Door Window Glass

#### **General Equipment**


Flat-bladed screwdriver


#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

3-door










5. General Equipment: Flat-bladed screwdriver




## Glass, Frames and Mechanisms


## **REMOVAL AND INSTALLATION**

5-door


6.



7. Torque: <u>7 Nm</u>



#### All vehicles



#### Installation


**1.** To install, reverse the removal procedure.

## Rear Door Window Glass

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.


**1.** Refer to: Rear Door Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).












6. Torque: <u>7 Nm</u>



#### Installation

**1.** To install, reverse the removal procedure.


## Liftgate Window Glass

Materials	
Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5
General Equipment	
Adhesive Tape	


#### Removal

- 1. Refer to: Window Glass Health and Safety Precautions (100-00 General Information, Description and Operation).
- 2. Remove the polyurethane (PU) adhesive cap and heat the PU adhesive for a minimum of 30 minutes.

Material: Windshield Adhesive Kit (WSS-M11P57-A5)



- Refer to: Rear Spoiler (501-08 Exterior Trim and Ornamentation, Removal and Installation).
   Refer to: Rear Window Wiper Motor (501-16 Wipers and Washers, Removal and Installation).
- 4. On both sides.



#### **General Equipment**

Direct Glazing Removal/Replacement Equipment
Hot Air Gun
Knife
Laminated Card



# CAUTION: Make sure that the cutting blades are changed where the cutting depth changes.

Use laminated card to prevent paint damages.

General Equipment: Direct Glazing Removal/Replacement Equipment General Equipment: Laminated Card



#### Installation

1. NOTE: Minimum 1 mm bead thickness.

**NOTE:** Make sure that the mating faces are clean and free of foreign material.

**NOTE:** Touching the adhesive surface will impair rebonding.

General Equipment: Knife General Equipment: Hot Air Gun




2. NOTE: This step is only necessary if the original component is to be reused.

NOTE: Minimum 1 mm bead thickness.

**NOTE:** Make sure that the mating faces are clean and free of foreign material.

**NOTE:** Touching the adhesive surface will impair rebonding.

General Equipment: Knife General Equipment: Hot Air Gun



**3. NOTE:** Discard the first 100 mm of adhesive as this may have a reduced working time.

**NOTE:** Make sure that any breakage in the continuous bead of adhesive is overlapped by 20 mm.

General Equipment: Direct Glazing Removal/Replacement Equipment Material: Windshield Adhesive Kit (WSS-M11P57-A5)


(1030-10111 37-A3)	
Ø8 - 10mm	
E107843	

4. A CAUTION: During the curing time of the polyurethane (PU) adhesive, the door windows must be left open.

General Equipment: Adhesive Tape



5. On both sides.



**6.** Refer to: Rear Window Wiper Motor (501-16 Wipers and Washers, Removal and Installation).

Refer to: Rear Spoiler (501-08 Exterior Trim and Ornamentation, Removal and Installation).

## Rear Quarter Window Glass

Materials	
Name	Specification
	WSK-M11P57-A3 / 7U7J-T03863-AA
Windshield Adhesive Kit	WSS-M11P57-A5

#### Removal

#### 1. A CAUTION:

Refer to: Window Glass Health and Safety Precautions (100-00 General Information, Description and Operation).

#### **General Equipment**


Adhesive Tape	
Direct Glazing Removal/Replacement Equipment	
Knife	
Laminated Card	

- 2. 1. Material: Windshield Adhesive Kit (WSS-M11P57-A5)
  - 2. Remove the polyurethane (PU) adhesive cap and heat the 2K-PU adhesive for a minimum of 30 minutes.

General Equipment: Direct Glazing Removal/Replacement Equipment


3. Repairs under warranty:

Material: Windscreen Adhesive Kit - 1 Component (WSK-M11P57-A3 / 7U7J-T03863-AA)



3-door


3. General Equipment: Adhesive Tape



4. A WARNING: Make sure that the component paintwork is not damaged.


**NOTE:** Some resistance may be encountered when cutting through the glass locating spacers.

General Equipment: Laminated Card General Equipment: Direct Glazing Removal/Replacement Equipment



#### 5-door

5.




6. General Equipment: Adhesive Tape



7. A WARNING: Make sure that the component paintwork is not damaged.

**NOTE:** Some resistance may be encountered when cutting through the glass locating spacers.

General Equipment: Laminated Card General Equipment: Direct Glazing Removal/Replacement Equipment




#### Installation

1. 1. NOTE: Minimum 1 mm bead thickness.

General Equipment: Knife


- 2. **NOTE:** Make sure that the mating faces are clean and free of foreign material.
- 3. **NOTE:** Touching the adhesive surface will impair rebonding.

Prepare the rear quarter window glass, rear quarter window glass flange and trimmed PU adhesive in accordance with the instructions supplied with the glass adhesive kit.




#### 3-door

2. Apply the activator/ primer in accordance with the instructions supplied with the glass adhesive kit.




**3.** Apply the activator/ primer in accordance with the instructions supplied with the glass adhesive kit.



**4. NOTE:** Discard the first 100 mm of adhesive as this may have a reduced working time.

**NOTE:** Make sure that any breakage in the continuous bead of adhesive is overlapped by 20 mm.

General Equipment: Direct Glazing Removal/Replacement Equipment Material: Windshield Adhesive Kit (WSS-M11P57-A5) Material: Windscreen Adhesive Kit - 1 Component (WSK-M11P57-A3 / 7U7J-T03863-AA)




5. • Press firmly and evenly into position.

General Equipment: Direct Glazing Removal/Replacement Equipment

CAUTION: During the curing time of the polyurethane (PU) adhesive, the door windows must be left open.


Using tape, secure the rear quarter window glass in the correct position until the PU adhesive has cured.

General Equipment: Adhesive Tape




#### 5-door

**6.** Apply the activator/ primer in accordance with the instructions supplied with the glass adhesive kit.




**7.** Apply the activator/ primer in accordance with the instructions supplied with the glass adhesive kit.



8. NOTE: Discard the first 100 mm of adhesive as this may have a reduced working time.

**NOTE:** Make sure that any breakage in the continuous bead of adhesive is overlapped by 20 mm.

General Equipment: Direct Glazing Removal/Replacement Equipment Material: Windshield Adhesive Kit (WSS-M11P57-A5) Material: Windscreen Adhesive Kit - 1 Component (WSK-M11P57-A3 / 7U7J-T03863-AA)



9. • Press firmly and evenly into position.


General Equipment: Direct Glazing Removal/Replacement Equipment

• CAUTION: During the curing time of the polyurethane (PU) adhesive, the


#### door windows must be left open.

Using tape, secure the rear quarter window glass in the correct position until the PU adhesive has cured.

General Equipment: Adhesive Tape



10.



### Rear Window Glass

#### Materials

Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5


#### **General Equipment**

Adhesive Tape	
Hot Air Gun	
Knife	
Laminated Card	


#### Removal

- 1. Refer to: Window Glass Health and Safety Precautions (100-00 General Information, Description and Operation).
- 2. Remove the polyurethane (PU) adhesive cap and heat the PU adhesive for a minimum of 30 minutes.


Material: Windshield Adhesive Kit (WSS-M11P57-A5)




3. On both sides.





#### 4. On both sides.



5. On both sides.










CAUTION: If the original window glass is to be installed, take care not to damage the electrical connectors and the weatherstrip (if equipped).

Use appropriate cutting wire with suitable handles to cut the glass adhesive. Use adhesive tape and laminated card to prevent paint damages. Use suction cups to handle the window glass.

General Equipment: Laminated Card General Equipment: Adhesive Tape



**9. NOTE:** Note the position of the components before removal.



#### Installation


1. NOTE: Minimum 1 mm bead thickness.

**NOTE:** Make sure that the mating faces are clean and free of foreign material.


**NOTE:** Touching the adhesive surface will impair rebonding.

Prepare the windshield glass, windshield glass flange and trimmed PU adhesive in accordance with the instructions supplied with the PU adhesive kit.


General Equipment: Knife General Equipment: Hot Air Gun



**2.** Apply the primer supplied with the glass adhesive kit.



**3. NOTE:** Make sure that the component is installed to the position noted before removal.




**4. NOTE:** This step is only necessary if the original component is to be reused.

NOTE: Minimum 1 mm bead thickness.


**NOTE:** Make sure that the mating faces are clean and free of foreign material.

**NOTE:** Touching the adhesive surface will impair rebonding.

General Equipment: Knife General Equipment: Hot Air Gun




**5.** Apply the primer supplied with the glass adhesive kit.



6. NOTE: Discard the first 100 mm of adhesive as this may have a reduced working time.

**NOTE:** Make sure that any breakage in the continuous bead of adhesive is overlapped by 20 mm.


Material: Windshield Adhesive Kit (WSS-M11P57-A5)



7. A CAUTION: During the curing time of the polyurethane (PU) adhesive, the door windows must be left open.


Use suction cups to handle the window glass.

General Equipment: Adhesive Tape



**8.** If the ambient temperature falls below 10°C, apply warm air (25°C) continuously for 15 minutes.


General Equipment: Hot Air Gun




9. On both sides.




10. On both sides.




11. On both sides.







13.




### Front Door Window Regulator Motor

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Front Door Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 2. Torque: 3.5 Nm



#### Installation


**1.** To install, reverse the removal procedure.

### Rear Door Window Regulator Motor

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Rear Door Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 2. Torque: 3.5 Nm



#### Installation

**1.** To install, reverse the removal procedure.

### Front Door Window Regulator

#### **General Equipment**

Flat-bladed screwdriver

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.


**1.** Refer to: Front Door Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Front Door Window Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).


3-door

2. A CAUTION: Take extra care not to damage the clips.


General Equipment: Flat-bladed screwdriver



**3.** If equipped. Torque: <u>3.5 Nm</u>




4. Torque: <u>3.5 Nm</u>




4-door and 5-door

5. A CAUTION: Take extra care not to damage the clips.


General Equipment: Flat-bladed screwdriver Torque: <u>8 Nm</u>



6. If equipped. Torque: <u>3.5 Nm</u>



7. Torque: <u>3.5 Nm</u>



#### Installation

**1.** To install, reverse the removal procedure.

### Rear Door Window Regulator

#### **General Equipment**

Adhesive Tape


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

#### **General Equipment**

Flat-bladed screwdriver

- **1.** Refer to: Rear Door Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 2. Torque: 7 Nm




3. General Equipment: Adhesive Tape



Vehicles with manual windows


 General Equipment: Flat-bladed screwdriver Torque: <u>8 Nm</u>




Vehicles with power windows

#### **REMOVAL AND INSTALLATION**

5. Torque: <u>3.5 Nm</u>




7. Torque: <u>3.5 Nm</u>



#### All vehicles

8. Torque: <u>3.5 Nm</u>



#### Installation

1. To install, reverse the removal procedure.

### Windshield Glass

Materials	
Name	Specification
	WSK-M11P57-A3 / 7U7J-T03863-AA
Windshield Adhesive Kit	WSS-M11P57-A5

#### Removal


#### 1. A CAUTION:

Refer to: Window Glass Health and Safety Precautions (100-00 General Information, Description and Operation).

- 2. 1. Material: Windshield Adhesive Kit (WSS-M11P57-A5)
  - 2. Remove the polyurethane (PU) adhesive cap and heat the 2K-PU adhesive for a minimum of 30 minutes.

General Equipment: Direct Glazing Removal/Replacement Equipment

- 3. Repairs under warranty:
  - Material: Windscreen Adhesive Kit 1 Component (WSK-M11P57-A3 / 7U7J-T03863-AA)




#### **General Equipment**

Adhesive Tape


Direct Glazing Removal/Replacement Equipment Knife

**3.** Refer to: Cowl Panel Grille (501-02 Front End Body Panels, Removal and Installation).




Vehicles with heated windshield

- **4.** Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 5. On both sides.





Vehicles with manual dimming interior mirror




Vehicles with autolamps and rain sensor

7.






9.



#### **Glass, Frames and Mechanisms**

#### **REMOVAL AND INSTALLATION**

10.




All vehicles

11. 🕞 🕜

Use a suitable awl to thread the cutting wire.


General Equipment: Direct Glazing Removal/Replacement Equipment




# damage the electrical connectors and the weatherstrip (if equipped).

Use a suitable brace to prevent trim damages.

General Equipment: Direct Glazing Removal/Replacement Equipment






#### Installation

- NOTE: Minimum 1 mm bead thickness. General Equipment: Knife
  - 2. **NOTE:** Make sure that the mating faces are clean and free of foreign material.
  - 3. **NOTE:** Touching the adhesive surface will impair rebonding.


Prepare the windshield glass, windshield glass flange and trimmed PU adhesive in accordance with the instructions supplied with the glass adhesive kit.



kit.


#### **REMOVAL AND INSTALLATION**

**2.** Apply the activator/ primer in accordance with the instructions supplied with the glass adhesive




**3. NOTE:** Touching the adhesive surface will impair rebonding.

**NOTE:** Make sure that the mating faces are clean and free of foreign material.



**4.** Apply the activator/ primer in accordance with the instructions supplied with the glass adhesive kit.



**5. NOTE:** Discard the first 100 mm of adhesive as this may have a reduced working time.

**NOTE:** Make sure that any breakage in the continuous bead of adhesive is overlapped by 20 mm.

General Equipment: Direct Glazing Removal/Replacement Equipment Material: Windshield Adhesive Kit (WSS-M11P57-A5) Material: Windscreen Adhesive Kit - 1 Component (WSK-M11P57-A3 / 7U7J-T03863-AA)

Ø 8-10mm


6. • Press firmly and evenly into position.


General Equipment: Direct Glazing Removal/Replacement Equipment

A CAUTION: During the curing time of the polyurethane (PU) adhesive, the door windows must be left open.

Using tape, secure the windshield glass in the correct position until the PU adhesive has cured.


General Equipment: Adhesive Tape






**8.** Refer to: Cowl Panel Grille (501-02 Front End Body Panels, Removal and Installation).

Vehicles with manual dimming interior mirror




Vehicles with autolamps and rain sensor


#### 10.




11.



12




13.



Vehicles with heated windshield

**14.** On both sides. Torque: <u>11 Nm</u>



**15.** Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

## **SECTION 501-12 Instrument Panel and Console**

#### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

PAGE


#### **REMOVAL AND INSTALLATION**

Floor Console	501-12-2
Floor Console — Vehicles With: 6-Speed Automatic Transaxle (6DCT250)	501-12-4
Instrument Panel — Vehicles With: Manual Temperature Control	501-12-6
Instrument Panel — Vehicles With: Automatic Temperature Control	501-12-30
In-Vehicle Crossbeam	501-12-54

### Floor Console


#### Removal

1. On both sides.





3.




#### Installation

**1.** To install, reverse the removal procedure.


Floor Console — Vehicles With: 6-Speed Automatic Transaxle (6DCT250)

#### Removal


1. On both sides.




2.







5.



#### Installation

**1.** To install, reverse the removal procedure.

### Instrument Panel — Vehicles With: Manual Temperature Control

#### Special Tool(s)



303-435 Mounting Stand Special Tool(s)



Adhesive Tape

Draw Cord

Hose Clamp(s)


TORX screwdriver

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

# 1. A CAUTION: Make sure that the steering wheel lock is engaged.

**NOTE:** Make sure that the road wheels are in the straight ahead position.




2. NOTE: This step is only necessary on vehicles with air conditioning.


Refer to: Air Conditioning (A/C) System Recovery, Evacuation and Charging (412-00

Climate Control System - General Information, General Procedures).


- 3. Refer to: Cowl Panel Grille (501-02 Front End Body Panels, Removal and Installation).
- 4. On both sides.




5.



- 6. A CAUTION: Make sure that the motor is in the park position.
  - 1. Torque: <u>10 Nm</u>
  - 2. Torque: <u>8 Nm</u>




7. Torque: 25 Nm



8. A CAUTION: Make sure that all openings are sealed.

**NOTE:** Vehicles without air conditioning.


1. General Equipment: Hose Clamp(s)



9. A CAUTION: Make sure that all openings are sealed.

**NOTE:** Vehicles with air conditioning.

- 1. Torque: <u>8 Nm</u>
- 2. General Equipment: Hose Clamp(s)




**10.** Remove the driver side front door.

11. Remove the driver seat.

Refer to: Front Seat (501-10 Seating, Removal and Installation).


- **12 NOTE:** This step is only necessary on vehicles with manual transmission.
- **13. NOTE:** This step is only necessary on vehicles with automatic transmission.

14.






18. On both sides.




19. On both sides.







#### 17. On both sides.


Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).






- - 1. Torque: <u>28 Nm</u>








**23.** 1. Torque: <u>25 Nm</u> 2. Torque: <u>8 Nm</u>













- 27. A CAUTION: Take extra care not to crease the headliner.
  - 5. Attach a suitable draw cord to the antenna cable.


General Equipment: Draw Cord




28. Torque: <u>25 Nm</u>



29. Torque: <u>25 Nm</u>




- **30.** 1. Remove the tolerance absorber.
  - 2. Special Tool(s): 303-435, 501-153
  - 3. Torque: <u>10 Nm</u>
  - 4. Turn the tolerance absorber to the stop.



**31.** Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).













**34.** Depending on the vehicle variant, steering wheels with a different design for cut marks can be fitted.






On both sides. General Equipment: TORX screwdriver








38.

37. A CAUTION: Make sure that the clockspring rotor does not rotate.


Torque: <u>48 Nm</u>






## **39.** A CAUTION: Make sure that the clockspring rotor does not rotate.

General Equipment: Adhesive Tape










42 Torque: <u>10 Nm</u> E103087

































53.



54. Torque: <u>8 Nm</u>







#### Installation

1. To install, reverse the removal procedure.

## Instrument Panel — Vehicles With: Automatic Temperature Control

#### Special Tool(s)



303-435 Mounting Stand

Special Tool(s)



#### **General Equipment**

Adhesive Tape

Draw Cord

Hose Clamp(s)


TORX screwdriver

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

## 1. A CAUTION: Make sure that the steering wheel lock is engaged.

**NOTE:** Make sure that the road wheels are in the straight ahead position.





2. NOTE: This step is only necessary on vehicles with air conditioning.

Refer to: Air Conditioning (A/C) System Recovery, Evacuation and Charging (412-00


Climate Control System - General Information, General Procedures).

- 3. Refer to: Cowl Panel Grille (501-02 Front End Body Panels, Removal and Installation).
- 4. On both sides.






- 6. A CAUTION: Make sure that the motor is in the park position.
  - 1. Torque: <u>10 Nm</u>
  - 2. Torque: <u>8 Nm</u>




7. Torque: 25 Nm



8. A CAUTION: Make sure that all openings are sealed.

**NOTE:** Vehicles without air conditioning.


1. General Equipment: Hose Clamp(s)



9. A CAUTION: Make sure that all openings are sealed.

**NOTE:** Vehicles with air conditioning.

- 1. Torque: <u>8 Nm</u>
- 2. General Equipment: Hose Clamp(s)




**10.** Remove the driver side front door.

11. Remove the driver seat.


Refer to: Front Seat (501-10 Seating, Removal and Installation).

- **12 NOTE:** This step is only necessary on vehicles with manual transmission.
- **13. NOTE:** This step is only necessary on vehicles with automatic transmission.






18. On both sides.





19. On both sides.




#### 17. On both sides.


Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).






- - 1. Torque: <u>28 Nm</u>








**23.** 1. Torque: <u>25 Nm</u> 2. Torque: <u>8 Nm</u>













## 27. A CAUTION: Take extra care not to crease the headliner.

5. Attach a suitable draw cord to the antenna cable.

General Equipment: Draw Cord




28. Torque: <u>25 Nm</u>



29. Torque: <u>25 Nm</u>




- **30.** 1. Remove the tolerance absorber.
  - 2. Special Tool(s): 303-435, 501-153
  - 3. Torque: <u>10 Nm</u>
  - 4. Turn the tolerance absorber to the stop.



**31.** Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).













**34.** Depending on the vehicle variant, steering wheels with a different design for cut marks can be fitted.






On both sides. General Equipment: TORX screwdriver








38.

37. A CAUTION: Make sure that the clockspring rotor does not rotate.


Torque: <u>48 Nm</u>






# **39.** A CAUTION: Make sure that the clockspring rotor does not rotate.

General Equipment: Adhesive Tape










42 Torque: <u>10 Nm</u> E103087


















47.













52.



53. Torque: <u>8 Nm</u>







#### Installation

**1.** To install, reverse the removal procedure.

# In-Vehicle Crossbeam

#### **General Equipment**


Adhesive Tape

#### Removal

# **NOTE:** Removal steps in this procedure may contain installation details.

- Refer to: Heater Core Housing (412-01 Climate Control, Removal and Installation).
   Refer to: Heater Core and Evaporator Core
  - Housing Vehicles With: Manual Temperature Control (412-01 Climate Control, Removal and Installation).
  - Refer to: Heater Core and Evaporator Core Housing - Vehicles With: Automatic Temperature Control (412-01 Climate Control, Removal and Installation).
- 2. Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).






#### **General Equipment**

TORX screwdriver






5. Depending on the vehicle variant, steering wheels with a different design for cut marks can be fitted.






## On both sides. General Equipment: TORX screwdriver








9.

8. CAUTION: Make sure that the clockspring rotor does not rotate.


Torque: <u>48 Nm</u>






# 10. A CAUTION: Make sure that the clockspring rotor does not rotate.


General Equipment: Adhesive Tape







12

**13.** Torque: <u>10 Nm</u> E103087












**21.** Torque: <u>8 Nm</u>



Vehicles with manual temperature control


22.






Vehicles with electronic automatic temperature control (EATC)


24.







#### All vehicles


**26**.














30.




31.



**32** 1. Torque: <u>8 Nm</u> 2. Torque: <u>10 Nm</u>



33. WARNING: Make sure that new nuts are installed. Torque: <u>22 Nm</u>



#### 34. Torque: <u>8 Nm</u>



#### Installation

**1.** To install, reverse the removal procedure.

PAGE

# SECTION 501-14 Handles, Locks, Latches and Entry Systems

#### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

# DESCRIPTION AND OPERATION

Handles, Locks, Latches and Entry Systems (Component Location)	501-14-2
Handles, Locks, Latches and Entry Systems (Overview)	501-14-4
General	501-14-4
Handles, Locks, Latches and Entry Systems (System Operation and Component	
Description)	501-14-5
Control Diagram	501-14-5
System Operation	501-14-6
Unlocking the vehicle	501-14-6
Locking the vehicle	501-14-6
Emergency unlocking/locking	501-14-7
Start the engine	501-14-8
Start the engine	501-14-9
Switching off the engine	501-14-9
Component Description	501-14-9
Start/stop button	501-14-9
Steering Column Lock Control Unit	501-14-10
Emergency starting function	501-14-11
Service Instructions	501-14-11
Vehicles with Keyless Vehicle System	501-14-11
Vehicles without Keyless Vehicle System	501-14-11
DIAGNOSIS AND TESTING	
Locks, Latches and Entry Systems	501-14-12
Principles of Operation (Vehicles with Remote Keyless Entry (RKE)	501-14-12

#### REMOVAL AND INSTALLATION


Ignition Lock Cylinder	501-14-13
Front Door Latch	501-14-14
Rear Door Latch	501-14-15
Exterior Front Door Handle	501-14-16
Exterior Rear Door Handle	501-14-18
Front Door Lock Cylinder	501-14-19

Inspection and Verification (Vehicles with Remote Keyless Entry (RKE)..... 501-14-12

#### DISASSEMBLY AND ASSEMBLY

Door Lock Cylinder	501-14-20
Ignition Lock Cylinder	501-14-25

Handles, Locks, Latches and Entry Systems – Component Location



ltem	Description	
1	Start/stop button	
2	Electronic steering lock unit	
3	RF remote receiver	
4	keyless vehicle module	
5	Tailgate release switch	
6	Luggage compartment antenna	

ltem	Description	
7	Interior antenna <b>Comments:</b> 3 units (one behind the instrument panel, one in the middle of the vehicle under the center console, one on the luggage compartment floor)	
8	Outside door handle with antenna and lock/unlock button	
9	BPP (brake pedal position) switch	
10	Instrument cluster	

# Handles, Locks, Latches and Entry Systems – Overview

A keyless vehicle system is available as an option or dependent on the vehicle equipment level.

#### General

The keyless vehicle system allows the vehicle to be operated without conventional keys or without active actuation of the radio remote control. With this system, the user only needs to carry a valid radio remote control (a **passive key**).

The system features the following modifications in addition to the usual components:

- keyless system vehicle module,
- Passive key (pure radio remote control without conventional key blade),
- additional lock/unlock buttons in the front door handles,
- External and internal antennae to localize a valid passive key:
  - external antennae in both door handles and at the luggage compartment as well as three interior antennae,
- electronic steering lock unit (replaces the mechanical steering lock),
- Start/stop button for starting/switching off the engine; the conventional ignition lock is dispensed with.

In order to **gain access to the vehicle**, a passive vehicle key must be located in the vicinity of the vehicle.

A passive key is identified via low-frequency (LF) polling. When a valid vehicle key is identified, the vehicle can be unlocked directly via the appropriate lock/unlock button on the front door handles or via the tailgate release switch.

A passive vehicle key must be present in the vehicle interior in order to **start the engine**. A passive key is identified via low-frequency (LF) polling.


When a valid key is recognized, the **ignition can be switched on** via the **Start/Stop button** in the instrument panel or the engine started directly.


After switching on the ignition or for **directly starting** the engine

- the clutch pedal must be pressed on vehicles with manual transaxles.
- the brake pedal must be pressed on vehicles with automatic transaxles.

Handles, Locks, Latches and Entry Systems – System Operation and Component Description

# Control Diagram





RF remote receiver

3

Electronic steering lock unit

6


Item	Description		
7	Passive vehicle key		
8	Door locking units		
9	External antennae - door handle Comments: 2 units, integrated into the front door handles		
10	External antennae - tailgate		

# **System Operation**

With the keyless vehicle system, there is a choice between individual door unlocking and global unlocking. The programming process is the same as on vehicles without a keyless vehicle system.

## Unlocking the vehicle

Exterior antennas: approximate detection range (in mm)



Three exterior antennas are installed on the vehicle:

- one in the driver door handle,
- one in the passenger door handle,
- one under the luggage compartment/tailgate (behind the bumper).

When a door handle lock/unlock button or the tailgate release switch is operated, the corresponding external antenna emits a low frequency signal.

The passive vehicle key is thereupon activated and emits an encoded radio signal.

Item	Description	
A	Radio signal <b>Comments:</b> from one of the external antennae to passive vehicle keys	
В	Radio signal Comments: from passive vehicle key to radio frequency receiver	

The encoded radio signal from the passive key is received by the radio frequency receiver.

The radio frequency receiver transfers the signal to the keyless vehicle module.

If the keyless vehicle module recognizes a valid key signal, the actuated door or liftgate is unlocked. The **Unlocking** is performed by the GEM. For this the GEM receives an appropriate signal via the MS-CAN (controller area network) from the keyless vehicle module.

The electronic steering column lock unit is unlocked as soon as the driver's door is opened (signal from the door contact switch).

If more than 45 seconds elapse after the vehicle is unlocked but without the ignition being switched on, then the electronic steering column lock unit is re-locked.

The electronic steering column lock unit re-locks if a time of 45 seconds has elapsed after the ignition is switched off.

If the vehicle goes over 5 days without being unlocked, the system enters energy saving mode. This mode prevents excessive loading of the vehicle battery. In this mode, the response time of the keyless vehicle system during unlocking is slightly longer. The energy saving mode is deactivated again if the vehicle is unlocked once after more than 5 days.

## Locking the vehicle

There are two options for central locking of the vehicle:

- · actuating the door lock button once,
- actuating the relevant button on the radio remote control of the passive key once.

In order to activate **double locking**, the door lock button or the button on the remote control must be pressed twice within 3 seconds.

When the central or the double locking system has been activated, the vehicle remains locked for 3 seconds. During this time the vehicle **cannot** be opened using the door handle lock/unlock button, tailgate release switch or the remote control.

This allows the driver to check whether the vehicle is locked. This delay time can be changed or switched off via IDS (Integrated Diagnostic System).

The **global locking function** can only be activated via the remote control. To do this, the lock button and the unlock button of the remote control must be pressed for about 4 seconds.

Lock/unlock button - driver's door handle:

• Depending on what is set, this button either unlocks the driver's door or the whole vehicle.

Lock/unlock button - passenger's door handle:

• Regardless of what is set, the whole vehicle will be unlocked when this button is pressed.

Note, when locking the vehicle with another key, if a key remains in the vehicle:

- In this case the key which remains in the vehicle will be deactivated after about one minute. Background: If an unauthorized person enters the vehicle, the engine cannot be started because the deactivated passive key does not send a radio signal.
- The passive key remaining in the vehicle will be re-activated by pressing one of the buttons on the remote control once.

#### **Emergency unlocking/locking**




If the keyless vehicle system is unable to detect the passive key, the vehicle can be unlocked using the **emergency key**. The emergency key is integrated in the passive key.

For detailed instructions on assembly of the emergency key, please refer to the Owner's Handbook.

Only the driver door features a conventional door lock for the purpose of emergency unlocking.

# Start the engine




ltem	Description	
1	Start/stop button	
2	BPP	
3	RF remote receiver	
4	Instrument cluster	
5	keyless vehicle module	

ltem	Description	
6	Electronic steering lock unit <b>Comments:</b> with transceiver for emergency start	
7	Passive vehicle key	
8	PCM (powertrain control module)	
9	ABS (anti-lock brake system)/ESP module	

ltem	Description       Interior antenna       Comments:       in total 3 units	
10		

#### Start the engine

#### Interior antennas: approximate detection ranges



**NOTE:** In order for engine starting to be enabled it is necessary for a valid passive key to be present inside the vehicle.

Three interior antennas are installed in the vehicle:

- · one behind the instrument panel,
- one under the floor console,
- one behind the rear seat bench.

Three states can be switched to via the start/stop button:

- Switch on the ignition
- directly start the engine,
- switch off the engine.

The following options are available:

- Ignition ON:
  - actuate the start/stop button.
- Starting the engine from ignition ON or directly from ignition OFF:
  - Vehicles with manual transmission: Depress the clutch pedal and press the Start/Stop button.
  - Vehicles with automatic transmission: Depress the brake pedal and press the Start/Stop button.

Item	Description	
A	Radio signal Comments: from one of the external antennae to passive vehicle keys	
В	Radio signal Comments: from passive vehicle key to radio frequency receiver	

When the start/stop button is pressed, the interior antennas of the keyless vehicle module are activated.

The passive vehicle key is thereupon activated and emits a coded radio signal.

The coded radio signal from the passive key is received by the radio frequency receiver.

The radio frequency receiver transfers the signal to the keyless vehicle module.

If the keyfree module recognizes a **valid code**, a **coding enquiry** is made to the PCM.

The coding enquiry is made over the HS-CAN. Only when the PCM approves the coding enquiry is the start enable issued.

#### Switching off the engine

The engine is switched off by actuating the start/stop button, provided the vehicle is stationary (vehicle speed = 0 km/h).

The engine can be stopped in an **emergency** as follows:

- Press the Start/Stop button three times within two seconds or
- press the Start/Stop button and hold it pressed for three seconds.

# **Component Description**

#### Start/stop button

For safety reasons the Start/Stop button is designed with two switch functions. It therefore sends the actuation signal to the keyless vehicle module over two separate cables.


When a valid key is recognized, the engine is switched on or off or started via the Start/Stop

button, depending on the previous status. Please

refer to the table for the individual sequences.

Status prior to performance of the action	Action	Status after performance of the action
ignition OFF	Clutch or brake pedal and start/ stop button actuated	Ignition ON, engine starts
ignition OFF	Only start/stop button actuated	Ignition ON
Ignition ON	Clutch or brake pedal and start/ stop button actuated	Engine starts
Ignition ON	Only start/stop button actuated	ignition OFF
Engine running and vehicle stationary	Start/stop button actuated	ignition OFF
Engine running and vehicle speed > 0 km/h	Long or repeated actuation of the start/stop button	ignition OFF

#### **Steering Column Lock Control Unit**



Item	Description
1	Steering Column Lock Control Unit
2	PATS (passive anti-theft system) transceiver <b>Comments:</b> only relevant for the emergency start function

The steering lock unit is attached to the steering column.

The steering lock unit comprises:

- a DC motor with a locking pin,
- integrated control electronics.

Actuation is via the keyless vehicle module.

The steering lock unit communicates with the keyless vehicle module via a private data bus (K-wire).

The steering lock unit is unlocked:

- by opening the driver's door:
  - Signal from the door contact switch to the GEM, then from the GEM via the MS-CAN to the keyless system module.
- when the ignition is switched on (if the Start/Stop button is not pressed within 45 seconds of the driver's door being unlocked),
- when the clutch or brake pedal is depressed.

When the vehicle is unlocked or the ignition is switched on, the steering column lock unit is supplied with battery voltage from the keyless vehicle module. The unlocking routine then commences:

- The keyless vehicle module checks the status of the steering lock unit. In addition, the identification code is queried (i.e. whether a correctly programmed steering lock unit is connected).
- Following successful completion of the check/identification, the DC motor is actuated by the control electronics and the steering lock is released.

The steering column lock will be locked when the vehicle is locked or after 45 seconds, if the following conditions are met:

- Engine OFF,
- Ignition OFF,
- vehicle speed 0 km/h.
- Depending on the software version, the steering wheel lock can only be locked if there is no passive key in the vehicle.

#### **Emergency starting function**

If the keyless vehicle system is unable to recognise the passive key, the vehicle can be started via the emergency starting function.

To do this, a conventional transceiver is installed on the steering column lock unit.

To start the engine, the passive key must be held near the steering column lock unit (see current Owner's Manual). Then press the Start/Stop button with the clutch or brake pedal depressed.

#### **Service Instructions**

#### Vehicles with Keyless Vehicle System

A total of up to **eight passive vehicle keys** can be programmed.

**All** available passive vehicle keys must be reprogrammed using IDS if one or more passive keys are to be added.

After the **keyless vehicle module has been changed**, all the available passive vehicle keys must be reprogrammed using IDS.

In addition, the keyless vehicle module must be initialized with the following modules using IDS:

- PCM,
- · steering lock unit.

After a new steering lock unit is installed, initialization must be performed with the keyless vehicle module using IDS.

After a **new PCM has been installed** IDS must be used to initialize it with the keyless vehicle module.

#### Vehicles without Keyless Vehicle System

#### Up to eight remote controls can be programmed.

**All** available remote controls must be reprogrammed if one or more remote controls are to be added.

The **remote controls can be programmed** either using IDS or by running through the following steps:

- 1. Disable the alarm system (if installed) and unlock the vehicle.
- 2. Turn the ignition on and off four times within 6 seconds.

- 3. Turn off the ignition and leave the ignition key in the ignition lock. A signal tone sounds to confirm that programming mode is active.
- Press any button on the remote control within 10 seconds. A signal tone sounds to confirm that the remote control has been programmed.
- 5. Repeat step 4 with all other existing remote controls.

Programming mode is deactivated if:

- No buttons on a remote control are pressed within 10 seconds after the signal tone,
- The position of the ignition lock is changed,
- The maximum number of 8 remote controls has been programmed.

The **unlocking function** of the central locking works in two ways:

- Pressing the unlock button on the remote control unlocks all doors.
- Pressing the unlock button on the remote control unlocks only the driver's door. Pressing the unlock button again within 3 seconds unlocks all doors.

To **reprogram the unlocking function**, run through the following steps:

- 1. Switching the ignition OFF.
- Simultaneously hold down the unlocking and locking buttons on the remote control for at least 4 seconds.
- 3. Reprogramming is confirmed by the turn signals flashing twice.

Repeat these steps to revert to the previous functioning.

#### DIAGNOSIS AND TESTING

# Locks, Latches and Entry Systems

#### **General Equipment**

Ford diagnostic equipment

#### Principles of Operation (Vehicles with Remote Keyless Entry (RKE)

#### **RKE** locking system overview

This system consists of mechanical/electrical operated door latches driven by outputs from the generic electronic module (GEM). The system uses a radio frequency transmitter and receiver to operate the remote lock/unlock functions and normal key or inner door handle inputs for standard central and double locking functions.

When the normal key or inner door handle is operated, switching contacts within the door latch supply a command signal to the GEM. Dependant upon the current state of the locking system, the GEM allows battery voltage to be applied to the door latch motors.

The liftgate or luggage compartment lid is opened when the vehicle is in the unlocked mode by a ground signal from the liftgate or compartment lid release switch to the GEM. The GEM will supply a voltage to the liftgate or compartment lid latch motor.

If the vehicle is locked, the input from the liftgate or compartment lid release switch will be ignored.

The RKE functions are operated by sending a radio frequency signal from the key transmitter and the signal is received by the GEM. For vehicles equipped with the keyless system the radio frequency signal is transferred to the keyless vehicle module and a signal is transmitted to the corresponding lock sent via controller area network (CAN) to the GEM module.

#### **Keyless Vehicle System Overview**

The keyless vehicle system also incorporates RKE functions, however the main purpose of the system is to allow the operator of the vehicle to gain access to and operate the vehicle without carrying out any actions with a key or remote buttons.

Vehicles equipped with keyless vehicle systems, will be delivered from production in shipping mode. Shipping mode reduces the vehicle battery drain to a minimum to extend the period of time the vehicle can remain dormant without discharging the vehicle battery.

# Inspection and Verification (Vehicles with Remote Keyless Entry (RKE)

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical or electrical damage.

#### Visual Inspection Chart


Mechanical	Electrical
<ul> <li>Misaligned door(s), tailgate, luggage compartment and hood</li> <li>Door latch(es)</li> <li>Liftgate latch</li> <li>Luggage compartment lid latch</li> <li>Hood latch</li> <li>Actuating Cable(s)</li> <li>Exterior door handle(s)</li> <li>Door latch remote control(s)</li> <li>Door lock cylinder</li> </ul>	<ul> <li>Fuse(s)</li> <li>Relay(s)</li> <li>Wiring harness</li> <li>Electrical connector(s)</li> <li>Door latch(s)</li> <li>Remote transmitter batteries</li> <li>Vehicle battery</li> <li>Remote transmitter</li> <li>Radio frequency receiver</li> <li>Liftgate exterior release switch</li> <li>Luggage compart- ment lid release switch</li> <li>Door control module(s)</li> <li>GEM</li> </ul>

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 4. If the cause is not visually evident, verify the symptom and refer to the diagnostic tab within the Ford diagnostic equipment.


# Ignition Lock Cylinder

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.



2.




3.




Left-hand drive vehicles

4.



Right-hand drive vehicles



#### Installation

**1.** To install, reverse the removal procedure.

Front Door Latch

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

**1.** Refer to: Front Door Window Regulator (501-11 Glass, Frames and Mechanisms, Removal and Installation).


Refer to: Exterior Front Door Handle (501-14 Handles, Locks, Latches and Entry Systems, Removal and Installation).

Refer to: Front Door Lock Cylinder (501-14 Handles, Locks, Latches and Entry Systems, Removal and Installation).

2. 2. Torque: <u>8 Nm</u>



#### Installation



Rear Door Latch


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

**1.** Refer to: Rear Door Window Regulator (501-11 Glass, Frames and Mechanisms, Removal and Installation).

Refer to: Exterior Rear Door Handle (501-14 Handles, Locks, Latches and Entry Systems, Removal and Installation).

2. 2. Torque: <u>8 Nm</u>





#### Installation

# **Exterior Front Door Handle**

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.






Vehicles with keyless entry

**3.** Refer to: Front Door Window Regulator (501-11 Glass, Frames and Mechanisms, Removal and Installation).





Vehicles without keyless entry




#### Installation

# Exterior Rear Door Handle

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.





#### Installation


**1.** To install, reverse the removal procedure.




# Front Door Lock Cylinder

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.



#### 2.



#### Installation

**General Equipment** 

4 mm Punch Electric Drill

# **DISASSEMBLY AND ASSEMBLY**

# Door Lock Cylinder


#### **General Equipment**

2 mm Punch	
4 mm Drill Bit	


#### Disassembly

# 1. E117695








3. General Equipment: Electric Drill General Equipment: 4 mm Drill Bit




4. General Equipment: 2 mm Punch








7. A CAUTION: Note the position of the components before removal.




#### Assembly


**NOTE:** Make sure that new components are installed.

8. A CAUTION: Make sure that the components are installed to the position noted before removal.







**11. NOTE:** The component can only be installed in 1 position.




#### 12 General Equipment: 4 mm Punch




13.







# Ignition Lock Cylinder

#### Disassembly










# 7. A CAUTION: Note the position of the components before removal.


**NOTE:** One group of tumblers is signed with a one digit number (1 to 5), the other group of tumblers is signed with a two digit number (11 to 15).




**NOTE:** Disassemble the new ignition lock cylinder.













#### Assembly

# 12 A CAUTION: Make sure that the components are installed to the position noted before removal.


**NOTE:** One group of tumblers is signed with a one digit number (1 to 5), the other group of tumblers is signed with a two digit number (11 to 15).









14.







# **SECTION 501-16 Wipers and Washers**

#### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

PAGE


#### **DESCRIPTION AND OPERATION**

Wipers and Washers (Component Location)	501-16-2
Wipers and Washers (Overview)	501-16-3
WINDSHIELD WIPERS	501-16-3
Front Wipers	501-16-3
Automatic wiper system	501-16-3
Rear wiper	501-16-3
Combined rain sensor/light sensor	501-16-3
Windshield washers	501-16-4
Wipers and Washers (System Operation and Component Description)	501-16-5
Control Diagram	501-16-5
System Operation	501-16-6
Front wiper / washer system	501-16-6
Intermittent wipe	501-16-6
Auto	501-16-6
Front washer system	501-16-6
Rear windshield wash/wipe system	501-16-7
Component Description	501-16-7
Switch, wash/wipe system	501-16-7
Rain Sensor	501-16-7
Front windshield wiper motor	501-16-8
Rear wiper motor	501-16-8

#### **DIAGNOSIS AND TESTING**

Wipers and Washers Inspection and Verification	501-16-10 501-16-10
GENERAL PROCEDURES	
Windshield Wiper Blade and Pivot Arm Adjustment	501-16-11
REMOVAL AND INSTALLATION	
Windshield Wiper Motor	501-16-13
Rear Window Wiper Motor	501-16-16
Windshield Washer Pump	501-16-17
windshield washer Fullip	001-10-17

# Wipers and Washers – Component Location



E107049

Item	Description
1	Windshield wiper arms and linkage
2	Combined rain sensor/light sensor
3	Switch, wash/wipe system
4	Rear window washer nozzle
5	rear window wiper arm
6	Rear wiper motor

ltem	Description
7	Front windshield wiper motor
8	Washer reservoir
9	Washer pump
10	Cap, washer reservoir
11	BCM (bodywork control module)
12	Front washer jets

**Rear wiper** 


#### **DESCRIPTION AND OPERATION**

# Wipers and Washers - Overview

The window wipers and the window washer system are controlled by the BCM (Body Control Module).

# WINDSHIELD WIPERS

#### Front Wipers




ltem	Description
1	Wiper arms
2	Wiper linkage assembly
3	Front windshield wiper motor

The front wiper blades are flat blades. These offer the following advantages over conventional wiper blades:

- · reduced noise when operating
- improved wiping because of the reduced tendency to lift up at high vehicle speeds
- lower installed height

#### Automatic wiper system

Some models without a combined rain sensor/light sensor are equipped with a speed-dependent wiper interval for the front wipers. If the vehicle is decelerated to walking speed or a standstill, then the system automatically changes to the next slower interval setting. If the speed is increased, the wiper speed returns to the manually selected setting. If the wiper lever is moved while the system is switched on the system is switched off. If the vehicle is decelerated to walking speed or a standstill again, then the system is switched back on again.



Item	Description
1	Rear wiper motor
2	Wiper pivot arms
3	Rear window washer nozzle

When reverse gear is engaged the rear wiper is automatically switched on if

- the rear wiper is switched off and
- · the front wipers are switched on or
- automatic wipe mode is selected (optional in certain markets) and the rain sensor (optional in certain markets) has switched on the front wipers.

The rear wiper delay interval is regulated according to the speed of the front wipers.


#### Combined rain sensor/light sensor

The combined rain sensor/light sensor is optional in certain markets.



The rain sensor is built into a housing which is mounted behind the rear view mirror on the windshield. The rain sensor evaluates optical conditions. Contamination such as oil, grease or dust will prevent correct operation. Before switching on the automatic windshield wipers, the windshield must be clean in the area of the rain sensor.

#### Windshield washers




Item	Description
1	Front washer jets
2	Washer reservoir closure

Water is pumped to both the front window washer and the rear window washer from a washer reservoir via a washer pump.

Item	Description
3	Washer reservoir
4	Washer pump
5	Rear window washer nozzle

# Wipers and Washers – System Operation and Component Description

# **Control Diagram**



Item	Description
1	TCM (transmission control module) (Vehicles with automatic transmission)
2	Instrument cluster
3	BCM (Body Control Module) input

ltem	Description
4	Rear wiper motor
5	Front windshield wiper motor
6	Washer pump
7	BCM

ltem	Description
8	Switch, wash/wipe system

# **System Operation**

The window wash/wipe system is controlled by the BCM (Body Control Module). To do this, the BCM primarily uses the signal from the window wash/wipe switch. Secondary signals include the signal from the combined rain sensor/light sensor (optional in certain markets) and the signal of the reversing lamp switch (vehicles with manual transmission) or the TCM (vehicles with automatic transmission).

#### Front wiper / washer system

The front window wash/wipe system will only operate if the ignition switch is in position **II**.

The front and rear windshield wash/wipe systems use a shared window washer pump and cannot be used simultaneously.

Four wipe functions are available:

- single wipe
- intermittent wipe or automatic wipe (depending on the vehicle specification)
- normal wipe
- · fast wipe speed

The setting of the window wash/wipe switch is transmitted to the BCM (Body Control Module). The BCM then actuates the wiper motor via relays and sets the wiper speed.

Normal wipe speed remains available in the event of failure of the BCM.

#### Intermittent wipe

The setting of the window wiper rotary switch is transmitted to the BCM (Body Control Module). The BCM then actuates the wiper motor via a relay and sets the wiper delay interval.

The window wiper rotary switch has six settings ranging from a short delay to a long delay:

- Wiper delay in level 1 = 1.2 seconds
- Wiper delay in level 2 = 4 seconds
- Wiper delay in level 3 = 8 seconds

ltem	Description
9	Reversing lamp switch (vehicles with manual transmission)
10	Combined rain sensor/light sensor

- Wiper delay in level 4 = 12 seconds
- Wiper delay in level 5 = 17.5 seconds
- Wiper delay in level 6 = 25 seconds

These values apply to a stationary vehicle. The intervals are shortened with increasing vehicle speed.

#### Auto

The automatic wipe function is optionally available in some markets.

The signal from the combined rain sensor/light sensor is transmitted via a LIN (local interconnect network) bus to the BCM (Body Control Module), where it is processed together with the signal from the window wiper rotary switch which is used to adjust the sensitivity of the sensor. The BCM then actuates the wiper motor and sets the wiper speed and wiper delay interval.

#### Front washer system

When the front washer system is switched on the BCM (Body Control Module) switches on the window washer pump. The BCM delays wiper operation for 360 ms after operation of the window washer switch. If the window washer switch is not operated for at least 360 ms, then the BCM does not switch on the window wiper. The BCM activates the window wiper for as long as the window washer switch is operated. The window washer pump is switched off after a maximum of 10 seconds. After clearance from the switch the BCM allows the wipers to wipe two or three times more.

This additional wiping function allows the front wiper blades to wipe one more time 4 seconds after the last wiping movement to remove any remaining water from the windshield.

The additional wiping function is activated if:

- the windshield wipers are off when the front windshield washer system is operated
- the windshield wipers are set to intermittent mode and have not wiped in the last 4 seconds

#### Rear windshield wash/wipe system

The rear window wash/wipe system will only operate if the ignition switch is in position **II**.

The front and rear windshield wash/wipe systems use a shared window washer pump and cannot be used simultaneously.

Depending on the wiper speed of the front wipers, the rear wipers run with a delay interval of 6 seconds, 10 seconds or continuously. The time delay is controlled by the BCM (Body Control Module).


The rear windshield wiper is switched on if:

- the window wash/wipe switch is in the 'rear wiper' position
  - The BCM actuates the rear wiper motor. The windshield wiper runs in intermittent mode.
- the rear windshield washer system is operated
  - The BCM switches on the rear window washer system. The washer pump is supplied with power. Reversing the polarity of the pump enables the washing fluid to flow to the rear washer jets instead of the front washer jets. The BCM activates the window wiper for as long as the window washer switch is operated. The window washer pump is switched off after a maximum of 10 seconds. After clearance from the switch the BCM allows the wipers to wipe two or three times more.
- the signal "Reverse gear engaged" is received from the reversing lamp switch or from the TCM and the front window wash/wipe switch is in the position for normal or fast wipe speed, or it is set to automatic wipe (optional in certain markets) or intermittent wipe at high speed.
  - The BCM actuates the rear wiper motor until the gear lever is moved to neutral.

# **Component Description**

#### Switch, wash/wipe system

The window wash/wipe switch is a simple electrical switch which is inserted into the steering wheel module.



ltem	Description
1	Switch, wash/wipe system
2	Window wiper rotary switch
3	Windshield washer switch


Switches and switch positions:

- Switch, wash/wipe system
  - One-touch function downwards for single front wipe
  - 3 fixed positions upwards for front intermittent wipe / automatic wipe (optional in some markets), normal wipe, fast wipe
  - Fixed position towards the steering wheel for rear intermittent wipe
  - One-touch function beyond the fixed position towards the steering wheel for the rear washer system
- · Window wiper rotary switch
  - 6 fixed switch positions for wiper intervals/rain sensor sensitivity (optional in some markets). The switch positions start from 1 (wide symbol) at the upper end point and end with 6 (narrow symbol) at the lower end point
- Windshield washer switch
  - One-touch function for front washer system

#### **Rain Sensor**

The rain sensor is optionally available in some markets.

The sensor contains a number of transmitter and receiver diodes which emit and receive infrared light. By comparing the received signal with the known transmitted signal, the rain sensor can determine the moisture on the outside of the windshield and request that the windshield wipers are switched on.



ltem	Description
1	Raindrop
2	LED <b>Comments:</b> (transmitter diode)
3	Lens
4	Photodiode Comments: (receiver diode)
5	Light loss due to deflection

The LED emits a beam of light with a known intensity. The emitted beam emerges through the lens and is then reflected by the windshield.

The reflected light beam enters back through the lens and then reaches the photodiode. The corresponding value taken without moisture on the windshield is used as the reference value for automatic calibration.

Subsequent deviations from this value cause the windshield wipers to be switched on.

If precipitation falls on the windshield, part of the light beam is deflected. This reduces the intensity of the light reflected by the windshield. This loss of intensity is registered by the photodiode and reported via an LIN signal to the BCM (Body Control Module).

When the automatic wipe function is switched on (window wash/wipe lever set to intermittent wiping) the wipers are only activated automatically if the rain sensor registers water on the windshield.

The sensitivity of the rain sensor can be changed by adjusting the window wiper rotary switch.

- Window wiper rotary switch at the top corner: high sensitivity
  - The wipers wipe even if only a small amount of water has been measured on the windshield.
- Window wiper rotary switch at the bottom corner: low sensitivity
  - The wipers only wipe if a large amount of water has been measured on the windshield.

The rain sensor is self-calibrating.

The rain sensor supplies LIN signals with values between 0 and 7 to the BCM (Body Control Module).

Meaning of signals from rain sensor:

- Signal "0": window is dry.
- Signal "1-5": Windshield is damp. The BCM activates normal wiping.
- Signal "6-7": Windshield is receiving severe precipitation. The BCM activates the fast wipe speed whenever the signal value is greater than 4.

#### Front windshield wiper motor

The front windshield wiper motor is a DC motor with 3 brush type contacts. One brush type contact is for ground and one is for normal wiping speed. The third brush type contact is activated for high wiping speed.

The integrated home switch is directly connected to the BCM (Body Control Module). The home switch contacts are open in all wiper motor positions except the home position. When the home switch contacts are open, the wiper motor remains switched on even if a signal from the steering wheel module requests that the wipers stop. In home position, the home switch contacts create a ground connection. The BCM recognizes this ground connection and switches the wiper motor off.

#### **Rear wiper motor**

The rear windshield wiper motor is a DC motor with 2 brush type contacts. It is controlled by a voltage supply.

The integrated home switch is directly connected to the BCM (Body Control Module). The home switch contacts are closed in all wiper motor positions except the home position. When the

home switch contacts are closed, the wiper motor is supplied with a voltage by the BCM. When the wiper motor reaches the home position, the home switch contacts are opened and the power supply is interrupted by the BCM. While the window wash/wipe switch remains in the "rear washer" position, the wiper motor is again supplied with a voltage by the BCM and continues to run. This process is repeated during every revolution of the wiper motor.

#### **DIAGNOSIS AND TESTING**

# Wipers and Washers

# Refer to Wiring Diagrams Section 501-16, for schematic and connector information.

#### **General Equipment**

Ford diagnostic equipment

#### **Inspection and Verification**

**NOTE:** Before retrieving the vehicle-specific data make sure that all electrical connections in the vehicle are reconnected so that the module and the Ford diagnostic equipment can communicate correctly.

**NOTE:** If a new generic electronic module (GEM) is being installed, the new module must be configured following installation. For this purpose, the vehicle-specific data is retrieved from the module to be changed using the Ford diagnostic equipment and is transferred to the new module.

- 1. Verify the customer concern.
- 2. Visually check for any obvious mechanical or electrical damage.

#### Visual Inspection Chart

	Mechanical		Electrical
•	Wiper blade(s) Rotating shaft – wiper arm Washer reservoir Hose(s) Nozzles Check the	• • • •	Electrical Fuse(s) Connectors Wiring harness Washer pump Front/rear window wiper motor
•	passenger-side windshield wiper for residue-free wiping in the vicinity of the rain sensor. Check the adhesive pad between the rain sensor and the windshield for trapped air.		
•	Clean wax residues from the windshield in the vicinity of the rain sensor.		
•	Check the wind- shield for damage/cracks in the vicinity of the rain sensor. Check that the rain		
	sensor retaining frame is correctly attached to the windshield.		

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 4. If the cause is not visually evident, verify the symptom and refer to the Ford diagnostic equipment to diagnose the system.

#### GENERAL PROCEDURES


# Windshield Wiper Blade and Pivot Arm Adjustment

#### Special Tool(s)

	501-027 Aligner, Wiper Arm
ES32006	501-027-01 Adapter for 501-027
E73710	

#### Adjustment

1. A CAUTION: Make sure that the motor is in the park position.




2. NOTE: The angle of the wiper on the scale must point from the zero center line to the center of the windshield/rear window. Ignore the plus/minus (+/-) signs on the adjusting tool.

**NOTE:** Make sure that the 3 marked points of the special tool are in contact with the glass.


Using the special tool, read off the angle between the wiper arm and the glass.


Special Tool(s): 501-027, 501-027-01



3. A CAUTION: Make sure that the special tool is lifted off the glass when adjusting the angle.


Adjust the wiper arm to an angle of 5°±2°.





# **GENERAL PROCEDURES**






# Windshield Wiper Motor


#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.


**1.** Refer to: Cowl Panel Grille (501-02 Front End Body Panels, Removal and Installation).








- 4. A CAUTION: Make sure that the motor is in the park position.
  - 1. Torque: <u>10 Nm</u>
  - 2. Torque: <u>8 Nm</u>



**5.** 1. **NOTE:** Note the position of the component before removal.

Torque: <u>18 Nm</u>



#### Installation

# Rear Window Wiper Motor

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

# 1. A CAUTION: Make sure that the motor is in the park position.

Torque: 9 Nm



- **2.** Refer to: Liftgate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 3. Torque: <u>8 Nm</u>



#### Installation


# Windshield Washer Pump

#### Removal

**1.** Refer to: Jacking and Lifting (100-02 Jacking and Lifting, Description and Operation).



3. **WARNING:** Be prepared to collect escaping fluid.



#### Installation


3.


# **REMOVAL AND INSTALLATION**

# Windshield Washer Reservoir

#### Removal


**1.** Refer to: Jacking and Lifting (100-02 Jacking and Lifting, Description and Operation).





4. A CAUTION: Make sure the open end of the hose is secured above the fluid level

in the reservoir.



#### Installation



# **SECTION 501-19 Bumpers**

#### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **REMOVAL AND INSTALLATION**

Front Bumper Cover	501-19-2
Rear Bumper Cover	501-19-8
Rear Bumper Cover — 4-Door	501-19-13

# Front Bumper Cover

### **General Equipment**

Cable Ties

## Removal


**NOTE:** Removal steps in this procedure may contain installation details.

## **General Equipment**

Interior Trim Remover


- **1.** Refer to: Jacking and Lifting (100-02 Jacking and Lifting, Description and Operation).
- 2. On both sides.






Vehicles with parking aid

4. General Equipment: Cable Ties




5. General Equipment: Cable Ties




All vehicles


6. On both sides.




- **7.** If equipped, on both sides.
- E108559
- 8. If equipped, on both sides.




9. General Equipment: Interior Trim Remover









Vehicles with parking aid

12

## Installation

# **Rear Bumper Cover**

#### **General Equipment**

5 mm Drill Bit


## Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Jacking and Lifting (100-02 Jacking and Lifting, Description and Operation).
- 2. Both sides, If equipped.



3. On both sides.




### **General Equipment**


Electric Drill


### Vehicles with parking aid

4.



All vehicles








#### 3-door

8. If equipped.

General Equipment: Electric Drill General Equipment: 5 mm Drill Bit



## Vehicles with parking aid

**9.** Refer to: Rear Parking Aid Sensor (413-13 Parking Aid, Removal and Installation).

## Installation

# Rear Bumper Cover — 4-Door

## Removal


**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Jacking and Lifting (100-02 Jacking and Lifting, Description and Operation).
- 2.






4. Both sides, If equipped.




5. On both sides.




Vehicles with parking aid

## All vehicles

7.







10. If equipped.



## Vehicles with parking aid

**11.** Refer to: Rear Parking Aid Sensor (413-13 Parking Aid, Removal and Installation).

## Installation

# SECTION 501-20A Safety Belt System

## **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **DESCRIPTION AND OPERATION**

Safety Belt System (Overview)	501-20A-2
Overview	501-20A-2

#### **DIAGNOSIS AND TESTING**


Safety Belt System	501-20A-3
Principles of Operation	501-20A-3
Inspection and Verification	501-20A-3
Component Test	501-20A-4

#### **REMOVAL AND INSTALLATION**

Front Safety Belt Retractor and Pretensioner	501-20A-6
Front Safety Belt Buckle	501-20A-7
Rear Safety Belt Retractor	501-20A-8
	501-20A-10
	501-20A-11
Rear Center Safety Belt Buckle	501-20A-12

# Safety Belt System – Overview

# Overview



ltem	Description
1	Retractor - front seat belt and belt tensioner
	Refer to: Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (501-20 Supplemental Restraint System, Description and Operation).

# Safety Belt System

#### **General Equipment**

Ford diagnostic equipment

## **Principles of Operation**

WARNING: All safety belt components including retractors, buckles, front safety belt buckle support assemblies (slider bar), child safety seat tether brackets and attaching hardware in use during a collision must be removed and new components installed. New safety belt components should also be installed where safety belts not in use during a collision, are inspected and found to be damaged or operate incorrectly. Failure to follow these instructions may result in personal injury.

Vehicles equipped with the supplemental restraint system (SRS) are equipped with a driver and passenger safety belt retractor(s) and pretensioner. The safety belt pretensioners are controlled as part of the SRS.

#### REFER to: Air Bag and Safety Belt Pretensioner

Supplemental Restraint System (SRS) (501-20 Supplemental Restraint System, Description and Operation).

The rear seat safety belt buckles are mounted directly to the floor pan underneath the rear seat cushion. When the ignition is turned on the RUN position the SRS warning indicator will illuminate for three seconds. If the SRS, including the safety belt electrical system, is operating correctly the SRS warning indicator will be extinguished. If a fault is detected the SRS warning indicator will generate a lamp fault code.

#### REFER to: Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (501-20 Supplemental Restraint System, Description and Operation).

The safety belt retractor, mounted within the base of the B-pillar, incorporates a torsion bar load limiting device. The device consists of a retractor reel which is mounted onto a spindle (torsion bar) which, once the sensor has locked the retractor reel and predetermined load is applied, twists and pays out additional webbing into the system. The deceleration force required to initiate this sequence is approximately the same as that required to initiate air bag deployment. The torsion bar load limiting device will only react if the safety belt is in use at the time of impact. Rear seat safety belt retractors do not use this type of retractor, they are equipped with a conventional retractor.

#### **Emergency Locking Retractor**

The retractors in all seat positions feature emergency locking retractor(s). The emergency locking retractor is part of the safety belt system that in normal operation allows free movement of the belted occupant. In an emergency the emergency locking retractor will lock, preventing webbing payout and hence forward movement of the occupant. Locking may be achieved by one of two mechanisms:

#### Vehicle Motion Sensor

vehicle motion sensor is operated by sudden deceleration of the vehicle or excessive tilt. Once operated the vehicle motion sensor causes a locking pawl to be engaged, thus locking the retractor, preventing webbing payout. When the vehicle is stationary, the vehicle motion sensor stabilizes, causing the pawl to disengage and unlock the retractor, allowing webbing payout.

#### Webbing Motion Sensor

The emergency locking retractor webbing motion sensor is operated by rapid acceleration of the webbing. Once operated, it causes a locking pawl to be engaged thus locking the retractor. Webbing payout is prevented in the same manner as vehicle motion sensor.

## **Inspection and Verification**

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical and electrical damage.

#### **Visual Inspection Chart**

	P	
	Mechanical	
•	Safety belt retractor	
•	<ul> <li>Safety belt buckle</li> </ul>	
•	<ul> <li>Safety belt retractor and pretensioner</li> </ul>	

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next stop.
- 4. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart.

#### Symptom Chart

Symptom	Possible Sources Action	
Normal mode - occupant     restraint system inoperative.	Safety belt retractor.	CARRY OUT the Safety Belt     Component Test in this section.

## **Component Test**

#### **Poor Retraction**

If a safety belt does not retract correctly, check that the anchor covers and trim bezels are correctly installed and not rubbing against the safety belt webbing. Where necessary, check that the safety belt webbing is not rubbing at one end of the retractor cover slot and, if so, correct by loosening the retaining bolt, aligning the retractor to centralize the safety belt webbing and retighten the bolt.

The safety belts are "dual sensitive" which means that they have:

- A vehicle motion sensor, which locks the safety belt webbing under braking, cornering, on steep hills and in adverse camber conditions.
- A webbing motion sensor, which locks when the safety belt webbing is quickly extracted.

Both systems should be fully operational and can be checked by the tests below:

#### **Vehicle Motion Sensor Test**

Either of the following two procedures may be used to check correct operation of the vehicle motion sensor. Both methods require two technicians but note that technicians of larger than normal build should not be asked to conduct these tests. This is to avoid the possibility of a fully unrolled safety belt webbing being mistaken for a correctly locked safety belt retractor.

#### Test Method 1 (braking)

WARNING: It is important that during this test, the driver and passenger allow the safety belts to provide the restraint and do not attempt to anticipate the sudden deceleration. The steering wheel should not be used as a brace. However, both driver and passenger should prepare themselves for the possibility that the safety belt will not lock. The passenger should hold their hands in front of them, just clear of the instrument panel or front seat backrest, depending on which safety

# belt is being tested. Failure to follow these instructions may result in personal injury.

- Select for this test a quiet or private stretch of road. Make sure that the road is clear and that full visibility is maintained at all times.
- Both driver and passenger should adopt a normal, comfortable seating position. Both occupants should wear the safety belts and the safety belt webbing must be correctly adjusted, with no slack.
- Proceed at a speed of 10 km/h (6 mph). Do not exceed 10 km/h (6 mph) for this test.
- Apply the foot brake sharply to stop the vehicle. If the vehicle motion sensitive lock mechanism is operating correctly, the safety belt webbing will lock and restrain the wearer.
- Conduct the test twice in each front and rear passenger seat position.
- Any safety belt retractor which does not restrain the wearer during this test must not be reused. A new safety belt must be installed.

## Test Method 2 (turning circle)

This method requires a flat open area of private road, sufficient for the vehicle to be driven in a continuous circle on full steering lock.

- The driver should wear the safety belt provided and the belt webbing must be correctly adjusted, with no slack.
- The passenger should occupy a rear seat with the safety belt correctly adjusted, with no slack.
- Start the engine and, with the steering on full right-hand lock, drive the vehicle in a continuous circle at 16 km/h (10mph). Do not exceed 16 km/h (10 mph) for this test.
- When the speed is stable, the passenger should attempt to slowly extract the safety belt webbing from each safety belt retractor in turn. If the vehicle motion sensitive lock mechanism is operating correctly, it will not be possible to extract the webbing.
- Any safety belt retractor from which it is possible to extract the webbing during this test must not be used. A new safety belt must be installed.

#### Static Test

With the vehicle stationary and on level ground take firm hold of the safety belt webbing (on the tongue side of the upper safety belt anchor) and pull out quickly. The retractor should lock within 0.25 meter (10 inches), preventing further webbing payout. Any safety belt retractor from which it is possible to extract further webbing must not be used. A new safety belt must be installed.

1. If the cause is not visually evident, verify the symptom and refer to theFord diagnostic equipmentto diagnose the system.

# Front Safety Belt Retractor and Pretensioner

### Removal

#### WARNINGS:

The supplemental restraint system (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.


Make sure that the vehicle electrical system is fully depowered and no other power source is connected.

**NOTE:** Removal steps in this procedure may contain installation details.


**1.** Refer to: Health and Safety Precautions (100-00 General Information, Description and Operation).

Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

- Refer to: B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 2. Torque: <u>45 Nm</u>



**3.** Torque: <u>45 Nm</u>



## Installation


# Front Safety Belt Buckle

### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

**1.** Refer to: Front Seat (501-10 Seating, Removal and Installation).

2.



3. Torque: 50 Nm



## Installation


# Rear Safety Belt Retractor

## Removal


# **NOTE:** Removal steps in this procedure may contain installation details.

**1.** Refer to: Health and Safety Precautions (100-00 General Information, Description and Operation).


#### 5-door



3.




#### All vehicles



5. Torque: <u>45 Nm</u>



6. Torque: <u>45 Nm</u>



## Installation

# Rear Safety Belt Buckle

## Removal

1. Refer to: Rear Center Safety Belt (501-20 Safety Belt System, Removal and Installation).

#### Installation

# Rear Center Safety Belt

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

**1.** Refer to: Health and Safety Precautions (100-00 General Information, Description and Operation).

2.



3. Torque: 45 Nm



## Installation

# Rear Center Safety Belt Buckle

#### Removal


**NOTE:** Removal steps in this procedure may contain installation details.

**1.** Refer to: Health and Safety Precautions (100-00 General Information, Description and Operation).

2.



3. Torque: 45 Nm



## Installation

# **SECTION 501-20B Supplemental Restraint System**

## **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

PAGE

#### **DESCRIPTION AND OPERATION**

Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (Component Location)	501-20B-2
Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (Overview).	501-20B-3
Overview.	501-20B-3
Driver airbag module, passenger airbag module	501-20B-4
Retractor - front seat belt and belt tensioner	501-20B-4
Restraints control module (RCM)	501-20B-4
Front crash sensor Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (System	501-20B-4
Operation and Component Description)	501-20B-5
Control Diagram	501-20B-5
System Operation	501-20B-5
General	501-20B-5
Component Description	501-20B-6
Front crash sensor	501-20B-6
Driver and passenger front air bag system	501-20B-6
Retractor - front seat belt and belt tensioner	501-20B-6

#### **DIAGNOSIS AND TESTING**

Inspection and Verification	501-20B-8 501-20B-8 501-20B-9 01-20B-10
Principles of Operation	


#### **GENERAL PROCEDURES**

Clockspring Adjustment	501-20B-12
	501-20B-13
	501-20B-14
Scrapped Vehicle Air Bag and Safety Belt Pretensioner Disposal - In-Vehicle Disposal	501-20B-15
All air bag modules	. 501-20B-18

#### **REMOVAL AND INSTALLATION**

Restraints Control Module (RCM)	501-20B-19
Front Impact Severity Sensor	501-20B-20
Driver Air Bag Module	501-20B-21
Passenger Air Bag Module	501-20B-24
Side Air Bag Module	501-20B-25
Side Air Curtain Module	501-20B-27
Clockspring	501-20B-29

Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) – Component Location




ltem	Description
1	Front crash sensor
2	Driver air bag
3	Retractor - front seat belt and seat belt tensioner

Item	Description
4	Front safety belt buckle
5	Restraints control module (RCM)
6	Front passenger airbag

Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) – Overview


## Overview




ltem	Description	
1	Front crash sensor	
2	Driver air bag	
3	Retractor - front seat belt and belt tensioner	

Item	Description	
4	Front safety belt buckle	
5	Restraints control module (RCM)	
6	Front passenger airbag	

Driver airbag module, passenger airbag module



# Retractor - front seat belt and belt tensioner




The pyrotechnic belt tensioners on the driver's side and front passenger's side are integrated into the retractor mechanism.

The following instructions must be followed when removing, installing or replacing the safety belt tensioner:

 Note the position and routing of the safety belt buckle pretensioner wiring harnesses to aid installation. An incorrectly routed wiring harness may lead to the wiring harness becoming damaged on the seat mechanism.

## **Restraints control module (RCM)**




The RCM is located underneath the floor console near the gearshift lever.

The following instructions must be followed when removing, installing or replacing the RCM:

- After an accident, the RCM can only be used again if it is not physically damaged and if it passes a self-test without any faults. For further information refer to TECHNICAL SERVICE BULLETIN 35/2006.
- A new RCM must be programmed using the diagnostic unit.

## Front crash sensor



The impact sensor is installed at the front of the vehicle next to the hood lock.

The following instructions must be followed when removing, installing or replacing the front crash sensor:


- Continued use of the impact sensor is permissible provided it has not been physically damaged and it passes a self-test.
- Make sure that the front crash sensor is installed in the correct position.

2

Ignition unit

Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) – System Operation and Component Description

# **Control Diagram**



Item	Description
1	Front crash sensor
2	Restraints control module (RCM)
3	Driver air bag

# **System Operation**

## General

The RCM performs a self-diagnosis when the ignition is switched on.

All components of the restraints control system are checked. If an error is found, the airbag control lamp is activated for 8 seconds after the ignition is switched on. The first 8 seconds of the ignition cycle always follow the same pattern: first 3.2 seconds on, then 4.8 seconds off. Only after 8


ltem	Description
4	Front passenger airbag
5	Retractor - front seat belt and belt tensioner

seconds can the airbag control lamp be used as a fault indicator.

After an airbag has been deployed, a new RCM must be installed. If the RCM is changed, the module must be configured with IDS.

# **Component Description**


## Front crash sensor



Data from the crash sensor are evaluated by the RCM to assess the severity of a frontal impact. The crash sensor transmits digitally encoded acceleration information to the RCM.


The RCM will store a trouble code (DTC) if one of the crash sensors fails.

## Driver and passenger front air bag system.



The driver and passenger air bags are single-stage air bags.

### Retractor - front seat belt and belt tensioner



The belt tensioner is built into the belt retractor and installed on the driver and passenger sides. On the outside of the seat belt retractor there is a metal tube, at the upper end of which is located a pyrotechnic ignition unit. It is connected with the metal tube via a joining connector.

# Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS)

Refer to Wiring Diagrams Section 501-20B, for schematic and connector information.

#### Special Tool(s)

418142	Test and Deployment Lead, Side Air Bag Module 418-555
501073	Simulator, Driver and Passenger Air Bags, Driver Lower Air Bag, Side Air Curtains and Driver and Passenger Safety Belt Retractor Pretensioners 501-073A
	Simulator, Side Air Bags 501-401
E102676	
General Equinmen	4

#### **General Equipment**

Ford diagnostic equipment

Driver air bag module wiring harness

## **Inspection and Verification**

- 1. Verify the customer concern.
- 2. Visually inspect for obvious signs of mechanical or electrical damage.

#### **Visual Inspection Chart**

	Electrical
•	Fuse(s)
•	Loose or corroded electrical connector(s)
•	Circuit(s)
•	Safety belt buckle switch(es)
•	Passenger seat occupant sensor
•	Safety belt retractor pretensioner(s)
•	Driver frontal air bag
•	Passenger frontal air bag
•	Driver lower air bag (if equipped)
•	Driver and passenger side air bags (if equipped)
•	Driver and passenger side air curtains (if equipped)

4. If the cause is not visually evident, verify the symptom and refer to the diagnostic tab within the Ford diagnostic equipment.

before proceeding to the next step.

## Air Bag Warning Indicator

The air bag warning indicator is incorporated into the instrument cluster, together with the automatic detach detect circuit. The air bag warning indicator illuminates for 3.2 seconds at key ON and goes OFF for 4.8 seconds. If the system self-tests OK the indicator will stay OFF, but if there is a fault condition, the air bag warning indicator will come ON again and stay illuminated.

The system is designed to illuminate the air bag warning indicator continuously if the RCM circuit is broken, either by loss of power, ground supply, module disconnect or CAN BUS failure.

Diagnostic evaluation of the SRS should be made through the DLC using the Ford diagnostic equipment to establish the nature of the concern.

#### Diagnosing Customer Concerns Without Hard DTCs

WARNING: To avoid accidental deployment, the restraints control module (RCM) backup power supply must be depleted. Wait at least one minute after disconnecting the battery ground cable(s) before commencing any repair or adjustment to the supplemental restraint system (SRS), or any component(s) adjacent to the SRS sensors. Failure to follow these instructions may result in personal injury.

**NOTE:** Following the pinpoint tests when a diagnostic trouble code (DTC) is not present, or the air bag warning lamp is not permanently illuminated, will result in needless replacement of air bag system components and repeat repairs.

Speak with the customer to determine if a particular set of conditions must be met in order for a fault to occur. If an illuminated air bag warning lamp is reported by the customer but is not present when the vehicle comes in for repair, pinpoint test diagnostics cannot be used.

# Diagnosing Customer Concerns with Hard DTCs

WARNING: Do not use substitute air bag simulators when working on the SRS. Use only the appropriate tool. Failure to follow these instructions may result in personal injury.

Most air bag system diagnostic procedures require the use of system deactivation and system reactivation procedures. These procedures require the air bag module(s) and safety belt retractor pretensioners to be disconnected from the SRS, thereby removing the risk of air bag deployment while diagnostics are carried out.

Air bag simulators are required to carry out diagnosis and testing of the air bag system. The simulator contains a resistor, used to simulate an air bag module connection to the system. It is not acceptable to short-circuit the air bag module connections with a 0 ohm jumper wire. If a 0 ohm jumper wire is used to short-circuit the air bag module connections, an illuminated air bag warning lamp will be displayed and a DTC logged by the RCM.

### Deactivation

- WARNING: To avoid accidental deployment, the RCM backup power supply must be depleted. Wait at least one minute after disconnecting the battery ground cable(s) before commencing any repair or adjustment to the SRS, or any component(s) adjacent to the SRS sensors. Failure to follow these instructions may result in personal injury.
- 1. Disconnect the battery ground cable.

REFER to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

- Wait at least one minute for the backup power supply in the RCM to deplete its stored energy.
- WARNING: To minimize the possibility of premature deployment, live air bag modules must only be placed on work benches which have been ground bonded and with the trim cover facing up. Failure to follow these instructions may result in personal injury.
- Remove the driver air bag module from the vehicle.
  - REFER to: Driver Air Bag Module (501-20 Supplemental Restraint System, Removal and Installation).
- **NOTE:** REFER to FordEcat for a compatible driver air bag module wiring harness to use as a test lead.

Connect a test driver air bag module wiring harness to the clockspring.

- Connect the simulator (501-073A) to the driver air bag module wiring harness in place of the driver air bag module at the top of the steering column.
- Remove the driver lower air bag module from the vehicle.
- Connect the simulator (501-073A) to the wiring harness in place of the driver lower air bag module.
- Disconnect the passenger air bag module electrical connector.

REFER to: Passenger Air Bag Module (501-20 Supplemental Restraint System, Removal and Installation).

## **DIAGNOSIS AND TESTING**

- Connect the simulator (501-073A) to the wiring harness in place of the passenger air bag module.
- Disconnect the side air curtain module electrical connectors on both sides.
  - REFER to: Side Air Curtain Module (501-20 Supplemental Restraint System, Removal and Installation).
- Connect the simulators (501-073A) to the wiring harnesses in place of the side air curtain modules.
- Disconnect the side air bag module electrical connectors on both sides.
  - REFER to: Side Air Bag Module (501-20 Supplemental Restraint System, Removal and Installation).
- Connect the simulators (501-401) to the wiring harnesses in place of the side air bag modules.
- Detach the driver side B-pillar trim panel to gain access to driver side safety belt retractor pretensioner electrical connector. REFER to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Disconnect the driver side safety belt retractor pretensioner electrical connector.
- Connect the simulator (501-073A) to the wiring harness in place of the driver side safety belt retractor pretensioner.
- Detach the passenger side B-pillar trim panel to gain access to passenger side safety belt retractor pretensioner electrical connector. REFER to:
  - B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Disconnect the passenger side safety belt retractor pretensioner electrical connector.
- Connect the simulator (501-073A) to the wiring harness in place of the passenger side safety belt retractor pretensioner.
- Connect the battery ground cable.
  - REFER to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

#### Reactivation

- WARNING: The air bag simulators must be removed and the air bag modules reconnected when reactivated to avoid non-deployment in a collision. Failure to follow this instruction may result in personal injury.
- 1. Disconnect the battery ground cable.
  - REFER to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).
- Wait at least one minute for the backup power supply in the RCM to deplete its stored energy.
- **NOTE:** If a new driver air bag module wiring harness has been used for testing, the wiring harness should be retained for future test use only.

Remove the simulator (501-073A) from the driver air bag module wiring harness at the top of the steering column.

- Remove the driver air bag module wiring harness from the clockspring.
- Connect and install the driver air bag module.
  - REFER to: Driver Air Bag Module (501-20 Supplemental Restraint System, Removal and Installation).
- Remove the simulator (501-073A) from the sub-harness at the driver lower air bag module.
- Connect and install the driver lower air bag module.
- Remove the simulator (501-073A) from the passenger air bag module wiring harness.
- Connect and install the passenger air bag module.
  - REFER to: Passenger Air Bag Module (501-20 Supplemental Restraint System, Removal and Installation).
- Remove the simulators (501-073A) from the side air curtain module wiring harnesses.
- Connect and install the side air curtain modules.
  - REFER to: Side Air Curtain Module (501-20 Supplemental Restraint System, Removal and Installation).
- Remove the simulators (501-41) from the side air bag module wiring harnesses.

## **DIAGNOSIS AND TESTING**

- Connect and install the side air bag modules.
  - REFER to: Side Air Bag Module (501-20 Supplemental Restraint System, Removal and Installation).
- Remove the simulator (501-073A) from the driver side safety belt retractor pretensioner wiring harness.
- Connect the driver side safety belt retractor pretensioner electrical connector.
- Attach the driver side B-pillar trim panel. REFER to:
  - B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Remove the simulator (501-073A) from the passenger side safety belt retractor pretensioner.
- Connect the passenger side safety belt retractor pretensioner electrical connector.
- Attach the passenger side B-pillar trim panel. REFER to:
  - B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Connect the battery ground cable.

REFER to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

• Prove out the system.

#### Glossary

#### Air Bag Simulator

Air bag simulators are used to simulate air bag module connections to the system.

#### **Deactivate the System**

Deactivate the system means to carry out the deactivation procedure. REFER to Deactivation in this procedure.

#### **Prove Out the System**

The air bag warning indicator will illuminate for three seconds. If there is a fault condition, the air bag warning indicator will stay illuminated or illuminate after a five second delay.

#### **Reactivate the System**

Reactivate the system means to carry out the reactivation procedure. REFER to Reactivation in this procedure.

### **Principles of Operation**

#### **SRS** Operation

The vehicle is equipped with a DC fired sensing system.

In the event of a severe frontal or three-quarter frontal impact, in excess of a predetermined limit, the driver and passenger front air bags and safety belt retractor pretensioners and driver knee air bag (if equipped) will deploy.

In the event of a severe full side impact, in excess of a predetermined limit, either the driver or passenger side air bag, side air curtain (if equipped) will deploy.

Air bag deployment will only occur, in the event of a severe collision, when the ignition key is in the RUN position. The passenger air bag deactivation (PAD) switch (if equipped) will deactivate the passenger frontal air bag in the event of a severe frontal impact; it will not deactivate any other deployable device.

#### RCM

The RCM retains full control of the whole system, providing continual system checks and full diagnostic capabilities. The non-volatile memory stores the diagnostic trouble codes, which can then be downloaded through the data link connector (DLC) to the Ford diagnostic equipment.

In the event of a failure in the vehicle supply during an accident, the RCM provides a backup power supply, sufficient to deploy the air bag(s) for a minimum of 150 ms. The backup power supply is discharged by the RCM within 60 seconds of the battery ground cable being disconnected.

The RCM contains electronic acceleration sensors which measure the longitudinal acceleration and the lateral acceleration and provide both signals to the micro-controller proportional to the amount of acceleration measured. The RCM also contains a safing sensor, which prevents unintentional deployment of the front air bags and safety belt retractor pretensioners and knee air bag (if equipped) in the event of a fault within the

#### **DIAGNOSIS AND TESTING**

electronic acceleration sensor(s). The RCM compares the values it receives from the crash sensor, side impact sensors, safing sensor and the internal electronic sensors. If the deceleration due to a frontal or side impact exceeds a stored threshold value then the RCM triggers the air bags and safety belt pretensioners as required.

#### **Front Crash Sensor**

The front crash sensor contains an acceleration sensor, filter, amplifier and an application specific integrated circuit for signal transmitting and is mounted on the radiator grille opening panel reinforcement. The crash sensor sends a signal at a level determined by the crash severity to the RCM. The RCM will evaluate the signal against stored data and deploy the frontal air bags and safety belt retractor pretensioners and knee air bag (if equipped) when required. Both the crash sensor and the internal RCM longitudinal acceleration sensor must exceed a preset limit to initiate the air bag.

#### Side Impact Sensor


The side impact sensors are mounted at the base of the B-pillar on either side of the vehicle, to facilitate remote lateral impact sensing. Each side impact sensor contains an acceleration sensor, filter, amplifier and an application specific integrated circuit for signal transmitting. In the event of an impact, in excess of a predetermined limit, the side impact sensor sends a signal at a level determined by the crash severity to the RCM. The RCM will evaluate the signal against stored data and deploy the side air bag on the side the deployment request was initiated. Both the side impact sensor and the internal RCM lateral acceleration sensor must exceed a preset limit to initiate the air bag. The RCM retains control of the side air bags, side air curtains.

# Clockspring Adjustment

#### **General Equipment**

Adhesive Tape


#### WARNINGS:



If the centralization of the clockspring is in doubt, the centralizing of the clockspring must be repeated.


**NOTE:** Make sure that the road wheels are in the straight ahead position.

- **1.** 1. Turn the clockspring in a clockwise direction until a resistance is felt.
  - 2. Turn the clockspring in a counterclockwise direction 2.5 revolutions, until the arrow marked on the rotor of the clockspring aligns with the raised 'V' section on the outer cover of the clockspring.



2. A CAUTION: Make sure that the clockspring rotor does not rotate.

General Equipment: Adhesive Tape



## opiementai Nestraini

## **GENERAL PROCEDURES**

# Deployed Air Bag Disposal

- WARNING: After deployment, the air bag module surface may contain deposits of sodium hydroxide, a product of the gas generate combustion, that is irritating to the skin. Use protective gloves when handling any deployed air bag module. Failure to follow this instruction may result in personal injury.
- 1. Remove the deployed air bag module(s). For additional information, refer to the relevant procedure in this section.
- 2. Seal the deployed air bag module(s) in the packaging from the new air bag module(s) or a suitable polythene bag, and then dispose of in accordance with local contaminated waste regulations.

# 501-20B-14

## **GENERAL PROCEDURES**

# Unserviceable Air Bag Disposal

#### 1. WARNINGS:

To minimize the possibility of injury in the event of premature deployment, always carry a live air bag module with the bag and trim cover pointed away from the body. Failure to follow this instruction may result in personal injury.

To prevent premature deployment, live air bag modules must only be placed on work benches which have been ground bonded. Failure to follow this instruction may result in personal injury.

**NOTE:** All unserviceable air bag modules have been placed on the Mandatory Return List. All discolored or damaged air bag modules should be treated the same as any unserviceable live air bag module being returned.

Remove the unserviceable air bag module. For additional information, refer to the relevant procedure in this section.

<sup>2.</sup> AWARNING: Under no circumstances is an unserviceable air bag module(s) to be returned through the local mailing system. Failure to follow this instruction may result in personal injury.

Seal the unserviceable air bag module(s) in the packaging from the new air bag module(s) and address to the appropriate manufacturer. The package should then be forwarded to the Exchange Plan Center (as appointed through the national sales company) who will arrange forwarding to the manufacturer.

3. NOTE: Autoliv air bag modules and seat belt pretensioners.

Autoliv Gmbh, Theodor Heuss Strasse 2, 85221, Dachau, Germany.

4. NOTE: TRW air bag modules.

**TRW Occupant Restraint Systems, FAO Rene** Getto, Industriestr 20, 73551, Aldorf, Germany.

5. NOTE: TRW seat belt pretensioners.

**TRW Occupant Restraint Systems, FAO** Helmut Goss, Industriestr 20, 73551, Aldorf, Germany.

6. NOTE: Takata Petri air bag modules.

Takata Petri AG, Grossostheimer Strasse 223, D-63741 Aschaffenburg, (Supplier Code P790M) Germany.

# Scrapped Vehicle Air Bag and Safety Belt Pretensioner Disposal - In-Vehicle Disposal

#### Special Tool(s)

во сторование 40007А	Test and Deployment Lead, Air Bag/Pyrotechnic Safety Belt 418-S055C (40-007D)
418143	Adapter Box (AC) 418-143 (40-007-10)

#### General Equipment

12 volt battery

1. This procedure must only be carried out by authorised scrap vehicle dismantlers.

#### WARNINGS:

- To avoid accidental deployment, the restraints control module (RCM) backup power supply must be depleted. Wait at least one minute after disconnecting the battery ground cable(s) before commencing any repair or adjustment to the supplemental restraint system (SRS), or any component(s) adjacent to the SRS sensors. Failure to follow these instructions may result in personal injury.
- To minimize the possibility of premature deployment, do not use radio key code savers when working on the SRS. Failure to follow this instruction may result in personal injury.
- Before deploying the air bag module or safety belt pretensioner pyrotechnic make sure that all personnel in the vicinity are aware that a loud noise (bang) is about to occur. Do not let anybody approach closer than 6 meters. Failure to follow this instruction may result in personal injury.
  - The air bag module or the safety belt pretensioner should not be handled immediately following deployment as the

air bag module will be very hot. Failure to follow this instruction may result in personal injury.


- After deployment, the inflator(s) becomes inert, direct contact to the skin or eyes of any free pyrotechnic residues should be avoided. Failure to follow this instruction may result in personal injury.
- Always wear gloves and safety glasses when handling deployed air bag modules and safety belt pretensioners, Failure to follow this instruction may result in personal injury.
- If the air bag module or safety belt pretensioner pyrotechnic residue should contact the eyes, wash the eyes with clean water and seek medical assistance. Failure to follow this instruction may result in personal injury.
- If a large amount of air bag or safety belt pretensioner pyrotechnic residue is inhaled, seek medical assistance. Failure to follow this instruction may result in personal injury.
- 2. Disconnect the battery ground cable.

For additional information, refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

3. Remove the floor console.


For additional information, refer to: Floor Console (501-12 Instrument Panel and Console, Removal and Installation).

4. Disconnect the RCM electrical connectors.




5. Connect the special tools as shown.


- 1. 12 volt battery.
- 2. Adapter box (AC).
- 3. Deployment lead (part of Test and Deployment Lead, Air Bag/Pyrotechnic Safety Belt).
- 4. Deployment lead (40-007-15 (part of Test and Deployment Lead, Air Bag/Pyrotechnic Safety Belt)).




6. Release the adapter box AC button.



7. To deploy an air bag or safety belt pretensioner, connect the deployment leads to the RCM electrical connector. • For the pin numbers, refer to the special tool usage table below.



8. Move as far away as possible from the vehicle and depress both switches to deploy the air bag or safety belt pretensioner.



- 9. To deploy the remaining air bags and safety belt pretensioners, refer to the special tool usage table below for the RCM electrical connector pin numbers.
  - Repeat steps six and seven.


#### Special Tool Usage

Description	Electrical connector	Red Deployment Lead	Black Deployment Lead
Driver air bag module	А	Pin 3	Pin 4
Driver lower air bag module	А	Pin 8	Pin 7
Passenger air bag module	A	Pin 9	Pin 10
Side air bag module - driver side	В	Pin 20	Pin 19
Side air bag module - passenger side	В	Pin 7	Pin 8
Safety belt retractor and preten- sioner - driver side	В	Pin 2	Pin 1
Safety belt retractor and preten- sioner - passenger side	В	Pin 3	Pin 4
Side air curtain - passenger side	В	Pin 10	Pin 9
Side air curtain - driver side	В	Pin 17	Pin 18

#### 10. RCM electrical connectors.

## Supplemental Restraint System

#### **GENERAL PROCEDURES**



#### All air bag modules

- 1. Deployed air bag module(s) and safety belt pretensioners should be sealed in suitable bags and then disposed of in accordance with local contaminated waste regulations.
- 2. NOTE: All unserviceable air bag modules have been placed on the Mandatory Return List. All discolored or damaged air bag modules should be treated the same as any unserviceable live air bag module being returned.

If an air bag module or safety belt pretensioner fails to deploy, remove the component.

<sup>3.</sup> WARNING: Under no circumstances is an unserviceable air bag module or safety belt pretensioner to be returned through the local mailing system. Failure to follow this instruction may result in personal injury.

If an air bag module or safety belt pretensioner fails to deploy, seal the unserviceable air bag module or safety belt pretensioner in suitable packaging and return to the Exchange Plan Center, as appointed through the local National Sales Company.

# Restraints Control Module (RCM)

#### **General Equipment**

Ford approved diagnostic tool

#### Removal


#### WARNINGS:

- The supplemental restraint system (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.
- Make sure that the vehicle electrical system is fully depowered and no other power source is connected.


Wear safety goggles.

**NOTE:** Removal steps in this procedure may contain installation details.

- 1. Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).
- **2.** Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).
- **3.** Refer to: Floor Console (501-12 Instrument Panel and Console, Removal and Installation).



#### 5. Torque: <u>10 Nm</u>




#### Installation

- 1. To install, reverse the removal procedure.
- **2.** When a new RCM is installed, configure the RCM using the diagnostic tool.
  - General Equipment: Ford approved diagnostic tool

# Front Impact Severity Sensor

```
Removal
```


#### WARNINGS:



Make sure that the vehicle electrical system is fully depowered and no other power source is connected.

**NOTE:** Removal steps in this procedure may contain installation details.

- 1. Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).
- **2.** Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).
- 3. Torque: <u>9 Nm</u>



#### Installation

1. To install, reverse the removal procedure.

# Driver Air Bag Module


#### WARNINGS:

The supplemental restraint system (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.

Make sure that the vehicle electrical system is fully depowered and no other power source is connected.


**NOTE:** Removal steps in this procedure may contain installation details.

- 1. Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).
- **2.** Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).
- **3.** Depending on the vehicle variant, steering wheels with a different design for cut marks can be fitted.






On both sides.





## Supplemental Restraint System

## **REMOVAL AND INSTALLATION**



## Installation

**1.** To install, reverse the removal procedure.

# Passenger Air Bag Module

#### WARNINGS:


The supplemental restraint system (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.

Make sure that the vehicle electrical system is fully depowered and no other power source is connected.

**NOTE:** Removal steps in this procedure may contain installation details.


- 1. Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).
- **2.** Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

# 4. Torque: <u>6 Nm</u>



## Installation

**1.** To install, reverse the removal procedure.



# Side Air Bag Module

#### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

- **1.** Refer to: Front Seat Backrest Cover (501-10 Seating, Removal and Installation).
- 2.




**3. NOTE:** Note the position of the electrical connectors.


### 501-20B-26

## Supplemental Restraint System

## **REMOVAL AND INSTALLATION**



### 4. Torque: <u>6 Nm</u>



## Installation

**1.** To install, reverse the removal procedure.

## Side Air Curtain Module

#### **General Equipment**

Flat-bladed screwdriver

#### Removal

#### WARNINGS:

- The supplemental restraint system (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.
- Make sure that the vehicle electrical system is fully depowered and no other power source is connected.

Wear safety goggles.

**NOTE:** Removal steps in this procedure may contain installation details.

#### **General Equipment**

Long Nose Pliers

1. Refer to: Supplemental Restraint System (SRS) Health and Safety Precautions (100-00 General Information, Description and Operation).


Refer to: Battery Disconnect and Connect (414-01 Battery, Mounting and Cables, General Procedures).

Refer to: Headliner - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).


Refer to: Headliner - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).


2. 1. If equipped.

General Equipment: Long Nose Pliers



- **3.** General Equipment: Flat-bladed screwdriver
- 4. 3. Torque: <u>10 Nm</u>
  - 4. Torque: <u>10 Nm</u>





## Installation

**1.** To install, reverse the removal procedure.

# Clockspring

### **General Equipment**

Flat-bladed screwdriver


### Removal

1.


**NOTE:** Removal steps in this procedure may contain installation details.

**2.** Refer to: Steering Wheel (211-04 Steering Column, Removal and Installation).

3.



4. General Equipment: Flat-bladed screwdriver



#### Installation

- **1.** To install, reverse the removal procedure.
- **2.** Refer to: Clockspring Adjustment (501-20 Supplemental Restraint System, General Procedures).

# **SECTION 501-25 Body Repairs - General Information**

VEHICLE APPLICATION: 2011 Fiesta	
CONTENTS	PAGE
PAGE 1 OF 2	
SPECIFICATIONS	
Specifications	501-25-3
DESCRIPTION AND OPERATION	
Description and Usage of Body Repair Literature	501-25-4
Symbols	501-25-5
Health and Safety Precautions	501-25-8
General	501-25-8
Personal protection	501-25-8
Protection of the vehicle	501-25-8
Protective equipment	501-25-9
Electronic components	501-25-9
Liquefied gas vehicles	501-25-9
Refrigerated conversion vehicles	501-25-10
Environmental Regulations	501-25-11
Body Construction	501-25-12
General	
Integral body-frame	
Convertible	
Non-monocoque bodywork	
Special points:	
Deformation behavior	
Crash element:	
Diagnosis and Damage Evaluation	501-25-17
Noticeable damage to the bodywork structure	
No noticeable damage to the bodywork structure	
Non-monocoque bodywork	
Body Sheet Metal	501-25-19
Types of steel	
Tools and Equipment for Body Repairs	501-25-21
Alignment systems	501-25-21
Measuring systems	501-25-22
Welding gear	501-25-24
Establish Repair Method	501-25-26
General	501-25-26
Planning	501-25-26
Chronological sequence of repair	501-25-26
Alignment Check	501-25-27
Straightening	501-25-30
General	501-25-30
Special features of non-monocoque bodywork	501-25-30
Complete Panel Replacement/Partial Replacement	501-25-31
Complete replacement	501-25-31
Corrosion Prevention	501-25-33
Panel coatings and corrosion protection	501-25-33

### PAGE 2 OF 2

Corrosion protection measures during repair work	501-25-33
Corrosion protection for the floor pan (example)	501-25-37
Corrosion Damage/Corrosion Repair	501-25-38
Sealer, Underbody Protection Material and Adhesives	501-25-40
Cutting Technique	501-25-41
Spot weld milling tool	501-25-41
Rod sander	501-25-42
Short stroke saw	
Orbital saw	501-25-42
Panel Beating Technique and Smart Repairs	501-25-43
General	501-25-43
Dent removal using special panel beating levers	501-25-43
Dynamic puller with counter bearing	
Hollow leveling (removing dent without a dolly)	
Dent removal using hammer and dolly	501-25-45
Heat-induced material shrinking	501-25-45
Lead loading	501-25-46
Paintless Dent Removal.	501-25-40
Plastic Repairs	501-25-47
	501-25-49
General	501-25-49
Plastic welding	501-25-51
Plastic adhesive bonding	
GRP repairs.	501-25-53
Special Repair Techniques	501-25-55
Cabriolet vehicles	501-25-55
Liquefied gas vehicles	501-25-55
Refrigerated conversion vehicles	501-25-56
Joining Techniques	501-25-57
Welding	501-25-57
Soft soldering	501-25-63
Rivets	
Bonding	
Bonding and welding	
Bonding and riveting	501-25-65
Impact of Insufficient Repair Quality	501-25-66
Water Leaks	501-25-68
General	501-25-68
Test method	501-25-68
Test with UV lamp	501-25-69
Chalk/powder test	501-25-69
Smoke test	501-25-70
Stethoscope test	501-25-70
Ultrasonic detection	501-25-71
Ultrasonic test device	501-25-71
Workflow for tracing water entry	501-25-71
Possible complaints and corrective actions	501-25-72
Wind Noise	501-25-77
General information	501-25-77
Diagnosis	501-25-80
Possible concerns with corrective measures	501-25-82
Noise, Vibration and Harshness	501-25-86

## SPECIFICATIONS

Description	Finis Code	Specification
Underbody protection	5 030 492	-
Anti-corrosion wax	1 219 834	WSK-M7C89-A
Cavity wax	5 030 081	-
Profiled butyl seal	1 128 983	S-M3G4620-A
Weld primer	1 205 996	-
Clinched flange protection	1 136 479	WSK-M4G245-B
Seam sealing compound	1 205 817	WSS-M4G364-A
Body sealing compound	1 143 255	-
Metal adhesive kit	1 203 241	-
Windshield sealant	1 613 838	WSK-M4G329-A
Adhesive spoiler set	1 219 837	-

# Description and Usage of Body Repair Literature

The purpose of this document is to give the vehicle body specialist a general overview of possible repair techniques for body repair on Ford vehicles. Likewise, information about materials and tools to be used is given.

No model-specific information is given. Such information is saved in the respective Ford Etis workshop manual. Supplementary or updated information can be found in the Technical Service Information.

Information on repair techniques, materials or tools, which are not necessary for body repair on Ford vehicles or which are not considered as conventionally in use, are not listed in this document.

#### Layout:

The general section is divided into the following subject areas:

- How to use the document, with information on the symbols used
- Health and safety information on using materials and tools
- Information on bodywork construction and materials used
- · Workshop equipment and use of tools
- Damage Assessment and determining the extent of the repair area
- Explanation of possible repair techniques for body repair
- Possibilities of the repair or remedying leaks, noises

#### Training:

The Ford Service Organization offers basic and more in-depth training on much of the content of this document. You can obtain an overview of the entire training offering from the Ford Service Organisation or on the Internet at www.ford-training.de.

# Symbols

#### Warnings and hazard notices

Warnings and hazard notices are shown in this literature by WARNING, CAUTION and NOTE indicators. These notices are always shown before a job step which can be associated with an immediate personal or material danger.

WARNING: This notice is used when failure to exactly follow the instructions given in this literature or failure to follow them at all may result in a hazard to persons and/or in persons being injured.

CAUTION: This notice is used when failure to exactly follow the instructions or test procedures given in this literature or failure


# to follow them at all may result in damage to the vehicle or to components.

**NOTE:** This notice is used when the operator should be made aware of special or extra information.

#### Symbols used

Symbols are used to graphically represent additional information about the operation, tool or materials. This information will not be shown separately again in the text.

The symbols used in this and other body repair manuals may be used alone as well as in combination in a diagram.




Des cript ion	Description
1	Measuring tape
2	Saw
3	Abrasive cutter
4	hot air blower
5	Temperature specification (170°C in this example)
6	Drill with 6mm diameter
7	Drill through one panel thickness with a 5 mm dia. drill

Des cript ion	Description
8	Drill through two panel thicknesses with a 5 mm dia. drill
9	Drill through one panel thickness
10	Drill through two panel thicknesses
11	Apply substance
12	Soldering iron
13	Metal-Inert Gas (MIG) weld
14	Resistance Spot Weld
15	Welded seam (full or intermittent seam)

#### Color coding

Different colors or shading can be used to depict special areas and components.



- Blue: Main component which will be removed or installed. Only actual movements will be shown in blue in the diagram.
- Magenta: Materials or fixings, e.g. spot welds or adhesives.

In an assembly operation, the colors show the sequence of removal steps.

- Green: First component or the first partial replacement section.
- Blue: Second component or the second partial replacement section.
- Brown: Third component or the third partial replacement section.


#### **Movement arrows**

Necessary work such as clinching flanges or moving lugs etc. will be represented by broken arrows.




#### Magnified and detailed views

If a detail cannot be clearly seen in the illustration because of its size or location, it is shown enlarged in a separate window.



#### Position lines within a diagram

A position line is used to indicate a special position or a component. A spot weld which must be drilled out through two panel thicknesses is indicated here, different to all the others.



# Health and Safety Precautions

## General

Appropriate repair methods and their correct implementation are very important for both vehicle operating safety and personal safety.

# WARNING: There is danger of injury through:

- High voltage when electrical welding.
  - Do not perform welding work in a damp environment or on a wet substrate. Use suitable insulation underneath.
- · Flammable substances in the welding area.
  - Remove flammable substances from the danger area. Remove the fuel tank and, where required, those components which supply fuel.
  - Completely remove the battery before carrying out any welding in that area.
- Welding fumes, which are harmful to health.
  - Always ventilate the workplace well and use an extraction system.
- Welding spatter and UV radiation.
  - Wear protective clothing, gloves and welding mask or welding goggles.
- Pyrotechnic components.
  - Disconnect the battery negative clamp and cover the battery terminal. Remove any airbag components.

All the regulations governing Health and Safety at Work must be complied with during body repairs.

## **Personal protection**

Welding gases and grinding dusts can be harmful to the health. For this reason, make sure that rooms are well ventilated and work using the welding fumes extraction system. Sealants, underbody protection and paint residues must not be burnt down with an unshielded flame, as this will produce gases which are damaging to health. A dedicated extraction system must always be used when welding or brazing.

When working with substances containing solvents, good ventilation must be provided, respiratory protection must be worn and an extraction system must be used. Do not weld in damp areas, if necessary use an insulation mat. Welding and grinding work near the battery presents the danger of explosion. For this reason, it must be removed before the work is started.

Cutting, grinding and alignment work on metal panels can cause a noise level of 85 to 90 dB (A) or even more. For this reason, you must always wear ear defenders.

The various body areas are subject to very high forces during realignment work. Should any component suddenly become detached during this process, there is a very great danger of injury. For this reason, pulling chains and pulling shackles must be secured with arrester cables.

**NOTE:** Work on airbag systems may only be performed by persons who have a relevant certificate of competence.

Some special instructions must be followed when working on airbag systems:

- Always stand to the side of it when removing or installing an airbag.
- Always store an airbag or an airbag/steering wheel with the airbag side pointing upwards and in a safe place.
- Only install the airbag again when the vehicle is fully repaired and the complete electrical systems has been tested.
- Take into account the location of air curtains and shoulder airbags.

## Protection of the vehicle

Protect affected areas from weld spatter and dust during all welding and grinding work on the vehicle. If metallic dust stays on the vehicle for some time, there is the likelihood of film rust formation. Grinding or sanding work produce tiny spots of damage to the paint surface, which may cause corrosion.

For this reason, make sure to:

- Use carbon fibre blankets to protect the vehicle body.
- Use covering film to protect the vehicle body from sanding dust and metal dust.
- Take appropriate measures to protect the interior equipment of the vehicle during any repair work.

In addition, take into account:

- · Remove fuel supply components as necessary.
- Protect working areas which are in danger of catching fire with a fireproof blanket.
- The welding must not cause components of the air conditioning system to become heated.
- Removal of any attached components in the space adjoining the repair area.
- Use covering paper to protect the interior from grinding dust.
- Create a definite barrier between the work area and the interior by using a carbon fibre blanket.

## **Protective equipment**

The following protective equipment must always be used:

- Protective helmet or welding mask.
- Ear defenders and breathing protection.
- Protective gloves and safety boots.
- Welding fume extraction.

## **Electronic components**

Increased use of comfort and safety electronics in modern motor vehicles also requires the greatest attention to be paid during body work. Overvoltages produced during welding and in alignment work during bodyshell rectification may cause electronic systems to be damaged. In particular, the safety instructions for performing welding work on vehicles with airbag systems must be adhered to.

**NOTE:** After disconnecting the power supply and before performing further work, a wait time of up to 15 minutes must be maintained, depending on the vehicle. Work on airbag systems may only be performed by persons who have a relevant certificate of competence.

Pay attention to the following points:

- Disconnect the battery negative clamp and cover the battery terminal.
- Disconnect the electrical connector at the airbag control module.
- If welding is to be performed directly near a control module, it must be removed beforehand.
- Never connect the negative cable of the welder near an airbag or a control module.
- Connect the negative cable of the welder close to the location of the weld.

For additional information, refer to:

- Side Air Curtain Module (501-20 Supplemental Restraint System, Removal and Installation), Side Air Bag Module (501-20 Supplemental
- Restraint System, Removal and Installation), Driver Air Bag Module (501-20 Supplemental
- Restraint System, Removal and Installation), Passenger Air Bag Module (501-20
- Supplemental Restraint System, Removal and Installation),
- Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (501-20 Supplemental Restraint System, Diagnosis and Testing).

## Liquefied gas vehicles

Alternative fuel vehicles often require special handling in the workshop area. Above all, assembly operations to some extent require particular knowledge when dealing with the special technology and the safety regulations.

**NOTE:** Only fully trained personnel are permitted to work on alternative fuel vehicles.

These special requirements must be understood and taken into account in the body shop as well.

CAUTION: Danger of fire and explosion. The safety instructions must always be followed when performing service work on fuel/gas systems. Failure to observe this instruction can lead to injury.

If the smell of liquefied petroleum gas (LPG) or compressed natural gas (CNG) is noticed in the workshop, instruct everyone present as follows:

- · No smoking and extinguish all naked flames.
- Shut off all electrical and air powered equipment.
- Evacuate the area.
- Ventilate the area.
- Contact the fire control authorities.
- Move the vehicle to a dedicated, well ventilated area.

Alternative fuels require special handling:

- Handle them in a specially dedicated, well ventilated area, which is only accessible to authorized persons.
- Identify the designated area with new warning notices.
- If possible close the main shut-off valve and run the vehicle on alternative fuel until it switches

automatically to petrol operation. Only then is it allowed to drive the vehicle into the workshop or service area.

- If possible do not allow any liquefied gas (LPG) to escape.
- The ambient temperatures must not exceed 40°C. For this reason the LPG and CNG fuel tanks must be removed on vehicles with LPG or CNG operation before using a drying oven to dry the paint where the temperature exceeds 40°C.

Avoid situations in which fuel from an LPG or CNG fuel tank can escape. These situations include:

- Extremely hot ambient temperatures.
- · Parking near a heating device.
- Raising the vehicle near a ceiling heater.

#### **Refrigerated conversion vehicles**

Apart from the special materials used in building the structure of the refrigerated compartment, such vehicles have special energy and refrigeration systems which require special handling during repair.

#### CAUTIONS:

- Danger of injury. Work on the 230<SP>volt system of the refrigeration equipment must only be carried out by trained specialist personnel.
- The refrigeration system is filled with refrigerant R134a. This can cause frostbite if it contacts the skin. Pay attention to the corresponding warning notices and instructions in the chapter Air Conditioning Systems.

**NOTE:** Work on the refrigerant circuit may only be performed by persons who have a relevant certificate of competence.

Vehicles with a refrigerated compartment are often used to transport foodstuffs. For this reason, additional hygiene regulations must be complied with during repair work.

Aluminum and plastic are used to construct the two different types of compartment found on refrigerated vehicles.

The aluminum conversion is a very stable and technically perfect variant. However, against this the relatively high production costs and a lower payload must be taken into account, because of the weight of the aluminum conversion itself. **NOTE:** Basic and in-depth training is offered on the following topics. You will find an overview of the complete range listed in the Training brochure published by the Ford Service Organization.

The plastic conversion has developed into a light, clean and economical alternative because of constant further development of materials and working techniques.

**NOTE:** The material combinations, the workmanship and the working methods must comply with the current food hygiene regulations. For this reason, service and repair work on the refrigerated conversion may only be performed by authorized and specially trained technicians.

Refrigerated compartment constructions are often made using both materials. The floor pan is made of structured, slip-proof aluminum panels and the wall and ceiling cladding is made of smooth surfaced plastic elements.

CAUTION: PUR hard foam is flammable. If PUR hard foam is overheated, it will burn on its own with a brilliant yellowish flame. It produces unpleasant choking and toxic fumes. Special measures must be taken when welding the vehicle body.

Polyurethane wall and ceiling elements are manufactured using a sandwich principle. An insulating polyurethane core is coated with food grade ABS plastic on one side.

PUR hard foam does not decompose, is rot resistant and is odorless. These properties make it suitable for use as insulation.

Because of its closed cell structure, water uptake by PUR hard foam is for the most part only a problem at edges. Cut edges or other mechanically worked surfaces must however be sealed with the greatest care.

The conversion to a refrigerated vehicle is performed as made-to-order production. The large surfaces of the wall and ceiling cladding can be changed and are particularly easy to repair.

If access to the back of a body panel section is needed because of body straightening work, in some circumstances it is cheaper to perform a cut-out repair instead of removing an element.

The repair process is fully described in the Student Information booklet Refrigeration System Technology, Transit 2000.5 Freshline.

# **Environmental Regulations**

Orderly and responsible waste management is not only very important for the protection of health and the environment, but it also has great importance where saving natural resources is concerned.

In body repair shops, since the introduction of the EU directives on the avoidance of vehicle waste and the promotion of return, re-use and recycling of vehicles and their components (2000/53/EU), more rigorous attention than before is also paid to avoidance and recycling of waste materials.

**NOTE:** The organization of disposal in the operation must comply with the country specific waste regulations:

In this respect, body repair shops must take into account and comply with the following requirements:

- Separate waste according to its recycling and disposal methods.
- Produce evidence for the correct transport and disposal of waste.

**NOTE:** The organization of disposal in the plant must comply with the requirements of the Waste Avoidance and Management Act.

The avoidance and recycling of waste must always take priority. However, despite all measures which may be taken, waste cannot be completely avoided.

**NOTE:** Useable waste which is not allowed in household rubbish, must be disposed of as special waste

All remaining waste must be treated as commercial waste and disposed of according to the local requirements.

#### Only applies to the EU:

The vehicle manufacturer is also under a legal obligation since the older vehicle legislation came into force throughout Europe in 2002.

This law covers the surrender, withdrawal and environmentally friendly disposal of older vehicles through the manufacturer.

The older vehicle legislation contains all the necessary information for the environmentally compatible disposal of older vehicles, starting with preliminary handling involving the removal of all operating fluids, deactivation of pyrotechnic components, elimination of pollutants and then further handling by dismantling components for re-use and recycling.

# Body Construction

## General

Under bodywork construction, a general distinction is made between monocoque and non-monocoque bodywork. The safety of the occupants is the main consideration for all types of bodywork construction. The front and rear sections are designed so that they absorb the energy of the impact via crumple zones. The use of modern design and manufacturing methods and the use of newly developed body panels (relating to their deformation and strength properties) mean that, despite the continuous weight-savings, all safety-related requirements made of the construction can be met.

## Integral body-frame

In this method of construction, coverings, reinforcements, retaining panels and profiles are permanently joined together using a variety of joining techniques (gluing, spot welding, laser welding, soft soldering or brazing). The load-bearing function of the structure must always be achieved in each case.

There is no distinction made between components which are purely subject to bending/torsion or thrust loads and parts which perform sealing/covering functions (as in non-monocoque bodywork for example). In modern passenger vehicles, monocoque bodywork is very widespread and offers the advantages of a lightweight and low-cost construction.



The rigidity of the bodywork is achieved by a panel skin and panel cross-section with the largest possible profile and therefore the largest resisting torque (such as for instance the rocker panel). Swage lines in the outer area of the bodywork increase the stiffness and the natural vibration frequency, to prevent possible drumming noises. The mounting points for ancillary components such as doors and wings are permanently built into the monocoque bodywork.

High rigidity of the bodywork is vitally important to keep the elastic deformations low at the joins to the ancillary components and to prevent noise when driving. Small gap dimensions are therefore


only possible on vehicles with very stiff bodywork. With high bodywork stiffness, the construction can exert an influence on the handling of the vehicle (e.g. on poor road surfaces).

Advantages of monocoque bodywork:

- · Weight reduction.
- Economical manufacturing technology. ٠
- High torsional rigidity and high flexural strength.
- Defined deformation behavior at the front and rear.
- Maximum passive safety due to the strong • passenger compartment

The protected passenger compartment with strong pillars, rocker panels and doors with integral side impact protection increase occupant protection. Opening of the doors is ensured, even if there is extreme deformation.

**NOTE:** Repair work must always be performed according to the established workshop literature. All the safety requirements must be guaranteed after any repair work has been performed !



## **Convertible**

Des cript ion	Description
1	Body components adopted from the Focus 2004.75 (07/2004-)
2	Conventional bodywork construction steel
3	High-strength sheet steel
4	Super-high strength sheet steel

Des cript ion	Description
5	Maximum-strength sheet steel
6	Aluminium, can be subjected to high stresses

The body of a convertible differs from the principle of the integral body-frame of a saloon due to the lack of a roof construction. The body has a high

degree of torsional stiffness. This is achieved by using high, super-high and maximum-strength sheet steel and body reinforcements in specifically-targeted areas.

These reinforcements can be installed in the area of the doors (diagonal braces etc.) or on the underfloor. In contrast to the saloon (or other non-convertibles) with square-section side members (closed profile), these reinforcements have a profile which is open on the underside (U-section).


Special constructional changes within the bodywork structure:

- Reinforcing or increase in the thickness of the sheet steel in the pillar area.
- Reinforcing or increase in the thickness of the sheet steel in the floor pan structure (rocker panel area).

- Use of heavily structured reinforcing panels in the rocker panel and pillar area.
- In the area of the windshield frame and A-pillars, thick-walled reinforcing tubes are used (roll-over protection).
- Because there is no roof, the bridge construction principle cannot be used as it is on the saloon for example. Flexural and torsional rigidity must be ensured by other components.

## Non-monocoque bodywork

Non-monocoque bodywork is built onto a frame or a chassis. Frames used for this have various construction forms, e.g. the ladder frame or tube frame. Non-monocoque bodywork is the original way of constructing vehicles.



Des cript ion	Description
1	Vehicle body.
2	Frame Assembly
3	Bolted connection

The ladder frame is still commonly used today for truck and off-road vehicles. The bodywork is placed on the frame or chassis. The total load which occurs while driving is transferred to the chassis.

More sporting vehicles can be built with non-monocoque bodywork, mostly using a lattice tube frame. Limitations in the design are accepted for the benefit of low weight. The outer skin here

is usually made of plastic or alloy. This type of construction is also common in touring car racing for instance.

# Special features of non-monocoque bodywork construction:

- Partly large surface panels and high volume shaped parts.
- Thicker materials and greater reinforcements in the frame area.
- Floor pan as frame structure with high torsional rigidity and flexural strength.
- Side panels only make a small contribution to the overall stability of the body.

#### Instructions for repair:

A different repair technique is necessary during repairs. A deformed frame structure requires high


suction power during straightening repairs. Frequently, the body also has to be detached from the frame structure in order to carry out separate repair.

Due to the very stable frame structure, please note that the straightening behavior is completely different to that of a passenger vehicle. The frame and the attached body must be repaired independently of each other.

Further information can be found in the respective body repair manual.

#### **Special points:**

#### Tailored blanks



#### Blue: Tailored blank

#### Arrows: Laser weld seam

The term "tailored blanks" describes the connection of two different panel thicknesses and/or strengths in the bodywork carcass. This connection is done using laser weld seams. Cut locations exactly on the laser weld seams are not permitted, as at present no joining techniques are approved for use in repair procedures that would re-create joins of the same quality.


**NOTE:** No cutting, no welding and therefore no sectional repairs are permitted in the immediate area of the laser weld seams. The model specific requirements are documented in the respective Body Repair Manuals.

Typical application areas are:

- Side member
- Door inner reinforcement/door frames
- Rocker panel inner reinforcement
- Roof rail inner reinforcement

Wheelhouses

## **Deformation behavior**



Des cript ion	Description
1	Bolted crash element
2	Front side member
3	Rear side member

Different materials and design features lead to staged deformation of the front and rear of the vehicle in an accident.

## Crash element:

At the front of the vehicle there is a crash element which is connected to the side member by threaded connections. This crash element can absorb light impacts of up to about 15 km/hr. Because of the threaded connections, the crash element can be changed very quickly.

**NOTE:** Deformed crash elements must not be straightened or repaired.

Heavier impacts which can no longer be absorbed by the crash element must be absorbed by the side members or the floor pan structure. Depending on the extent of the damage, a part or complete replacement can be performed on the side member. The rear of the vehicle, like the front of the vehicle, has structures which protect the passenger cell through staged deformation in the event of an accident. The design layouts, however, are adapted to the requirements of the rear area.

## Diagnosis and Damage Evaluation

Assessment of the extent of the damage includes visual inspection and dimensional inspection of the vehicle. In order to correctly determine the extent of the damage caused by an accident, in-depth technical knowledge, practical experience with the technical equipment and the testing and measuring devices is required.

# Noticeable damage to the bodywork structure

Positive accidental damage assessment can only be achieved if the service technician is able to reconstruct the effect of an impact on the body structure.

For example:

If the impact occurs on the front left-hand side member, the right-hand side member will usually also have been damaged. Often the length of this side member will not have changed, but because of the rigid body design, it may have become deformed. This damage can be detected through the size of the gap between the door and fender or by measuring the vehicle.

In the case of more severe impacts, in which the front part of the vehicle cannot absorb all of the impact energy, the passenger cell is also used to absorb the energy. Here, the energy is transferred via the A pillar and distributed there. This results in deformations in the roof and the door sill.

**NOTE:** Because of existing damage to the bodywork structure, damage diagnosis on a vehicle lift may give extra incorrect diagnosis results.

**NOTE:** Training courses are offered on this subject. For an overview, please refer to the Ford Service Organisation's training course brochure.

If for instance the Ford Focus Coupé/Cabriolet is raised on a vehicle lift, the dead weight of the vehicle will cause the front end to drop by approx. 2 to 3 mm.

The altered door position is clearly recognizable by stiffness of the lock; the door moves upwards. This causes the lock pin to contact the guide element of the door lock.

It is possible to draw conclusions about the extent of the damage through a visual inspection of the external damage. In general, the following areas are to be checked during the visual inspection:

- Outer panel including seam seals for cracks or flakes in the paint caused by the accident.
- Size of the gap on doors and hoods for evenness.
- Freedom of movement of door and hood/tailgate locks.
- The vehicle roof for folds (gap measurement on vehicles with sunroof)
- Dotted flange in door section for deformation and cracked weld spots.
- The side members and crash components for crumpling and folding.
- Trunk floor and floor pan from above and below for crumpling.

# No noticeable damage to the bodywork structure

In addition to external indicators such as flaking paintwork or cracks in the underbody protection, it is vital to check for damage to the body structure that is not visible from the outside (hidden body damage) during a damage assessment. Unless ancillary components are removed, it is often impossible to achieve accurate diagnosis of the underlying body parts.

**NOTE:** In order to determine the damage as accurately as possible, it may be necessary to remove ancillary components in the area of the damage.

Particular attention must be paid to the following components:

- The A, B and C pillars in the roof area.
- Floor pan.
- Rear ancillary components, such as bumper, lights, etc.
- · Trunk floor, spare wheel cavity.
- Rear coverings, such as interior trim, carpet, etc.
- Lower rubber seals, e.g. in door area (welded flange).
- Area under the rear seat.
- Attachment points of transmission system, steering, engine, drive shafts, front and rear axles.
- Electrical components, e.g. the radio (damage through shaking or through voltage peaks).

#### Non-monocoque bodywork

The chassis and bodywork must always be checked during damage diagnosis on vehicles with non-monocoque bodywork.

It is also important here to inspect closely for damage the impact area and the areas absorbing forces.

With these vehicles, simple inspections can already give an indication of possible deformations.

In addition, you must check for the following for vehicles with frame structures:

- Cracks in the paint on the frame welds.
- Traces of deformation on frame components.
- Check attachment points (silent blocks) for position changes and damage.
- Changed position of rubber seals.
- Fit and function of the ancillary components.

## Body Sheet Metal

## Types of steel

Steel body panels are still the most important materials used in the fabrication of stressed skin vehicle bodies. In addition to the familiar types of steel, reinforced high-strength and also ultra-high-strength special steels are used in vehicle body construction.

Types of steels are classified by their properties of strength and elasticity.

- Normal strength steel has a minimum yield strength of up to about 210 N/mm<sup>2</sup>.
- High strength steels have a minimum yield strength of about 150 to 600 N/mm<sup>2</sup>.
- Ultra-high-strength steels have a minimum yield strength of about 400 to 1200 N/mm<sup>2</sup>.

High-strength and ultra-high-strength steels are mostly installed in safety relevant locations (structural components). Among others, these are side members, pillars, roof frames.



Pos.	Used type of steel	Application range
1	Ultra High Strengh Steel (UHSS)	Impact carriers, Bumper carriers, Reinforcements
2	Extra High Strengh Steel (EHSS)	Frame side member,
3	Very High Strengh Steel (VHSS)	Wheel house,
4	High Strengh Steel (HSS)	Roof sticks,

Pos.	Used type of steel	Application range
5	Normal strength steels	Outer Panel,

#### Normal strength steels

Normal strength steels are most often used in body construction. They are relatively soft and are therefore particularly suitable for the deep drawing processes used in body manufacturing. As well as very good reshaping properties, the panels also have a relatively high rigidity.

#### High strength steel panels

The strength of the material and the nature of the surface can be changed as required by different engineering processes. In order to achieve suitable configuration and a good match between construction specifications and what is possible in production, a large range of high strength panels is available.

The range of the minimum yield strength is from 180 N/mm<sup>2</sup> to 460 N/mm<sup>2</sup>. High strength thin steel panels usually have a surface finish. Electrolytic surface sealing is preferred. Within the group of high strength steels, various types of steel are used in body construction:

- **Micro-alloyed high strength steels** for very difficult drawn components such as fenders, the internal components of doors, hoods and luggage compartment lids or load bearing components such as sidemembers, crossmembers etc.
- Bake-hardening steels and phosphorus alloyed steels for external panel components with higher draw depth and subject to higher operational demands.
- **Isotropic materials** for flat shaped outer steel panels on doors, hoods, luggage compartment lids, roofs.

#### **Ultra-high-strength steels**

These steels are predominately used for body structural components which are relevant to safety. Despite the reduced thicknesses of the panels used, weight reduction is often achieved together with greater strength. As with high-strength steels, special types of steel are used in the ultra-high-strength steels group:

- **Complex phase steels** are used for door side impact carriers, bumper carriers and body components relevant to crashes. Besides high strength, they have good cold reshaping properties and are easily welded.
- Dual phase steels have the same properties as complex phase steels. Because of their high strengthening properties they are suitable for body reinforcements.
- Residual austenite steels and martensite phase steels have very high strength levels of up to 1200 N/mm<sup>2</sup> and are mostly used in body structures relevant to crashes.

Because of the use of such steels, some special points must be taken into account during body repair:

- Increased force required during straightening.
- Strong springback tendency during alignment work.
- Cutting tools have a shorter useful life.
- **NOTE:** High-strength and ultra-high-strength steel panels must not be heated during straightening work.

Work without applying heat when carrying out straightening work. Losses of strength will occur at temperatures as low as 400°C. The basic working methods and the tools to be used are the same however.

### **Coated steel panels**

In a similar way to high-strength steel panels, coated steel panels are finding more applications because of the better corrosion protection which they offer. There are basically two different process which are used to apply a zinc layer:

- Hot dip zinc coating (no longer used in vehicle construction).
- Electrolytic zinc plating.

The following points must be noted when welding:

**NOTE:** Welding fumes are harmful to health. Make certain that the workspace is well ventilated and use welding fume extraction.

- Zinc starts to melt at about 420°C.
- The zinc vaporizes at a temperature of about 900°C.
- The amount of heating determines the damage to the zinc coating, and therefore to the corrosion protection.
- **NOTE:** Coated panels have a higher electrical resistance, but this can be compensated for by increasing the welding current by 10 20%.

Resistance spot welding is particularly suitable for welding zinc-coated panels, because no widespread warming occurs.

• With electrolytically zinc-plated panels there is no need for any special preparation because the zinc coating does not need to be removed.


## Tools and Equipment for Body Repairs

#### **Alignment systems**

**NOTE:** Please refer to the Ford Service Equipment Catalog for information on the body tools recommended by Ford.

Straightening and alignment repairs are often required to restore a vehicle body to its original shape after accident damage.

Universal aligning and measuring systems and universal alignment angle systems are suitable for this work.



Des cript ion	Description
1	Universal aligning and measuring system
2	Universal alignment angle system

Basically, the aligning and measuring system must satisfy the following requirements:

- Universally applicable to all types of passenger car. Can also be used on light commercial and off-road vehicles.
- Accepts the forces involved during straightening.
- High stability and mobility.
- Can accept all or part of the weight of the vehicle.
- Quick to set up.

- Simple to use.
  - Stationary design with drive-on ramp.
  - Height-adjustable aligning platform.
  - Universal gauge extensions with fast anchoring ability around the whole circumference of the aligning platform.
- Facility to test individual body measurement points, with or without aggregates being removed.

Alignment angle devices survey the vehicle at several points on the body. These are usually points which are also used in production. In addition, a recording over the rocker panels is possible. A measuring system is not needed, because the necessary body points are specified with gauges. For this purpose, vehicle specific or universal gauges are available.

**Universal alignment systems** consist of a vehicle mounting (universal clamps at the rocker panels) and a pulling device. In addition, a measuring system is required.

**NOTE:** Because universal clamps are used, the rocker panel area must be reworked for optical and corrosion protection reasons after the repair is completed.

Pay attention to the following points:

- Clean the attachment areas.
- Anchor the vehicle free of stress on the relevant system.
- Support the aggregates to take strain off the body.

### **Measuring systems**

In order to exactly diagnose a damaged vehicle body, measuring systems are required. Depending on the measuring method, the systems vary in having mechanical, optical, acoustic and electronic measuring devices. In some cases, hybrid versions of particular systems are found.

**NOTE:** When working with each measuring system, the manufacturer's instructions provided in the description of the measuring equipment must be followed.

Basically, the measuring systems must meet the following requirements:

- Universally applicable to all types of passenger car. Also can be used on light commercial and off-road vehicles.
- Suitable for all accident damage.
- Fast capture of body measurement points in the underfloor and external areas.
- Data catalog to record all measurement points (length, width and height) both with and without the aggregates being installed.

**NOTE:** Basic and in-depth training is offered on the following topics. You will find an overview of the complete range of training offered in the Ford Service Organization training brochure.

#### Beam compass

The beam compass is a very practical and straightforward aid for measuring bodywork and especially floor assemblies. The beam compass can be used to detect dimensional variations across the length and the width by means of comparison measurements and diagonal measurements. As a basic principal, body reference points should be chosen which are shown in the body frame measurement data sheet.

**NOTE:** To be able to determine difference in measurements, the same reference points must always be chosen on both sides. For this purpose the beam compass must be positioned symmetrically.

Comparison measurements can also be made on the outside of the body. Depending on the damage, left/right measurements (symmetry measurements) and diagonal measurements can be made using the beam compass, telescopic rod or a measuring tape.

#### Laser measuring systems

These systems use laser beams which are projected in one or more planes.



By the use of two parallel laser heads which can be turned, symmetrical points of a vehicle body can be tested and compared. Using the linear scales which are attached to the measuring points, the measurement data is read off with the aid of the projected laser beams.

The integral inclination gauge also allows differences in height to be quickly checked.

#### Mechanical measuring system

The use of mechanical measuring equipment is an easy and effective way to check a vehicle frame and chassis assembly quickly, exactly and reliably.

In many cases an assessment of the damage can be made with the help of this system, without the need for elaborate setting up.



Because of its self-centering mount, measurement can be carried out by one person.

Further advantages:

- Fast deployment.
- · Simple to use.
- Can be extended using adapters, measuring probes and measuring tubes.

Measuring systems which are firmly mounted on an aligning platform require more work in setting them up. They are used to constantly check measurements during alignment work.

This type of mechanical measuring system has measuring scales and measuring slides in three measuring axes. So that the body can be measured, the vehicle is secured on the aligning platform base frame using four universal chassis clamps. The exact fixing points are given in each respective data sheet.

# Ultrasonic and mechanical-electronic measuring systems

These measuring systems can be combined with all current aligning platforms. In addition these measuring systems can be used independently of an aligning platform by using a vehicle lift or suitable support stands.



Des cript ion	Description
1	Ultrasound measuring instrument
2	Mechanical-electronic measuring system

Acoustic or ultrasonic measuring systems use ultrasonic emitters and sensors to survey a body.

To do this, ultrasonic emitters are mounted on the vehicle using special attachments. During the measuring process the ultrasonic emitters constantly send out signals which are received by sensors (microphones) and then passed to a

computer. The measurements are displayed on the computer screen and are compared with the required values supplied by the vehicle manufacturer.

The ways in which mechanical-electronic measuring systems can be used are similar to those of the acoustic measuring systems. They can also be set up on a suitable understructure, without an alignment jig. After this system has been arranged under the vehicle floor and adjusted to three undamaged vehicle measuring points, the measuring arm is brought up to the required measuring points and the readings compared with the reference values. The data is transmitted to a computer where it is evaluated and the results displayed on a screen.

### Welding gear

As in the past, the dominant process in body construction is resistance welding, in particular spot welding. Depending on body type, up to 5000 spot welds are applied, either by welding robots or in the multi-point welding machine.

Resistance spot welding permits very high energy to be concentrated on a relatively small area of the workpiece in the shortest possible time and when high pressure is applied, a permanent joint is formed. During repairs the resistance spot welds used in production must be re-created accordingly.



Des cript ion	Description
1	MIG welding machine
2	Resistance spot welding machine

**NOTE:** If a suitably powerful welding machine is not available and multi-layer panel joints with a total thickness of over 3 mm need to be made, puddle welding must be used.

Although in principle, high and super high-strength panels are adequately or well suited to resistance spot welding, considerable problems may arise because of low welding power, especially where thicker panels or three layers of panel must be welded together in the workshop. In particular, older welding equipment does not have the latest welding technology nor welding power and therefore cannot reliably join panel thicknesses greater than 3 mm.

Equipment with inverter technology allows better spot weld quality because of a constant high welding current. In addition the high welding current makes shorter welding times possible and the electrodes therefore have a longer working life. Inverter welding is a further development of electrode welding.

Further advantages of the new inverter welding equipment are:

- good welding performance with constant quality, even with high switch-on times
- recognition of and compensation for disruptive factors: e.g. primer, adhesive, rust-prevention paint
- own and pre-set welding programs which can be saved and called up

- quality confirmation through logging of all important welding data
- fast changing of spot welding clamps or spot welding guns as required

The following functions can be controlled and monitored by programming the welding equipment:

- Control of the start conditions by resistance measurement (dirt, paint, bodywork adhesive, shunt circuit through the next spot weld).
- Ensuring the optimum welded connection.
- Checking the energy balance, resistance and quality.

In the case of resistance spot welded connections, faults in the weld are difficult to see from the outside. It is therefore absolutely vital to know the particular properties of the welding machine being used. A test weld with subsequent peeling test will provide information on the quality of the weld. The spot weld itself must not separate, it must tear away leaving a hole.

In the production of vehicle bodies, MIG welding plays a minor role as a joining technique. It is used for components subject to high demands, such as threaded plates for axle mountings, or at locations which cannot be spot welded for access reasons.

## Establish Repair Method

### General

Before starting accident repair work, make sure that the necessary spare parts and repair material are available.

## Planning

**NOTE:** The body interconnection is to be maintained if possible. Repair is preferred to renewal of body components. Furthermore, check if it is possible to perform a partial repair.

During planning the following job steps must be observed and adhered to:

- Determine the repair method taking into account the information made available in ETIS.
- Work out which repair components will be needed and obtain them.
- Establish what disassembly work is needed.
- Check for specific features such as airbags, route of water drain hoses, electric cables and the location of NVH elements.
- Cut out the old parts (only when the new parts are waiting ready).
- Prepare the joint locations.
- · Attach the new parts.
- Prepare the area of the repair for painting (grinding welded beads).
- Perform any solder work which is required at the repair location.

## Chronological sequence of repair

**NOTE:** Refer to each vehicle specific chapter in the workshop literature for details on the individual points.

The actual sequence of repair can be divided into the following steps:

Job steps for the coachbuilder:

- Straightening
- Establish separating cuts and mark them.
  - Take into account the requirements given in the repair instructions.
  - Place the new part ready for use and include it in the repair plan.

- · Separate and remove the old part.
  - Take into account the special features particular to the vehicle.
- · Prepare the joint locations.
  - - Sand and align the weld flanges.
  - Apply corrosion protection measures.
  - Offer up the new part.
- Attach the new component.
- · Rework the welded joints (grind welded seams).

## Alignment Check

#### General

If there is concern that the body has been deformed, the body must be measured. Several measuring procedures and tools can be used for this purpose.


With simple measuring systems, it is possible in most cases to draw a conclusion about the extent of the damage through a quick measurement without time-consuming assembly work (straightening jig).

**NOTE:** For the floor pan and the exterior of the vehicle, measuring data is contained in the vehicle-specific repair instructions for each vehicle. Manufacturers of measuring and straightening jigs create data sheets for this purpose for each vehicle.


Data sheets with the body frame dimensions for body measurement are specified in the model-specific repair instructions in each case. Pay attention to the position of the measuring probes for each of the measurements given. A tolerance of  $\pm$  3 mm applies to all specified dimensions.

Measuring points that are specified in a curve are to be measured so that the greatest distance from the opposite measuring point is reflected. For exact determination of the measuring points, enlarged sections are shown.

Example of measuring the vehicle superstructure



Example of measuring the floor pan



# Straightening

## General

Straightening repairs are often required to restore the original body shape. To do this, the vehicle must be placed on a straightening jig so that a pulling device can be used.

**NOTE:** Basic and advanced training courses are offered for the following contents. For an overview of all training courses offered, please refer to the Ford Service Organisation training course brochure.

Straightening is considered as the process of pulling out the deformed body parts, up to cutting out the parts that need replacing. If distorted components remain on the vehicle, then the term alignment work is used.

Body straightening requires practice and experience. Before starting body straightening, the exact direction of impact must be determined. The straightening force must be applied in the opposite direction to that of the impact. Only in this way can it be guaranteed that the original shape will be achieved again.

Note the following points during the process of body straightening:

- Secure the pulling unit with a safety cable.
- Do not remove bonded glass prior to straightening.
- Never apply heat during straightening.
- If necessary, open doors or hoods/lids/liftgates during straightening.
- Check dimensions and gaps continuously during straightening.
- High-strength steel panels have a stronger tendency to retain their deformed shape.
- During the straightening repairs, monitor the attachment of the pulling unit to the vehicle.
- Carry out the straightening work in several stages, never in one pulling process. This prevents the risk of overstretching and of joints tearing out.
- During individual straightening steps (under a pulling load), relieve tension by striking the deformed areas with an aluminum hammer while they are still under tension.

# Special features of non-monocoque bodywork

Straightening is different to monocoque body construction because of separate straightening for bodywork and chassis.

If only the body is damaged in an accident, light straightening repairs can be carried out while still mounted on the chassis.

**NOTE:** With strong straightening forces, these bolted connections may be damaged (bodywork to chassis frame). Monitor the bolted connections continuously during the straightening work. Holding clamps or alignment angles must be attached directly to the chassis frame.

#### Straightening of chassis frames

**NOTE:** High-strength steels must not be heated.

If the body and chassis frame have to be straightened, they must first be separated from each other.

The following conditions must be met:

- The repair must be economically justified.
- The production quality and stability of a frame must be achieved again after carrying out the repair.
- In principle, the driving and operating safety of the vehicle is paramount.
- Cold straightening of deformed areas with sharp edged folds cannot be carried out.
- Straightening with the application of heat (welding torch) requires much experience and accurate knowledge of the behavior of steel panels when heated.
- The temperature and duration of application of the heat are to be considered in particular.
- Individual components of the frame, such as cross members, brackets, etc. can be replaced.


## **Complete Panel Replacement/Partial Replacement**

**NOTE:** Basic and advanced training is offered for the following contents. For an overview of all training courses offered, please refer to the Ford Service Organisation's training course brochure.

Repairs always mean intervention in the body shell structure and thus also intervention in the vehicle's passive security system.

**NOTE:** From an economic perspective, the possibility of a partial replacement (sectional repair) must be considered when assessing an accident-damaged vehicle.

#### **Partial Replacement**



Item	Description
1	Join area
2	Original welding

#### **Decision criteria**

The following are always crucial for the decision:

- · How economical the repair is.
- Retention of the original join.

In addition, Ford must have given its approval for a sectional replacement solution in the damaged area. For those partial replacements approved by the factory and described in the model-specific body workshop literature/technician's information, some spare parts (service parts) specially prepared for partial replacements are offered through the spare parts sales department.

Sectional replacement (sectional repair) means the replacement of a section of the body shell structure. Sectional repairs fulfill their purpose above all if the replacement of a complete part is too time-consuming and thus not economical. Approved sectional repairs are clearly defined in the model-specific body literature. These requirements must be complied with.

Depending on the damaged areas, further facts are to be taken into account when deciding for or against partial replacement:

- Severance cuts should be as short as possible.
- The effort for follow-on work on the connections must not be too great.
- It must be possible to reproduce the optical path of visible edges on door openings.
- Inner reinforcement panels must not limit the straightening work.
- Inner reinforcement profiles in the pillar areas must allow for separation.
- The Ford regulations for partial replacements on structural frame sections must be taken into account.
- The large surface welding seams at the connections must be restored.


#### Advantages of a partial replacement

A partial replacement repair offers many advantages for a professional repair of accident damage:

- Repairs can be made both in the outer panel area (e.g. side frame) and in the inner areas (e.g. structural member, trunk floor).
- The repair can be limited to the actual damaged area.
- Reduction of repair costs, as aggregates and other components can usually remain in the vehicle.

## **Complete replacement**

In a complete replacement, the original connections are largely reused.



A complete replacement is advantageous if the damaged body part can be detached from its original connections and a completely new part can be fitted without creating additional joints (e.g. liftgate).

A complete replacement is necessary if there is no sectional replacement solution.

## **Corrosion Prevention**

The corrosion protection provided in production must be carefully maintained and reproduced during body repair work, in order to ensure the long-term warranty for Ford vehicles.

**NOTE:** Please take the notes in the model-specific repair descriptions into account. Please also note the manufacturer's instructions when handling the different anti-corrosion agents.

Only Ford original bodywork components and Ford approved repair materials are to be used for body repairs. The Ford logo is stamped onto every Ford original spare part.

# Panel coatings and corrosion protection

Body steel panels are provided with a coating for corrosion protection purposes. The coating material is predominantly zinc in a variety of composition forms. Aluminum is also used to some extent. Basically, all types of steel sheet can be coated.

A variety of coating processes are used:

- Hot dip zinc coating (no longer used in vehicle construction).
- Electrolytic zinc plating.
- · Organic coating.
- Hot dip aluminum coating.

**NOTE:** Welding fumes are harmful to health. Make certain that the workspace is well ventilated and use welding fume extraction.

The following points must be noted when welding:

- Zinc starts to melt at about 420°C.
- The zinc vaporizes at a temperature of about 900°C.
- The amount of heating determines the damage to the zinc coating, and therefore to the corrosion protection.
- Resistance spot welding is particularly suitable for welding zinc-coated panels, because no widespread warming occurs.
- With electrolytically zinc-plated panels there is no need for any special preparation because the zinc coating does not need to be removed.

**NOTE:** Coated panels have a higher electrical resistance, but this can be compensated for by increasing the welding current by 10 - 20%.

# Corrosion protection measures during repair work

CAUTION: Always be extremely careful when handling solvents, sealants and adhesives. Some products contain substances harmful to health or give off harmful or poisonous vapors. Always follow the manufacturer's instructions. If there is any doubt as to whether a particular solvent is suitable, it must NOT be used.

All Ford bodywork components have a cathodic primer. Moreover, most parts are zinc-plated on one or both sides. If possible, these protective layers must not be damaged.

#### **Before welding**

Interior surfaces of new bodywork components which will no longer be accessible after installation must be painted beforehand. The welding flanges are treated with a special welding primer. The joint areas are not always accessible from inside later. Therefore, prepare these areas so that no soot is produced by burning paint during welding.

**NOTE:** In order to ensure that the corrosion protection produced in production is not destroyed, the working area must be kept as small as possible.

**NOTE:** Do not touch cleaned bare metal any more with the bare hands. The dampness of your hands will corrode the metal.

Procedure:

- Remove the primer or paint/zinc layer in the welding area using a tress wire brush to prevent the formation of soot from the paint.
- Thoroughly clean the welding area with a metal cleaning agent and rub dry.
- Coat the welding flange with welding primer on all sides and allow to dry.

**NOTE:** The welding primer must only be applied thinly to the spot welding area, to minimize spattering when welding.

#### After welding

During repair work, body panels are often heated at very high temperatures, which results in the destruction of the corrosion protection.

Reworking of the affected areas is therefore vital:

- Grind the welded seams flat and clean thoroughly with silicone remover. Dry with a lint-free cloth.
- If the join area is accessible from the inside, the transition area to the paint must be abraded for all types of join so that good adhesion of the primer is achieved later.
- If the join area is not accessible from the inside, the cleaning and sanding work is not done. For this reason, ensure that there is as little contamination as possible in the area of the repair. This allows the cavity wax applied later to penetrate the join area without hindrance.

**NOTE:** Only apply a small amount of panel cleaner to the cleaning cloth when cleaning the repair area. Make sure that no cleaner reaches the connecting flange, so that the welding primer is not washed away again.


#### Priming after welding

Primer is applied to the welded flanges after cleaning. A check must also be made that the production corrosion protection is present in the area of the flanges. Any damage must also be re-primed.

#### Sealing work

Depending on the type of repair, the clinched flanges on the hood, doors, tailgate and trunk lid must be sealed with clinched flange sealer.

#### Clinched flange protection with flat nozzle



Clean the clinched flange area of the new component with silicone remover and dry with a lint-free cloth.

The sealant must be applied to the dry primed surface (i.e. dip priming as for delivery).


Apply clinched flange protection to the clinched flange using one of the flat nozzles supplied. The nozzle must be cut to the necessary width beforehand and the guide stop cut as required.

During application the clinched edge must be covered with an overlap of at least 3 mm. The beginnings, ends and edges or interruptions in the sealer bead need to be reworked by forming with a brush or a spatula, to ensure a 100% tight sealing of the flange.

The speed and angle of application are decisive for a good appearance and a bubble-free bead. Always apply the sealer with as few as possible interruptions to avoid sealer rework. Never use solvents or thinners as this will considerably slow down the hardening process of the sealer.

For an application thickness of 3 mm of the clinched flange sealer it is recommended to allow to dry over night at room temperature. A minimum hardening time of 5 hours is required anyhow before a 2-component primer can be applied.

# Clinched flange protection applied to the correct width and thickness.



# Underbody protection/stone chip protection

The underbody protection is used as corrosion protection and must also be applied such that it matches the original condition, from a visual perspective.

Two main application methods are used in production:

- The underbody protection is applied as a sprayable sealing compound.
- In the area around the structural members, the underbody protection is sprayed on and spread across a wide area.

Because of the coarse surface structure of the stone chip protection material, it is recommended to only perform a repair over the whole surface, if there is damage over visible areas. Otherwise there is the danger of serious irregularities on the surface.

The thickness and appearance of the underbody protection and stone chip protection must be matched to the original. Special spray guns are used to work the materials for this reason. A test spray must always be performed beforehand however, to determine the correct appearance and layer thickness.

#### **Cavity protection**

After painting work has been completed, a general check is made of the work that has been done. Before final reassembly of the vehicle, the cavity wax protection in the area of the repair must be renewed. Cavity wax protection must be performed carefully so that the quality of the repair conforms with Ford standards:

- Guide the cavity wax probe carefully in the area of the repair so that targeted corrosion protection is achieved.
- Pay special attention to edges and swage line on stepped joints, the wax must cover the inner edge areas.
- The cavity wax must flow along the stepped sheets so that the wax is drawn between them by capillary action.

A hole may be drilled in a suitable place for areas which are not accessible for the application of cavity wax. The diameter depends on the size of plugs available. When this is done it is vital to make sure that no drilling swarf remains in the cavity (rust will form if any remains). The edge of the hole must be treated with cavity wax. Finally close with a plug and seal with underseal.

Only on components with clinched flange edges:


After painting, the inner clinched flange edge must be sealed as far as is possible with cavity wax. For this, the repaired component should be positioned upright and corrosion protection wax sprayed into the water drainage holes and/or the thread holes for the hinges in both directions (50 ml corresponds to about 20 seconds spraying time).

For doors, tilt and turn the component to spread the corrosion protection wax over the whole edge of the flange.

#### Wax application



## **Corrosion protection for the floor pan (example)**



ltem	Description
1	Injection points for cavity wax protection
2	PVC stone chip protection at the wheel arches
3	PVC underbody protection
4	PVC stone chip protection
5	PU primer

## Corrosion Damage/Corrosion Repair

Modern vehicle bodies are protected from corrosion by elaborate measures. Multilayer coatings on the panel surface prevent direct contact between the metal and oxygen, and so protect it from corrosion.

In the long-term however, corrosion on a vehicle cannot be completely prevented.

**NOTE:** Basic and in-depth training is offered on the following topics. You will find an overview of the complete range of training in the Training Brochure issued by the Ford Service Organization.

#### What is corrosion?

Corrosion is destruction of a subsurface caused by chemical or electrochemical effects which operate from the outer surface.

If the protective layers become damaged, electrochemical conversion processes are initiated, which allow the metal to oxidize. This leads to the formation of corrosion.

The following factors lead to corrosion:

- Mechanical damage such as stone chips and scratches which penetrate through to the steel panel.
- Damp interiors.
- Unfavorable weather or environmental conditions, as may occur in areas with high humidity, high salt content in the air or serious air pollution due to aggressive gases and dusts.
- Insufficient corrosion protection after repairs.
- Lack of care by the vehicle owner of the painted and corrosion proofed surfaces or areas on the vehicle.

In order to maintain long-term corrosion protection, the vehicle must be checked at regular intervals.

In doing so, the follow areas must be inspected and any damage rectified:

- Damage to the paint surface cause by scratches or stone impact must be suitably rectified according to the specifications.
- Damage to the PVC underbody protection or the PU stone chip protection must be refinished.
- Damage to the PVC underbody protection or the PU stone chip protection must be refinished.
- Incomplete or damaged sealing at clinched flanges must be renewed.
- Check the cavity protection and renew it if incomplete.

- Poorly installed or damaged covers and stone chip protection fixtures must always be renewed.
- Check seals and seal carriers for wear and correct mounting. Any damaged seals must be renewed.
- All rubber grommets and blanking plugs must be present and correctly installed.
- A damp or wet floor inside the vehicle indicates that there are leaks in the bodywork. The interior must be dried out and the leaks must be completely rectified.

The corrosion formation can vary in extent.

With rust film or edge rust formation, the surface of the paint has small traces of corrosion present. The traces of corrosion can possibly be removed in such cases by polishing the paint surfaces. If this is not possible however, the traces of corrosion must be rectified by using a touch-up technique.

If the corrosion is just starting, with up to 1 mm rusting below (in the form of a dot or a line) the damage is rectified as follows:

- Clean the defective location.
- Mechanically remove the rusting which is starting below the surface.
- If the area is small, apply primer and allow it to dry, then use the paint pencil to touch up the area if not, respray the damaged area.

If rust is already under the paint finish to the steel panel, then the whole paint finish in the affected area must be sanded away.

Furthermore, the existing traces of corrosion in the body panel must be carefully and completely removed.

Finally a new paint finish must be applied in this area. In the case of rusting through, the affected body panel is already completely destroyed. Such damage requires complete or at least partial replacement.

**NOTE:** : In the general section there are several chapters which present the techniques necessary for a professional corrosion repair.

The outcome of this is the following repair sequence:

- Remove the rusted-through part.
- Remove the remaining traces of corrosion.
- Offer up the new part.
- Prepare the joint areas.

- Weld the new part into place.
- Produce the corrosion protection.

For a professional repair it is essential to reproduce the corrosion protection during and after the repair.

## Sealer, Underbody Protection Material and Adhesives

Sealants, adhesives, cavity wax and underbody protection materials are used during the various body repairs. In this area Ford offers a range of products which have been tested and matched to each other.

CAUTION: Always be extremely careful when handling solvents, sealants and adhesives. Some products contain substances harmful to health or give off harmful or poisonous vapors. Always follow the manufacturer's instructions. If there is any doubt as to whether a particular solvent is suitable, it must NOT be used.

#### **Clinched flange protection**

One-component adhesive/sealer which can be applied by brush or spraying, based on MS polymer, with a flat nozzle for application and with the following properties:

- · Can be sanded
- Permanently elastic
- Non-corrosive
- · Very good adhesion
- · Rapid hardening and resistant to ageing
- Can be over-painted with almost all proprietary paints

#### Seam sealant T Anthracite

One-component sealer based on MS polymer, for sealing joints and seams, with the following properties:

- Silicon-free
- · Solvent-free and low-odor
- suitable for gluing HVH elements into position in their respective body areas

#### Body sealant T beige

Sealer with the following properties:

- Stable
- Contains solvent
- · Especially suitable for visible seams
- After hardening can be overpainted with two-pack paint

#### **Underbody Coating**

Underbody protection is necessary for permanently elastic corrosion protection of vehicle underbodies.

It is very durable and has good resistance to abrasion,

#### **Cavity wax**

This touch-proof, transparent corrosion protection wax is used for the preservation of cavities and flange joints.

#### Anti-corrosion wax

Anti-corrosion wax is a coating material which can be applied in fine spray, forming a very thin and grease-like protective film, therefore offering very good corrosion protection.

#### 2-component metal adhesive

For joining metal to metal and plastic to metal. The adhesive reduces droning noises and improves corrosion protection.

#### Windshield sealant

Solvent-containing, stable sealing material. The sealer is permanently elastic and does not form a skin on the surface.

#### 1-component window glass adhesive kit

For direct glazing. The vehicle is ready to drive after 6 hours (passenger airbag). Prevents contact corrosion.

#### 2-component window glass adhesive kit


For direct glazing. The vehicle is ready to drive after 1 hour (passenger airbag). The adhesive is not an electrical conductor and permits interference-free radio reception. Prevents contact corrosion. Using a 150ml additional cartridge, the adhesive can also be used for large windows or to produce a double seam of adhesive.

#### PU glass adhesive

150ml additional/replacement cartridge for direct glazing using 2-component window adhesive kit. Suitable for double beads or larger windows. Also suitable for sealing NVH elements.

## **Cutting Technique**

**NOTE:** Without exception, before starting work you must read the safety and warning instructions in the chapter "Safety Instructions". In addition, pay attention to the warning instructions of the particular equipment manufacturer. **Possible cut lines (example)**  **NOTE:** After all separation work, make certain that the metal swarf is completely removed from the vehicle body.




Depending on the separating tools used, there are some fundamental points to bear in mind:

- Only start the cutting work once the new part is to hand.
- Compare the new part with the old part for shape and size.
- The straightening work must be completed before any body components to be replaced are cut out.
- Before separation work is started, all welded connections which cannot be seen must be freed of underbody protection, sealant etc.

## Spot weld milling tool

Resistance spot welds are separated using a spot weld drilling machine or a spot weld milling tool.




**NOTE:** Steplessly variable machines increase the working life of the cutting tool. Use of a suitable lubricant can increase this even further.

A spot weld milling tool usually has an adjustable depth stop and a safety fixing system. These prevent the machine from drilling too deep and the cutter from slipping while working.

## **Rod sander**

Another option for separating resistance spot welds is to use the rod sander.



If spot welds and MIG welds are difficult to reach, a rod sander may offer an alternative.

## Short stroke saw

The short stroke saw is suitable for separating vehicle body components and for making a separating cut for partial repairs.



**NOTE:** In order not to damage panels, wiring harnesses, hoses or similar components which lie behind, remove them beforehand as necessary.

The narrow design of the saw blade permits cutting in tight curves. Straight cuts require a relatively great deal of practice.

## **Orbital saw**

Where use of the short stroke saw is difficult because of the body construction, the orbital saw can be used.



The cutting depth of the orbital saw can be set. This allows separating cuts to be made, despite panels or other components lying in danger behind. Straight cut lines can be more easily made using the orbital saw.

# Panel Beating Technique and Smart Repairs

## General

Smaller scale body repairs, where damaged panels do not need to be replaced, can often be carried out by realignment work. Whether the repair is economical however, often depends on the accessibility of the affected body area.


**NOTE:** Basic and in-depth training courses are offered on the topics which follow. An overview of the complete range of training offered is provided by the Ford Service Organization Training brochure.

During damage assessment, the following technical points must be taken into account:

- Small mild dents (without damage to the paint), which are in areas that make access from the inside possible, can be rectified using undamaged paint panel beating.
- If the inner side of the damaged area (with paint damage) can be accessed, then conventional panel beating techniques can be used.
- If the damaged area has no access from inside, then it can only be rectified using outside panel beating techniques.

# Dent removal using special panel beating levers

**NOTE:** In the Undamaged Paint Dent Removal section, you will find more information on pressure techniques.




Des cript ion	Description
1	Deflection by a hook arrangement
2	Pressure tool

This panel beating technique with pressure is mainly used to rectify smaller dents as a result of hail impact, transportation or parking, without the paint being damaged.

Small dents are removed from the inside of the body panel by pushing them outwards in a mechanical process using panel beating levers.

Because of the great variety of shapes of these levers, it is possible to use this panel beating technique on almost all areas of the vehicle body.

#### Dynamic puller with counter bearing



Des cript ion	Description
1	Puller device for minor damage, with integral copper electrode
2	Puller device for more extensive damage
3	U-washers spot-welded in place
4	Puller bits spot-welded in place
5	Attachment for U-washers or puller bits

This method can be used to reshape dents or more extensive damage from the outside.

For minor damage, the copper electrode in the tool is secured onto the panel surface by spot-welding and the puller device is used to pull out the damage without jolting.


For more extensive damage, puller bits or U-washers (depending on the application area) are spot-welded to the panel surface and the area pulled out using the puller device.

Because of the versatile puller and the variable counter bearing, a wide variety of damage can be worked and rectified using this repair method.

Because of the mechanical lever operation, the variable counter bearing and the optimum controlled application of power, this external dent removal system allows dents in almost all vehicle body areas to be pulled out.

# Hollow leveling (removing dent without a dolly)

Hollow leveling can only be used on areas which are accessible from the rear.




Des cript ion	Description
1	Center of dent
2	Spoon

During hollow leveling, the dent is removed from the inside a using suitable panel beating tool and applying knocking or pressing movements. High spots around the edge of the dent area are flattened with blows from the aluminum or wooden headed hammer.

The usual tools are for instance hammers of various designs, dollies, levering irons and various spoon irons. The correct choice of tool is made depending on the shape of the dent and the access which is possible.

## Dent removal using hammer and dolly

Panel beating can only be performed using a hammer and dolly if access can be gained from the rear side.



Des cript ion	Description
1	Aluminum hammer
2	Box file

The purpose of the dolly in this case is to transfer the force of the impacts from the hammer to the steel panel which is in between. As this is done, the deformed body panel is smoothed (dressed) and the tension fields in the body panel are removed.

The favored tool for this repair process is the aluminum hammer and as opposite support the universal hand dolly. To rectify minor panel damage, the box file should be used as opposite support. Because of its serrated surface, the box file prevents normal stretching of the body panel which would otherwise occur.


## Heat-induced material shrinking

Material shrinking, also called settling in, can be performed in a variety of ways depending on the extent of the damage and the access to the repair area.

These repair processes differ depending on the type of heating and subsequent working of the heated surface. They sub-divide into two basic processes:

- · Heating using a carbon electrode.
- Heating using the oxy-acetylene torch.


In the carbon electrode process the working is done exclusively by warming. In this case the access to the repair position is only from the outside.



Des cript ion	Description
1	Carbon electrode
2	Spiral shaped heating pattern

If the damage is concentrated in a spot and is in the form of a more rigid raised area, then the carbon electrode must be replaced by a copper electrode. As heat is applied, slightly more pressure is applied to the raised area.

In the method using heating by the oxy-acetylene torch, material shrinking is achieved by a combination of heat and mechanical working of the damaged area.



Des cript ion	Description
1	Overstretched area
2	Point heating using the oxy-acetylene torch
3	Spiral shaped knocking back with dolly

The repair area must always be accessible from both sides, so that the heated area can be properly worked mechanically.

The combination of heating and mechanical working is very effective.

As soon as the warm point is established, hammering is immediately started using the aluminum hammer together with a suitable dolly on the inside of the repair surface, working in spiral movements towards the warm point. This causes material to build up in the center of the warmed area.

## Lead loading

Despite good external panel beating techniques, it is not always possible to rectify every surface unevenness. For this reason, application of lead loading is an important part of panel beating.



CAUTION: Poisonous gases and dust can be produced when working solder. Use an

# extraction unit and, if required, a protective mask.

**NOTE:** Since 07/2003, lead compounds have been ruled out for production. Appropriate lead-free tin solders and pastes must also be used in the workshop.

Typical application areas:

- Body components with limited or no access from the rear.
- Body components with very narrow cross-section.
- Body components which are particularly exposed or which can move.
- Weld seams of partial repairs.
- Rocker panel areas, wheel arch edges, side panel areas.
- Doors, hood, luggage compartment lid.
- Swage lines and joint areas.

Tin has the following advantages:

- Excellent bonding on bare metal surfaces.
- Good moulding properties.
- Good properties for the production of shapes and contours.
- Permanent shape.
- Heat expansion is the same as steel.

To create a basis for the actual lead loading process, a lead loading paste is first applied to the panel. The paste is then heated and wiped away with a cloth. Now the tin can be applied and moulded with a brazing block.

After the repair site has cooled down, it is worked using for example the body plane until the surface is smooth and has no transitions.

## Paintless Dent Removal

**NOTE:** Basic and in-depth training is offered on the following topics. You will find an overview of the complete range listed in the Training brochure published by the Ford Service Organization.


#### General

Application is restricted to body surfaces which are accessible from both sides. This repair technique is seldom feasible on double-skinned body components or closed body profiles. The same applies to edge areas, swage lines and seams on body components, which are very dimensionally stable.

The following characteristics must be present for a dent to be removed:


- The diameter must be no more than 50 mm.
- No material stretching in the centre of the dent.
- Repair area must be accessible

Furthermore, sufficient experience in the use of special tools and knowledge of materials are also requirements for a successful repair.




Item	Description	
1	Deflection by a hook arrangement	
2	Pressure tool	

#### Mild dent



Satisfactory repair results are only possible on mild dents with little depth and small deformation radii. Therefore this repair method is particularly suitable for hail, parking and transportation damage.

#### Dent with material stretching



If strong and direct force during the damage process causes the material to stretch in the middle of a dent, then the result is a small and sharp edged dent. Such damage cannot be rectified without visible deformation.

Advantages of a planishing technique:

- · Economical in time and materials
- The original paint is retained
- Environmentally friendly (no sanding or painting work)

While carrying out the repair, the following itemized repair route and process flow must be complied with:

- 1. Damage diagnosis
- 2. Repair preparations
- 3. Perform repair
- 4. Paint finishing, corrosion protection and quality control

In order to ensure corrosion protection, all inner areas of the repair must be treated afterwards. Where it is possible, the paint is repaired. In every case the inner area of the repair must be treated with cavity wax.

## **Plastic Repairs**

## General

The proportion of plastics used in vehicle construction continues to rise. Up to now damaged plastic components often had to be replaced. These days, plastic repairs are becoming more and more widely accepted because of the increasing cost of spare parts.

**NOTE:** Plastic adhesives are chemical products and are subject to the safety instructions of the manufacturer.

In repair work, the material properties of plastics are highly significant. There are two main groups:

- · Thermoplastics.
- Thermosets.

**NOTE:** Elastomers make up a third group of plastics. These are not mentioned below because they have no plastics repair applications.

#### Thermoplastics

Heat causes thermoplastics (also called TP polymers) to transform from the solid state into the thermoelastic state and then into the thermoplastic state. When thermoplastics are cooled, they return to solid state.

Brief descrip- tion	Plastic
ABS	Acrylonitrile butadiene styrene copolymer
PA	Polyamide
PC	Polycarbonate
PP	Polypropylene
PP/EPDM	Polypropylene/ethylene propylene diene copolymer
PC/PBT	Polycarbonate/polybutylene tereph- thalate
Hard PVC / soft PVC	Polyvinylchloride

#### Thermosets

Thermosets (also called TS polymers) are much harder and more brittle than thermoplastics. Their strength remains largely unchanged when they are heated. Thermosets are destroyed when heated above the critical temperature. Also, the original state will no longer be restored on cooling.

Brief descrip- tion	Plastic
GRP	Glass reinforced plastic
PUR	Close-meshed cross-linked poly- urethane
PUR	Wide-meshed cross-linked poly- urethane

#### **Plastic identification**


Normally the appropriate identifier is marked on the plastic components used in vehicle construction.

The capital letter sequences used for this are standardized in DIN EN ISO 1043-1 and DIN ISO 1629 (for rubber) and can be looked up in the tables which they contain. In addition the string of characters provides information about the exact mixture ratio and the proportion of certain fillers.

#### Examples of the identification of plastics







**NOTE:** The identification of the type of plastic is necessary for the plastic welding process in order to determine the correct welding rod (welding material) to use.

If an identifier is missing or cannot be made out, the following easy to perform tests will help:

#### **Visual Inspection**

Visual inspections mainly serve to identify PUR and GRP materials. Thermoplastic components are often painted and are therefore difficult to identify.

Identification characteristics:

- When PUR cracks or similar damage occurs, pores of foam can be seen.
- GRP can be recognized by the glass fiber structure on the inside.

#### **Mechanical test:**

The plastic group can be determined by a sound test:

- Degree of hardness the higher-pitched the sound, the harder the plastic.
- Elasticity the more muffled the sound, the higher the elasticity of the plastic.

#### Sanding test

In this a place is chosen which will not be visible later, and the finger belt sander is used to sand the plastic.

The plastic group can be determined using the pattern of the dust:

- Thermosets produce a white dust.
- Thermoplastics smear and do not produce dust.

#### Float test in water:

Take a small piece of plastic from the component to be repaired and test whether it floats on water (PP-EPDM, HD-PE, PP) or sinks (PVC/U, PVC/P, ABC, PC).

#### Nature of the surface

The surface of plastics can be categorized as rigid (PVC-U, PVC-P) and waxy (PP/EPDM, HD/PE, PP).

#### Adherence test using welding rod

Heat a welding rod that is identified with the type of material and the plastic component using the hot air gun. Press the welding rod onto the plastic component to be welded. When the welding rod cools down, if it remains stuck to the component or can only be removed with great difficulty, then it can be assumed that the two are made of the same plastic. When pulling away from PP/EPDM, HD/PE and PP, this can lead to strings.

#### **Burning test**

Every plastic has a characteristic behavior and smell when burned. Using a knife, cut off a small piece from the component to be repaired, remove any dirt and paint residues and set light to the small chip. Now observe the burning behavior. Compare the color, type and smell of the smoke with the results from the following table.

Short descrip- tion	Plastic recognition using a burning test
ABS	Blackish smoke, the material drips like a candle when burning and smells like wax.
PA	No smoke, draws filaments, smells like burnt horn.

CAUTION: Danger of poisoning! When burned, most plastics release vapors harmful to health. Ventilate the room well and use respiratory protection. Where possible work using an extraction system.

Short descrip- tion	Plastic recognition using a burning test
PC	Yellowish, sooty smoke. Smells sweetish.
PP	No smoke, the material drips like a candle when burning and smells like burnt oil.
PP/EDM	No smoke, the material drips like a candle when burning and smells like burnt oil.
PC/PBT	Hard and shiny, burns yellow, fluffy soot.
Hard PVC / soft PVC	Blackish smoke and acrid smell.

### Safety instructions

In addition to the general safety instructions, the relevant regulations and accident prevention legislation must be observed.

**NOTE:** Without exception, before starting work you must read the safety and warning instructions in the chapter "Safety Instructions". In addition, pay attention to the warning instructions of the particular equipment manufacturer.

Information sheets, safety notices and guidelines for the processing of adhesives containing isocyanate, polyester resin, adhesives, solvent and thinners provide more details on their use.

The following instructions must always be followed:

- Polyester resin, adhesive, solvents and thinners are inflammable and must not be used near naked fire or flames.
- Sawing and grinding operations must only be carried out in rooms equipped with extraction systems.
- If no rooms with extraction systems are available, only use tools with extraction equipment.
- Protective equipment such as gloves, protective goggles, aprons and breathing masks are essential.

Because of the various compositions of plastics, repair work to plastic parts involves a variety of repair methods.

The following methods are used:

- Thermoplastic straightening.
- Plastic welding.
- Plastic adhesive bonding.
- Plastic lamination techniques.

### Thermoplastic straightening

Damage to thermoplastics can be rectified by heating using the hot air gun (temperature about 100°C) while the deformation is pressed out until the shape is regained.

### **Plastic welding**

Splits formed in plastic bumpers are typical possible plastic repairs.

**NOTE:** Do not carry out plastic welding in the area of fixed foam backing. The foam backing will usually be destroyed and the function of the component is then no longer guaranteed.

If repair using adhesive methods is not possible because of unfavorable conditions at the rear of the repair location, plastic welding is a possible repair process.

There are two methods of welding: hot air draw welding and hot air fanning welding.

### Plastic welding set



ltem	Description
1	Various welding rods
2	Scraper (heart-shaped)
3	Hot air blower (approx. 1500 W)
4	Clamps
5	Welding nozzles

In addition to the components listed, plastic welding requires tools already found in the workshop such as scrapers, sanders, face cutters etc.

As with all other welding processes, only certain material combinations can be joined together using plastic welding.

**NOTE:** Basic and in-depth training is offered on the following topics. You will find an overview of the complete range listed in the Training brochure published by the Ford Service Organization.

**NOTE:** The manufacturer's data must be taken into account when choosing welding materials and the correct temperature setting of the hot air gun.

Repair sequence during plastic welding:

- To prepare the location for welding, remove paint residues and sand the weld area.
- If parts of the material have been pushed in by an impact, the damaged area can be brought back to shape by heating.
- Drill out the ends of the split to stop it spreading further. Machine the location of the weld into a 90° V-shaped groove, to accept the welding rod.
- Lay the welding rod in the groove.
- Perform the welding. Hot air draw welding or hot air fanning welding.
- Rework the weld seam. After cooling, sand the raised weld seam.
- Clean the sanded repair surface using plastic cleaner. Apply plastic primer thinly to the repair surface and paint it.

Despite good preparation and the correct choice of welding materials, weld faults may occur.

The following points must be noted when welding plastic:

- Weld together like with like:
  - With very few exceptions, only the same materials can be welded together, e.g. PP with PP.
- Correct temperature:
  - The correct choice of temperature is important for the success of the repair. The plastic must be warmed until it plasticizes (dough-like, soft).

Guideline values for welding temperature:

Brief descrip- tion	Plastic	Temperat ure
ABS	Acrylonitrile butadiene styrene copolymer	360°
PA	Polyamide	400°

Brief descrip- tion	Plastic	Temperat ure
PC	Polycarbonate	370°
PP	Polypropylene	280°
PP/EPDM	Polypropylene/ethylene propylene diene copolymer	280°
PUR	Polyurethane	300°
Hard PVC	Polyvinylchloride	340°
Soft PVC	Polyvinylchloride	370°

· Even pressure:

- When rod welding, the pressure is applied by pressing on the welding rod.
- · Steady speed:
  - To achieve a good weld, care must be taken that the working speed is steady.

Possible causes of weld faults:

- Deformation caused by overheating of the repair area or tensions in the material while welding the component.
- Plastic material too thin.
- Poor weld joint because the weld temperature was too low or the welding speed was too fast.
- · Welding different materials together.
- Weld seam dropped because the split gap was too wide or the welding temperature was too high.

A good weld is recognized by a slightly raised, smooth and even weld bead on the surface of the component.

The weld bead must only be worked once it has fully cooled down.

### Plastic adhesive bonding

Adhesive bonding of plastics has some advantages over welding methods:

- Within the group of thermoelastic plastics, all semi-rigid ancillary components (such as bumpers, front grilles, etc.) can be repaired without identification.
- A two-component polyurethane based adhesive is used for all thermoplastic parts.
- Reinforcement strips can be attached behind splits (split length up to max. 100mm) and


openings to ensure the original strength properties.

Tools and equipment also familiar from paint repairs can be used in making adhesive repairs to thermoplastic components.

Angle grinders and belt sanders can be used to grind out scratches and splits. Orbital sanders with extractors are used for fine sanding.

The infrared heater is used to provide fast and certain drying throughout.

### Plastic adhesive set



ltem	Description
1	2-component adhesive
2	Cartridge gun
3	Mixing tube

Apart from the components shown, other materials may be needed to bond plastics, depending on the repair position.

For large scale repairs, it may be necessary to insert reinforcement panel strips and reinforcement matting as fixing aids.

Repair sequence during plastic adhesive bonding:

**NOTE:** Follow the manufacturer's guidelines when using adhesives.

- Prepare the location of the bond. Remove paint residues and sand the area to be bonded. Drill out the ends of the split to stop it spreading further. Prepare the bond location into a V-shape and clean it with plastic cleaner.
- Apply the adhesive. The two-component adhesive is applied to the cleaned and primed repair location using a hand gun. Spread and smooth the adhesive using a flexible plastic spatula.
- Rework the bond location. After cooling, sand the raised adhesive. Clean the sanded repair

surface using plastic cleaner. Apply plastic primer thinly to the repair surface. Apply paint.

### **GRP** repairs

GRP material is hard and brittle in its strength properties. Because of these material properties, splits and openings often result in cases of serious damage.

The stability of GRP parts is impaired if the glass fiber reinforcement is cracked. The component must be replaced in cases of serious damage that affect the structure.

Minor damage (such as abrasion, splits up to 80mm, holes up to approx. 60mm diameter, etc.) can be repaired to a technically and visually perfect standard, provided that the damage does not occur in heavily used or hard-to-reach areas.

To ensure perfect repair results, observe the following points:

- The room temperature should be at least 15°C and the air should be as dry as possible.
- The repair location must be thoroughly dry and clean.
- Before the repair, the GRP part being repaired must be dried using an infrared heater or in a drying oven.
- In cases of large splits and fractures, the strength of the outer skin can be re-established by backing with a reinforcement material.

Tools and equipment from the paint shop can be used to carry out repairs to GRP parts. Angle grinders and belt sanders can be used to grind out scratches and splits. Orbital sanders with extractors are used for fine sanding.

### **GRP** repair set



ltem	Description
1	Polyester resin
2	Glass fiber mats
3	Hardener

Scissors, paintbrush and cleaning materials are other materials which will be needed to perform a GRP repair.

**NOTE:** Follow the manufacturer's instructions when using the repair materials.

The repair process for a GRP repair is as follows:


- Prepare the repair location. Remove paint residues and sand the repair area.
- Drill out the ends of the split to stop it spreading further.
- The repair location must be sanded by hand. If machine working is attempted, the resin will be heated so much that the surface structure will be changed. The result is inadequate adhesion.
- Perform the GRP repair. Apply polyester resin thinly to the repair location. Lay the glass fiber mat in place and apply polyester resin over it again.
- Rework the location of the repair. Sand away any polyester resin which stands proud after it has hardened.
- Clean the sanded repair surface using plastic cleaner. Apply plastic primer thinly to the repair surface and after it has dried apply the paint finish.

### **Special Repair Techniques**

### **Cabriolet vehicles**

The body of a cabriolet vehicle is different to the self-supporting body of a saloon car because of

the special roof construction (folding top). The stability requirements must therefore be ensured by construction changes within the body structure.



These are for instance:

- Longitudinal and torsional reinforcing components which compensate for the lack of the roof.
- Reinforcements to the floor assembly, particularly in the rocker panel area.
- · Reinforcements in the pillar areas.
- High-strength and ultra-high-strength steel panels with single panel thicknesses of up to 2.5 mm, which in combination can become up to 6mm thick (e.g. reinforcements in the floor area, rocker panels).

If deformation to load carrying components occurs, the stability of the whole body shell can be adversely affected.

On a cabriolet, accident damage repair to the components mentioned above is considerably different in certain aspects compared with the usual repairs (closed body construction):

 A model specific alignment angle system must always be used during straightening and repair work, securing using clamps at the rocker panel area is not always adequate for the cabriolet.

- To avoid damage to the doors, they must always be open during straightening work. In the case of more severe damage, additional tension and compression spindles must be used to stabilize the door cut-outs (between the A- and B-pillars).
- In load bearing areas such as the rocker panels, side members and floor pan, increased straightening forces are necessary due to the additional reinforcements.
- NOTE: Additional information on welding can be found in the section Welding Equipment and Joining Techniques.

High-power welding equipment for panel thicknesses in overall combination of up to 6 mm total material thickness.

 The fitting accuracy and longitudinal rigidity of the affected component is especially important to ensure that the doors, door windows and the roof fit and close correctly.

### Liquefied gas vehicles

Alternative fuel vehicles often require special handling in the workshop area. Above all, assembly operations to some extent require particular

knowledge when dealing with the special technology and the safety regulations.

**NOTE:** Only fully trained personnel are permitted to work on alternative fuel vehicles.

These special requirements must be understood and taken into account in the body shop as well.

CAUTION: Danger of fire and explosion. The safety instructions must always be followed when performing service work on fuel/gas systems. Failure to follow these instructions may result in personal injury.

**NOTE:** You will find further information about working on liquefied gas vehicles in the section Health and Safety Information.

### **Refrigerated conversion vehicles**

Apart from the special materials used in building the structure of the refrigerated compartment, such vehicles have special energy and refrigeration systems which require special handling during repair.

# CAUTION: Danger of injury. Work on the 230<SP>volt system of the refrigeration equipment must only be carried out by trained specialist personnel.

**NOTE:** Work on the refrigerant circuit may only be performed by persons who have a relevant certificate of competence.

Vehicles with a refrigerated compartment are often used to transport foodstuffs. For this reason, additional hygiene regulations must be complied with during repair work.

Aluminum and plastic are used to construct the two different types of compartment found on refrigerated vehicles.

The aluminum conversion is a very stable and technically perfect variant. However, against this the relatively high production costs and a lower payload must be taken into account, because of the weight of the aluminum conversion itself.

**NOTE:** Basic and in-depth training is offered on the following topics. You will find an overview of the complete range listed in the Training brochure published by the Ford Service Organization.

The plastic conversion has developed into a light, clean and economical alternative because of constant further development of materials and working techniques. **NOTE:** The material combinations, the workmanship and the working methods must comply with the current food hygiene regulations. For this reason, service and repair work on the refrigerated conversion may only be performed by authorized and specially trained technicians.

Refrigerated compartment constructions are often made using both materials. The floor pan is made of structured, slip-proof aluminum panels and the wall and ceiling cladding is made of smooth surfaced plastic elements.

### CAUTION: PUR hard foam is flammable. If PUR hard foam is overheated, it will burn on its own with a brilliant yellowish flame. It produces unpleasant choking and toxic fumes. Special measures must be taken when welding the vehicle body.

Polyurethane wall and ceiling elements are manufactured using a sandwich principle. An insulating polyurethane core is coated with food grade ABS plastic on one side.

PUR hard foam does not decompose, is rot resistant and is odorless. These properties make it suitable for use as insulation.

Because of its closed cell structure, water uptake by PUR hard foam is for the most part only a problem at edges. Cut edges or other mechanically worked surfaces must however be sealed with the greatest care.

The conversion to a refrigerated vehicle is performed as made-to-order production. The large surfaces of the wall and ceiling cladding can be changed and are particularly easy to repair.

If access to the back of a body panel section is needed because of body straightening work, in some circumstances it is cheaper to perform a cut-out repair instead of removing an element.

The repair process is fully described in the Student Information booklet Refrigeration System Technology, Transit 2000.5 Freshline.

**NOTE:** You will find further information about working on vehicles with a refrigerated compartment in the section Health and Safety Information.

# Joining Techniques

### Welding

Before welding work is performed on a vehicle body, all safety measures for the protection of people, modules and electrical components must be observed.

**NOTE:** Before beginning the work, please refer to the safety instructions and warnings in the chapter Safety Instructions. Please also note the warnings of the respective equipment manufacturer.

Resistance spot welding and MIG welding are the most common techniques used in body construction. During repair work, the welded connection must be restored to be equivalent to the original.

### Resistance spot welding.

**NOTE:** Before starting the work, please refer to the chapter on safety instructions.



In doing so, the repair welds must match the standard of those produced in production in number and diameter.

Preconditions for resistance spot welding:

- The panels to be welded overlap.
- The weld spot is accessible on both sides for the electrodes.
- The shape and alignment of the weld electrodes is correct.
- The resistance welding equipment is powerful enough to be able to reproduce the production spot weld diameter.

**NOTE:** The welding equipment settings and the adjustment of the individual parameters are to be made in accordance with the device manufacturer's specifications.

Well-prepared welding flanges are a prerequisite for a problem-free welded joint. This means:

- The welding flanges must lie perfectly flat to one another.
- The welding flanges must be clean and free of oil or grease on both sides.
- Welding primer (zinc-coated and conductive) must be applied as corrosion prevention.

Only in limited cases can welding errors in resistance spot weld joints be detected from the outside . Therefore, a test weld should be carried out before each repair weld. The peel test carried out after the welding gives information on the quality of the welding. The spot weld must not flake off.

### **MIG** welding

Basically, three methods of MIG welding are used:

- Puddle weld.
- · Continuous bead welding
- Intermittent bead welding

Fields of application

- Any joins that are MIG welded in production must also be replaced by MIG welds.
- Puddle welding may be used in certain cases, if there is insufficient access.
- If the overall panel thickness is greater than 3 mm, without correspondingly powerful spot welding equipment, puddle welding should be used.
- When dealing with any MIG brazed joints which are present, follow the vehicle-specific repair instructions.

**NOTE:** The increased application of heat during MIG welding destroys the corrosion protection layers over a much larger area than during resistance spot welding. For this reason, greater care must be taken when applying the corrosion protection afterwards.

Welding repairs can only be carried out properly if the equipment is set up correctly and all welding-related preparations are complied with accurately.

- Please note the instructions of the respective welding equipment manufacturer.
- The hose assembly must be untwisted.
- The core must be free from particles of wire debris.
- The gas and current nozzles must be free of slag and scale residue.
- Pay attention to the quality of the welding wire and the gas flow rate.
- Ensure that the joint surface is perfect.
- Prepare a bare metal joint surface.
- Maintain the correct gaps (root formation).
- Produce a test weld.

### **Plug Weld**



Special features to note when puddle welding:

- The panels to be joined must lie perfectly flat to one another.
- The panel flanges must be treated with corrosion protection. The position of the weld must be bare.
- Prepare the holes depending on the thickness and number of the panels. The hole size should be 6-10 mm, or match the original weld spot.
- Start the welding procedure on the panel at the bottom so that the hole is filled completely.

### Continuous bead welding

A welded joint with a full seam is suitable for joining highly profiled body parts. Pillar and sill areas are typical application areas.




Special features to note during bead welding:

- Both parts of the panel must be bare on both sides over a width of 5 mm.
- Align the parts precisely with clamps.
- To prevent the panel from warping, tack longer joints before welding them.

### Intermittent bead welding


Intermittent bead welding is used when the connecting flanges are stepped. This form of seam is mainly used on the external panel area for sectional repairs.



Special features to note when intermittent bead welding:

- Weld gap.
- Spot weld interval.
- Apply alternate tack welding across the entire length of the seam. This keeps warping to a minimum.

### **MIG brazes**



E96577

Des cript ion	Description
1	Rear side member / wheelhouse reinforce- ment
2	Apron panel reinforcement / A-pillar

Metal Inert Gas (MIG) brazing is increasingly used in production for certain body areas. In areas where resistance spot welding is not possible due to limited space or higher strength requirements, MIG welding was previously used.

Increasingly, these MIG welded seams are being replaced by MIG brazes. The temperature range used during MIG brazing is significantly lower. This keeps the damage to the anti-corrosion zinc layer on zinc-coated panels to a minimum.

This results in the following advantages of the MIG brazed seam:

- No corrosion of the brazed seam.
- Low erosion of the zinc coating in the joining area.
- Low level of heating and thus little warping.
- Easy finishing of the brazed seam.
- Good for bridging gaps.


**NOTE:** MIG welds must not be carried out on or near existing MIG brazed seams as even the

smallest amount of brazing solder can result in a reduction in the strength of the weld seam.

MIG brazing requires a new generation of welding equipment and training in the technique.

### Joining techniques

### **Butt joints**



Des cript ion	Description
1	Join areas
2	Profile
3	Full seam

The butt joint is a joining technique frequently used in body repairs. The butt joint is typically used for repairs in the pillar and rocker panel area.

Areas that are suitable for the use of the butt joint:

- · short seam lengths.
- highly profiled structures.


The edges of the panels to be joined are placed against each other and are joined with a full seam in whilst maintaining a required welding gap (welding gap same as panel thickness).

**NOTE:** The butt joint requires a high degree of accuracy and care when trimming and cutting. For correct execution of the welding, an exact, even welding gap must be maintained.

Preparation of the joint areas includes:

- Sanding the connection areas bare on both sides.
- Removal of the zinc layer in the welding area.
- Carrying out welding tests on an equivalent sample panel before the actual welding, if necessary.
- Tack welding in the join area: From the edges to the centre, then check the shape.
- Joining new and old parts with a full seam weld.

### Joggled joint



Des cript ion	Description
1	Body part
2	Joggled area
3	New panel

The joggled joint variant is restricted to body areas with a good surface condition without beads/swage lines or profiles. A sectional replacement with a joggled joint is welded using a continuous seam. This procedure is used, for example, at the transition from the side panel to the rocker panel (3-door vehicles).


When cutting the new part, slight measuring tolerances are permitted, as these are covered by the joggled area.

Preparation of the joint areas includes:

- Sanding the connection areas bare on both sides.
- Removal of the zinc layer in the welding area.
- Preparation of a joggled strip.
- Carrying out welding tests on an equivalent sample panel before the actual welding, if necessary.
- Joining the new and old panel with continuous seam welding.
- · Lead loading the weld seam.

### Soft soldering

**NOTE:** The roof is secured to the side walls with laser soldered seams in production. When repairs are carried out, these laser-soldered seams must be replaced by soft-soldered seams.



WARNING: Poisonous gases and dust can be produced when working solder. Use an extraction unit and, if required, a protective mask. **NOTE:** Ford offers basic and in-depth training on the following topics.

**NOTE:** Areas for soft soldered joints require careful preparation. It is extremely important that the joint

WARNING: The roof repair may only be carried out in Ford-approved special workshops and only by specially trained personnel.

surfaces are exactly aligned and that a bare metal joint surface is prepared.

This means:

- Thorough cleaning of the surfaces to be brazed.
- Close contact of the panels at the brazing position.
- Use the soldering iron to warm the location of the seam to be joined.
- The liquid brazing material is drawn between the panels through capillary action.

### **Rivets**

With riveting, two or more panels are joined together using a joining element (rivet). In body construction, pop rivets and punched rivets are used.


Advantages of riveted connections:

- Metallic and non-metallic materials can be joined together.
- Different thicknesses of materials can be used.
- The material does not have to be heated, and therefore does not warp.
- Low level of preparation required.

**NOTE:** For detailed instructions on the procedure, please refer to the equipment manufacturer's operating manual.

Disadvantage:

• During dismantling procedures, swarf/rivet remains can fall into inaccessible cavities, which can lead to rattling and rusting.



Des cript ion	Description
1	Panels
2	Pop rivet

Pop rivets are used if only one side of the panel is accessible. In this process, overlapping panels are drilled and connected with a pop rivet.

Pop rivets can be inserted pneumatically, hydraulically or manually with rivet guns.

### Bonding



Des cript ion	Description
1	Butt joints
2	Bonded connection

Bonded connections are used more and more in modern body designs. Here, a distinction is made between bonds for stabilization purposes and bonds for adhesive strength. Bonds for stabilization purposes are found on clinched flanges and on cross beams in doors or on the roof.

WARNING: Risk of poisoning! Adhesive can be harmful to health. Ventilate rooms well and use breathing protection. Where possible, work with an extraction unit.

**NOTE:** Adhesives are chemical products and are subject to the safety regulations of the manufacturer.

Please refer to the specifications in the general part of the particular manual for information on the repair adhesive which is to be used.

Advantages of glued joints:

- They are air and watertight.
- High corrosion protection
- · Different materials can be connected.
- Bonding can be combined with resistance spot welding.

**NOTE:** The quality of the bonded connection is largely dependent on the care taken during preparatory work. When gluing bodywork parts, follow the work instructions from the adhesive manufacturer.

### Bonding and welding

On some vehicle models, (such as the Ford Ka), bonding is combined with resistance spot welding. This connection technique has the following advantages:

- Tight, anti-corrosion connection seam.
- High strength due to additional resistance weld spots.

Please note the following points during the repair work:

- Only use adhesive suitable for welding (conductive).
- Carry out resistance spot welding on the connection flanges before the adhesive hardening process.
- Carry out test welding with the adhesive applied.
- If MIG welding is carried out during a sectional repair on a connection flange with adhesive material, the adhesive material must be applied at a distance of approx. 10 mm from the weld spot.

### **Bonding and riveting**

As with welding, bonding can also be combined with riveting. This connection technique has additional advantages. These are:

- Metallic and non-metallic materials can be joined together.
- Different thicknesses of materials can be used.

- The material does not have to be heated, and therefore does not warp.
- The rivet connection stabilizes the connected components during the adhesive hardening phase.

# Impact of Insufficient Repair Quality

Body repairs usually require a significant level of intervention in the existing body shell structure. The corrosion protection, seals and NVH components are destroyed and must be replaced.

To prevent the vehicle quality from being reduced due to a poor quality repair, all repairs carried out in all repair sections must be inspected during and after the accident repair.

Simply checking the vehicle at the time of delivery is not sufficient to guarantee the repair quality. Rather, continuous checking of the work carried out is recommended.

**NOTE:** Logs of the acceptance of individual operations are a useful tool for quality assurance. A comprehensive final inspection can be carried out based on a final acceptance log.

In the process, the entire repair sequence must be split into meaningful sections, with the creation of check points to which particular attention must be paid.

The following are some possible sections:

- During and after body work.
- Final assembly, ancillary components, functional tests.
- · Vehicle delivery.

**NOTE:** The following points offer an indication of possible test logs. They can be combined and supplemented differently, depending on the individual operating procedures.

# During and after body work the following areas should be checked:

After completion of the body repairs, the following areas should be checked:

- Manufacturing inspection for functionality and originality in the accident area.
- Check snug fitting of metal panel parts (welding and screw connections).
- Check snug fitting of ancillary components (doors, hoods, glazing).
- Check surface condition of the welded seams.
- Check seals, blanking plugs, NVH components.
- Check corrosion prevention measures
- Check that the repair work is in the correct condition for painting.

# Final assembly, ancillary components, functional tests

After final assembly, not only a visual inspection is required, but also the functionality of many components must be checked:

- Check repair area for originality.
- Check ancillary components for correct installation.
- Check precision fitting of all parts.
- Check that the doors and flaps are working correctly.
- Check that all mechanical parts, such as the window winder are working correctly.
- Check for leaks in the repair area.

### Vehicle delivery

Vehicle delivery again offers the opportunity of checking the repair quality. In the process, the following points are to be checked again:

- Corrosion protection, sound damping matting and rubber seals.
- Check for traces of leftover paint.
- Check the cleanliness of the vehicle.
- Functional check of the mechanical and electrical components.
- Road test the vehicle.
- Check for noise, vibration and harshness (NVH).
- Check for wind noises.

After repair work on the body and vehicle, not only the visual restoration of the damaged vehicle, but also the functional restoration must be guaranteed.

Customers are making increasingly high demands of vehicles, particularly in terms of driving comfort. Customers find noise, vibrations and harshness (NVH) as well as squeaking and rattling annoying, particularly after repair work. It is therefore important that the condition of the vehicle at the time of production be restored after an accident repair.

After body repairs, the entire repair area must be checked for any water leaks. It is crucial that a leak test be carried out as part of the final inspection so that water leaks can be detected and eliminated even before delivery of the vehicle to the customer.

The requirements of the vehicle manufacturer are to be taken into consideration during all inspections. Only in this way can it be guaranteed

that the vehicle quality is not reduced through insufficient repair quality.

### Water Leaks

Water leaks can occur after body repair work, but can also occur on new vehicles. The test methods described below allow the various causes to be identified. In all cases, a systematic and logical procedure is required to locate water leaks.

### General

When searching for faults, it must be taken into account that water can enter the vehicle passenger compartment in various ways and circumstances. Therefore, it is sometimes not sufficient to perform a water test on a stationary vehicle.

Before beginning extensive checks, a thorough visual inspection must be carried out. The following points are to be taken into account in the process:

- Check the clearance and accurate fit of ancillary components such as the trunk lid and doors.
- Check for correct installation and possible damage to sealing elements such as blanking plugs, seals and rubber door seals.
- Check that the water runoff openings and pipes are free of obstructions


### Test method

### Water test

**NOTE:** Do not use a power washer. Use a normal garden hose with a spray nozzle or sprinkler head. Make certain that all windows and doors are completely closed.

Water leaks into the vehicle passenger compartment cannot usually be located immediately, as the water often spreads across a large area. For this reason, the passenger compartment must be dried before the leak tests. Any ancillary components that block the view must be removed. During the water test, the vehicle is sprayed or sprinkled with water at the suspected location of the leak. At the same time, a second person checks the passenger compartment for places where water enters the vehicle. Depending on the test and the vehicle, it may take some time before there is any sign of water entering the vehicle. We recommend laying blotting paper under the location being tested so that the water entry can be localized.

Example: Water test with sprinkler head (rain test)



### Car wash test

Certain leak problems only appear in a car wash or can only be simulated there. The concerned area of the passenger compartment should be inspected with a torch during the wash procedure.

### **Road Test**

Some leaks only appear when the vehicle is moving. If no leaks are detected during the above-mentioned tests, road tests should be carried out on wet roads:

- · At various speeds.
- On various road surfaces (asphalt to cobbles).
- · With loaded or unloaded vehicle.
- Driving through puddles (splash water).

### Test with UV lamp

A leak test can also be performed using a UV lamp and a special contrasting agent. The advantages of using contrast agent are:

- No need to dry out wet areas beforehand.
- The water entry and its subsequent path can be seen more clearly.
- No need to remove most ancillary components from the vehicle.

**NOTE:** The equipment manufacturer's instructions must be followed when using a UV lamp and contrast agent.

Procedure for using a UV lamp.

- Wet the test area with clear water from the outside.
- Prepare test liquid and apply it from the outside using a suitable water sprayer.
- Illuminate the relevant area from the inside using the UV lamp. The test liquid which enters will make the leak visible.

### Chalk/powder test

This test checks the contact surfaces of seals on doors, hatches and lids.


Process using a door seal as an example:

To do this, the door seal is coated with powder or brushed with chalk. A thin layer of grease is applied to the contact area of the seal. The door must then be slowly closed and reopened. The width and continuity of the imprint can now be checked on the seal.

Flow checking device

### **DESCRIPTION AND OPERATION**

### Smoke test



Des cript ion	Description
1	Test pipe
2	Test pipe opener
3	Puffer ball

### **Operating principle**

The flow checking device is a set made up of a flow-testing pipe, a test pipe opener, puffer ball and closing-off caps for the pipe.

The test pipe contains a filling layer which is impregnated with fuming sulfuric acid. When air is blown through the pipe by the puffer ball, sulfuric acid is emitted as an aerosol in the form of a white smoke.

**NOTE:** Pay attention to the instructions for use and the safety directions issued by the manufacturer. The smoke test can only be performed in a draft-free environment.

This test can be used to detect leaks visually. Procedure:

- Break off both tips of the pipe in the pipe opener, in exceptional cases in the top of the packaging.
- Insert the pipe into the puffer ball so there are no leaks.
- Close the hole in the puffer ball with your thumb and press the air contained in the ball through the pipe.
- Set the ventilation blower in the passenger compartment to the highest setting.


# 3

- Close all doors so that a slight overpressure can build up in the passenger compartment.
- Move the smoke pipe along the outside of the body to the areas to be checked.
- Leaks can be detected through the irregular movement of the smoke.

### Stethoscope test

This procedure is very similar to the smoke test. Instead of the smoke pipe, move a stethoscope past the areas of the body that are at risk. Leaks can now be detected acoustically.

### Stethoscope




### **Ultrasonic detection**

This test uses ultrasonic waves to locate the positions of leaks. When an ultrasonic transmitter is placed inside the vehicle, it sends out ultrasonic waves. A leak is located by running a detector along the suspected area. The position with the loudest reception of the escaping ultrasonic waves is the location of the leak.

Procedure:

- Place the ultrasonic transmitter in the vehicle.
- Completely close the vehicle.
- Search the exterior of the vehicle using the detector.
- The detector provides a simple indication of a leak.

### **Ultrasonic test device**



### Workflow for tracing water entry

Sta ge	Testing	Res ult	Action
1st	Ask customer for a detailed list of possible reasons for the water entry. Does this information allow the cause of the leak to be identi- fied?	Yes	Dry out the vehicle and repair the damage. Perform a water test as a check (see test method).

Sta ge	Testing	Res ult	Action
		No	Step 2.
2nd	Perform an initial visual inspection on the vehicle. Look for signs of water entry. Can the cause of the leak be identified immediately?	Yes	Dry out vehicle. Repair damage. Perform a water test as a check (see test method).
		No	Step 3.
3rd	Is it possible that water is getting into the vehicle through a seal (door seal, trunk lid seal)?		Check the seal for damage. Check the creation of the seal using the chalk test (see test methods). Step 4.
		No	Step 5.
4th	Is the contact area for the seal adequate?	Yes	Step 5.
		No	Perform work as described under Areas with possible water leaks - Door seals. Dry out vehicle. Repair damage. Perform a water test as a check (see test method).
5th	Before starting any further work, use the VIN to look for model- specific informa- tion in eTIS. Perform Oasis query and check TSIs. Does this information allow the cause of the leak to be identi- fied?	Yes	Dry out vehicle. Repair the damage using the information found. Perform a water test as a check (see test method).
		No	Step 6.

Sta ge	Testing	Res ult	Action
6th	Establish the extent of the damage. To do this, expose wet areas. Remove parts. Investigate the suspected area for signs of water. Does an investigation of the suspected area allow the cause of the leak to be identified?	Yes	Dry out vehicle. Repair leak. Perform a water test as a check (see test method).
		No	Step 7.
7th	Check exterior areas (seals, seal welds). Check interior areas: Signs of water, plugs, seal welds. Can the cause of the leak be identi- fied?	Yes	Dry out vehicle. Repair leak. Perform a water test as a check (see test method).
		No	Step 8.
8th	Perform water test or ultra- sound test. Can the cause of the leak be found?	Yes	Dry out vehicle. Repair leak. Perform a water test as a check (see test method).
		No	The water entry may only occur under dynamic driving condi- tions. This requires intensive tests to be repeated with the corres- ponding climatic influences (rain).

# Possible complaints and corrective actions


**NOTE:** Water leaks and changed vehicle acoustics can have similar causes. For this reason, information from the Wind noise or Noise,

vibrations, roughness chapters may be useful in identifying the fault.

An outline of the possible complaints due to water leaks is provided below. The causes of water leaks and the possible remedies are presented using selected examples. They are intended to provide troubleshooting tips and suggestions for the user but do not represent an exhaustive faults list.

### **Glued windows**

A broken pasted seam can cause water to enter around the window. A broken pasted seam can be located using a water test or by carefully blowing compressed air onto the inside of the window seal.




### **Corrective action**

Broken adhesive seams **-Arrow-** can be sealed from inside using PU glass adhesive.

If this seal does not resolve the problem or the broken pasted seam is too extensive, it is necessary to remove the window and glue it back into place.

### Door seals

If water appears at the bottom of the door, it is possible that the door seal behind the door trim is damaged. If the door is intact, water can enter through the window weatherstrip and flow out through gaps on the underside of the door. If the door seal adhesion is faulty or the door seal is damaged, water can get into the interior.



Des cript ion	Description
1	Seal/adhesion
2	Clips
3	Door speaker

# Fastening bolts could be loose or clips incorrectly positioned on door modules.

### **Corrective action**


Depending on the door seals used, different sealing methods can be used.

**NOTE:** The drainage holes on the underside of the door may not be blocked - if they are, clean them. Defective films and foam seals must be replaced.

Once the adhesive surfaces have been cleaned, plastic films must be stuck with double-sided adhesive tape or replaced.

Leaky foam seals are sealed with Butyl tape or replaced.

Plastic door modules are fitted with a weatherstrip, which cannot be replaced. Seal the leaky point with Butyl tape or replace the part.



Leaks can be caused by badly fitted seals. In particular, areas with radii **-Arrow-** must be thoroughly checked.

Door seals can develop leaks due to:

- Damaged or expanded seals.
- Ageing.
- Insufficient contact pressure.
- Inadequate contact area for seal on body part.
- Uneven welded flange thickness because of several layers of body panels or production tolerances.
- Kinks.


The contact pressure of a seal can be determined using a strip of paper. If a strip of paper trapped in the closed door can be pulled out easily, the contact pressure is too low.

### To resolve

# Door weatherstrip

- Replace damaged or aged seals. Prevent kinks.
- The contact pressure can be changed by adjusting the catch bolt or correcting the panel flange.
- Even out the uneven welded flange thicknesses. Properly repair any paint damage that occurs. If the bodywork flanges are very uneven, appropriate alignment work must be performed. Pay particular attention here to the new corrosion protection which needs to be applied afterwards.
- If water entry is caused by a spot weld (burr on the surface), this must be rectified and appropriate corrosion protection applied.

### Tailgate sealing rubber




Leaks at the tailgate rubber seal have the same causes and remedial measures as for door rubber seals. Especially vulnerable areas -arrows- must be thoroughly checked.

### Rubber grommets / plugs

Rubber grommets or plugs are fitted at numerous points on the body. They are frequently used as seals for cables, hoses or actuating links. Rubber plugs are frequently used for gaps caused during production.

# Example: Possible problem locations in the tailgate area



Des cript ion	Description
1	Hinge seal
2	Cable duct

Leaks can be caused by badly fitted or damaged rubber grommets and plugs.

Damaged cable insulation can also cause leaks.


Where components are bolted on, water can enter if there are inadequate seals at the connection point.

### To resolve

- Correctly fit rubber grommets / plugs. During fitting, ensure that the sealing lips are not trapped and are applied properly.
- The contact area of the rubber grommets / plugs can also be sealed with PU sealing compound.
- Replace the damaged rubber grommets and repair the damaged cable insulation.
- Smooth the panel deformations in the contact area of the plugs.

### Heater housing/ventilation

Loose butyl sealing strips, damaged sealing surfaces or a trapped carpet can cause leaks around the heater housing / ventilation **Arrow**. Badly positioned or badly fitted hoses can also be responsible for water entry. Water drains must not be blocked




**NOTE:** A large quantity of water flows through the water tank. If there are leaks in this area, it is essential to ensure that the water drainage mechanisms function correctly. Drainage openings may not be blocked or stuck. Leaves and other dirt must be removed before troubleshooting.

### **Corrective action**

Before the actual repair, make sure that the water drains are not blocked or stuck.

Remove the heater housing / ventilation and fit a new Butyl sealing strip. Damaged sealing surfaces must first be adjusted. A trapped carpet must be removed.

### Seal welds



PU sealing beads are applied to welded or riveted connections **Arrows** to seal the interior of the vehicle. Incorrectly applied or damaged seal welds can allow moisture to penetrate into the interior of the vehicle. It is also possible that sealing beads whose shape and size appear to be intact actually have poor adhesion.

### **Corrective action**

Incomplete seal welds must be supplemented with PU sealing compound. Damaged seal welds must


be removed and re-applied properly. Make sure that any residual moisture is effectively removed before a new seal is applied.

### Attached parts

The add-on parts include:

- Exterior mirros, handles, controls.
- Mouldings, roof mouldings, lettering.
- Roof aerial, roof rack or connections for roof rack systems.
- Bumper mountings.
- Injection nozzles, door contact switches, bump stop rubber.
- · Control unit seals.
- Tail lamps.
- All kind of screwed connections (pedal block, door and tailgate hinges)

# Example: Possible water entry points at the rear lamp



Des cript ion	Description
1	Clips
2	Gaskets.
3	Rubber grommet

Add-on body parts must be fitted with seals, grommets or sealing compound to prevent water entry. However, even when a sealing system is fitted, the screw thread may still cause leaks.

### **Corrective action**

Seals must be tested and, if necessary, replaced. Check contact surface and adjust if necessary. Points sealed with sealing compound must be thoroughly cleaned and the seal replaced. Check grommets and replace if necessary. At all screwed connections, seal the thread with an appropriate sealing material.

## Wind Noise

Wind noises as well as other general noises are dealt with under Noise, Vibration and Harshness (NVH).


**NOTE:** Basic and in-depth training is offered on the following topics. You will find an overview of the complete range of courses in the Training Brochure issued by the Ford Service Organization.

Due to the continuous reduction in drivetrain noises, wind noises have come to the fore in the vehicle and are perceived to a greater extent by the customer. There are various causes of wind noises. They can be due to the design of the vehicle, or they can occur after a repair. They are mostly caused by poorly mounted components, which must be located and installed in the correct position.

### **General information**

In order to carry out targeted diagnosis, it is important to know the basics of noise formation and sound transmission.

### Potential areas of wind noises



ltem	Description			
1	Wiper arms			
2	Windscreen seal			
3	Antenna/antenna base			
4	Sun roof/roof rail			
5	Tailgate			
6	Door handles			
7	Exterior Rear View Mirror			

ltem	Description		
8	Door seals		
9	Headlamps		
10	Radiator grille.		

Noises are categorized according to their type and formation as follows:

### "Normal" air flow noises:

Normal air flow noises are caused by air blowing against even, flat vehicle surfaces, such as the

roof, doors and side windows. When the vehicle is moving fast, air layers (turbulence) form, which cause variations in air pressure. These variations in air pressure spread in the form of sound waves and are transferred to the vehicle interior via the side windows and seals.

# Noises caused by deviations in air flow and circulation around separate components:

If air flows over an edge on a vehicle, the air flow cannot follow the shape of the surface, but separates at the edge. Eddies are formed, which collapse again after a certain time or distance. The associated fluctuations in air pressure create a corresponding sound wave which is noticeable by for instance a rushing noise at the A-pillar or the outside mirror.

Turbulence and the associated radiation of noise can also occur at the vehicle underbody. Air circulation around small components and also flow through small gaps (e.g. the radiator grille) cause the rushing noise to change to a whistling, which rises and becomes louder as the vehicle speed increases.

### Noises caused by vibrating seals:

Seals which do not make firm contact at the door or window area can be made to vibrate by pressure variations outside the vehicle, which in turn mean noise radiating into the interior of the vehicle.

### Noises caused by air flowing out:

Noises caused by air flowing out are created by leaks at the vehicle interior sealing system, when stationary air mixes with flowing air. As a result, the noise increases as the speed of the air flowing out increases. Example: Letting air out of a tire.

### Cavity noises:

Cavity noises are those created when the air volumes found in bodywork cavities are caused to vibrate by an opening located in the airflow. The frequency of the tone does not vary with the vehicle speed but depends on the volume of the cavity and the size of the opening. Example: Blowing across the top of a bottle.

### Wind noises overview:

### Workshop diagnosis

Assessm ent	Type of wind noises	Place of origin
Normal	"Normal" wind noises	Roof, side windows
Normal	Noises caused partly by changes in the direction of air flow and by air flow around separate components	A-pillars, outside mirrors, antennas
Serious	Noises caused by vibrating seals	Door gaps too large, door/ window seals not making firm contact
Serious	Air escape and air passage noises	Leaks in the bodywork/ sealing system
Serious	Cavity noises	Unsealed body- work cavities

Those noises listed under "Serious" indicate a possible source of the fault.

### Workshop diagnosis

There are two ways that the level of noise in the vehicle interior can be reduced and the character of the noise can be improved through assessment and diagnosis in the service department:

- Reducing the intensity of the noise sources.
- Reducing the noise transfer routes.

Before carrying out repair work, a visual inspection of the vehicle must be carried out. The gaps in the doors, the sunroof and at all other body parts must be checked in particular.

When the doors are adjusted to fit exactly, development of wind noises at high speeds can often be eliminated (lifting of doors off the seals). Furthermore, the following points should be noted:

- The windows and doors must be fully closed.
- The air guides and air grilles must be correctly seated.
- All of the trim strips and plastic components must be firmly fixed down without gaps.
- All blanking plugs present.

### **Test method**

The test procedures given in the chapter Noise, Vibration and Harshness can also be used to diagnose wind noises.

### **Road tests**

Wind noises can usually only be localized by road tests

**NOTE:** There should always be two people present during road tests to find noises. A driver who reconstructs the situation causing the noise, and a person to carry out the checks.

The following points should be taken into account for such road tests:

- Check that the tire pressure is correct.
- Remove non-standard ancillary components from the vehicle.
- Choose a dry, flat road with as little traffic as possible.

- Carry out the road test in all speed ranges. Use a high gear so that the engine noise is low.
- Do not perform a road test near any sound reflecting objects.

If it is difficult to detect the noise sources, the search can be made easier by masking potential areas.

### Chalk/powder test


This test checks the contact surfaces of seals on doors, hatches and lids.

Process using a door seal as an example:

To do this, the door seal is coated with powder or brushed with chalk. A thin layer of grease is applied to the surface against which the seal makes contact. The door must then be slowly closed and reopened. The width and continuity of the imprint can now be checked on the seal.

### Smoke test

### Flow checking device




Item	Description		
1	Test pipe		
2	Test pipe opener		
3	Puffer ball		

Mode of operation:

The flow checking device is a set made up of a flow-testing pipe, a test pipe opener, puffer ball and closing-off caps for the pipe.

The test pipe contains a filling layer which is impregnated with fuming sulfuric acid. When air is blown through the pipe by the puffer ball, sulfuric



acid aerosol is emitted in the form of a white smoke.

**NOTE:** Pay attention to the instructions for use and the safety directions issued by the manufacturer. The smoke test can only be performed in a draft-free environment.

This test can be used to detect leaks visually.

Procedure:


- Break off both tips of the pipe in the pipe opener, in exceptional cases in the top of the packaging.
- Insert the pipe into the puffer ball so there are no leaks.

- Close the hole in the puffer ball with your thumb and press the air contained in the ball through the pipe.
- Set the ventilation blower in the passenger compartment to the highest setting.
- Close all doors so that a slight overpressure can build up in the passenger compartment.
- Move the smoke pipe along the outside of the body to the areas to be checked. Leaks can be detected through the irregular movement of the smoke.

### **Ultrasonic test**

This test searches for leaks in the system of seals or rather acoustic bridges. When an ultrasonic transmitter is placed inside the vehicle, it sends out ultrasonic waves. A leak is located by running a detector along the suspected area. The position with the loudest reception of the escaping ultrasonic waves indicates places where noises occur.

### Ultrasonic test device




### Procedure:

- Place the ultrasonic transmitter in the vehicle.
- Completely close the vehicle.
- Search the exterior of the vehicle using the detector.
- The detector provides a simple indication of a leak.

### Stethoscope test

### Stethoscope



### Diagnosis

Wind noises often have similar causes as the general NVH noises. For instance, a windshield which is incorrectly bonded in position can cause normal driving noises to become more noticeable.

Asking the customer detailed questions and a road test together with the customer are the requirements for a targeted diagnosis.

**NOTE:** Take the customer concern seriously. But do not confirm that a noise is a problem until you are sure that it is something which is not normal for the vehicle series.

Possible questions:

- · How long has the noise been there?
- · Has any work been done on the vehicle?
- · Where does the noise come from?
- In which driving situation does the noise appear?
- Is there any special situation in which the noise appears?

Remember that a noise is often more or less noticeable depending on where you are sitting in the vehicle.

Sta ge	to test	Res ult	Reference or Action		Sta ge	to test	Res ult	Reference or Action
1st	Road test the vehicle with the customer. First let the customer drive to demon- strate the noise, before you drive the vehicle your- self. Check that the concern is justified. Is this a noise which gives cause for concern?	Yes	Step 2.	-	3rd	Before starting any further work, use the VIN to look for model- specific informa- tion in eTIS. Perform Oasis query and check TSBs. Can a cause for the noise be determ- ined based on the information available?	Yes	Take the action specified in the Oasis or TSB information. Check whether the measures have been successful.
		No	Explain the noise				No	Step 4.
			and tell the customer what is causing it. Possibly offer a comparable vehicle for a road test.		4th	Localize the noise. In doing so, check whether it is an unusual noise or if it is a usual driving noise that	Yes	Step 5.
2nd	Visually inspect the vehicle. Look for loose, damaged or missing compon-	Yes	Eliminate the noise or carry out a repair as the case may be. Check whether			is more notice- able because of inadequate sealing. Is it an unusual noise?		
	ents. Check that the vehicle is to		the measures have been				No	Step 7.
	standard produc- tion series specification. In particular, check for any after- market compon- ents which may have been		successful.		5th	Determine the source of the noise. Can the cause be determined?	Yes	Eliminate the noise or carry out a repair as the case may be. Check whether the measures have been successful.
	installed. Depending on						No	Step 6.
	the type of noise, check the suspected area. Could a cause of the noise be found?	No	Step 3.		6th	Determine the path of the noise using the stetho- scope. By way of a trial, mask the suspected area or components	Yes	Eliminate the noise or carry out a repair as the case may be. Check whether the measures have been
L			0.000 0.			or remove them. Can the cause be determined?		successful.
				ŀ		i	i	1

Step 7.

No

Sta ge	to test	Res ult	Reference or Action
7th	Check the vehicle for inad- equate or damaged seals. The sealing of a vehicle can be checked using the stethoscope, the powder test, the smoke test and the ultra- sonic detector. (See under test method.) Could a leak be detected?	Yes	Renew the seal or perform the appropriate repair as neces- sary. Check whether the measures have been successful.
		No	Step 8.
8th	Under certain circumstances there may be a constructional problem which is not yet known about. Record the problem in an Express Service Report and send it on by the usual method.		

# Possible concerns with corrective measures


**NOTE:** Instructions on general noise are summarized separately in the Noise, Vibration and Harshness section. These can be useful when searching for the causes of wind noises.

There follows an outline of the possible concerns relating to wind noises. Selected examples are given showing the causes of wind noises and the ways in which they can be eliminated. They are intended to provide troubleshooting tips and suggestions for the user but do not represent an exhaustive faults list. The topics are subdivided by the different groups of components.

The test procedures described in the Noise, Vibration and Harshness section can be used when troubleshooting.

### Seals

In general, seals are very important when eliminating wind noises. Special attention should always be paid here to the possible causes of wind noises.




Take the following points into account:

- Seals age, i.e. they become porous and with time they lose their original elasticity. If the vehicle is relatively old and there are already visible signs of distortion or damage to a seal, then it should be replaced.
- At high speeds the doors or hatches may lift slightly from the seal surfaces because of variations in air pressure. Wind noises are caused when the preload on the sealing surface is not sufficient. The preload depends on the installation position of the components, the elasticity of the seal and the location of the sealing flange.
- The contact surface of the seal must be sufficient. This can be checked using the chalk test. If the specifed width of the contact surface is not known, you must determine it on another component of identical construction.
- A bulging seal carrier indicates that the sheet metal of the retaining flange is uneven.

- Seals must be correctly installed. Special attention must be paid at corners **-arrow-** that the installation follows the contours.
- The seal must not show any kinks or folds or any other damage.
- Seals must seal all around their circumference. Gaps in seals result in openings which lead to an increased incidence of noise. In this respect, it is especially important to pay attention to the seals in the area of the windows.

### **Remedial Action**

Renew older seals which no longer have adequate preload. Deformed or widened retaining flanges must be reworked and provided with a new seal.




The corner areas **-arrow-** of a seal must be properly seated. In some circumstances, a butyl sealing strip must be affixed to support the sealing at a corner.

### **Bonded joints**

Glass is usually installed today using a bonded joint. Gaps in the bonded joint can lead to noises in the vehicle interior. If there are noises which are believed to be associated with window glass, the following points should be checked:

Gap in window bonding



- The window must be bonded without any gaps **-arrow-**. Leaks can be found using the ultrasonic tester or compressed air carefully blown from inside onto the window glass bonding.
- The installed position of the window glass must be correct. It must not have been bonded into a position which is too low or offset to one side.
- The sealing or trim strips must fit tightly and the glass must be mounted so that it is fully enclosed. If a sealing or trim strip has not been applied with enough pressure, high air speeds can cause it to lift up. This can lead to wind noises at higher speeds. Apply masking tape to these areas for test purposes.

### **Corrective measures**

Leaking areas of the window glass bonding material can be sealed using PU sealing compound. Pay special attention at the front windshield, that any breaks in the bonding are not too large. Otherwise the glass must be removed and bonded in place again.


The installed location of a window glass cannot be corrected. It must be removed and bonded into place again.

Replace the trim strips or secure the lip seal using PU adhesive.

### Gaps, edges

Door gaps and edges are places where air turbulence can form. This causes noises which can be perceived as troublesome.

### Gaps and edges - problem areas



Doors, hood and tailgate can cause wind noises because of gaps **-arrow-** which are too large. If the components are not installed flush to the bodywork or the neighboring component, air break edges can arise, which in turn can create a wind noise.

The sun roof may be the cause of whistling noises in the roof area. The sun roof may be incorrectly adjusted or the seal on the sun roof may be damaged.


Noises from the door area could come from a window which does not fully close. Side guides (seals) can also be the cause of wind noises.

The covers of window frames can be incorrectly mounted or aligned. The quarter-lights in doors must also be checked for correct installation.

### **Corrective measures**

Check the gaps and adjust them according to the specifications. If there are problems at the sun roof, correct the adjustment and if necessary replace the seals.

### Problem area at side windows



Side windows which do not fully shut **-arrows-** must be adjusted. If the vehicle is equipped with electric window regulators, the remedy may be to perform the window regulator learning process again. In all cases, make certain that the glass enters far enough into the seal.

### **Ancillary Components**

Components installed on the bodywork may cause noises when they are not correctly mounted.


When troubleshooting it may be helpful to remove the suspected component or, when this is not possible, to mask it off with suitable covering tape.

### Roof moldings, roof rail, roof antennas

Moldings and roof moldings must touch the bodywork along their whole length without any gap. Check the end sections in particular. These must neither have any splits nor stand away from the bodywork. Noises may come from the roof rail if the seal between it and the roof is not correctly installed or is cracked. Gaps at the mounting grooves of the carrier can also create wind noises.

The roof antenna and antenna foot seal must be correctly secured. The seal must lie completely on the roof and must not be damaged.

Roof moldings mounting



If the original mounting points of the roof moldings are in good condition, the fixing can be improved using silicone sealant -arrow- if necessary. Align or renew the seals of the roof rail. Reduce the clearances of the mounting grooves.


### **Corrective measures**

If the original mounting points of the roof moldings are in good condition, the fixing can be improved if necessary using silicone sealant **-arrow-**.

### **Exterior mirrors**

Exterior mirrors or covers of exterior mirrors which are not correctly mounted cause noises. The cover must lie evenly on the component and must not lift during driving. There are ducts present on the doors for the electrical or mechanical adjusters for the exterior mirrors. If there are leaks, wind noises will be caused. Holes can also be present at the transition to other components.

Exterior mirror seals



There are ducts present on the doors for the electrical or mechanical adjusters for the exterior mirrors. If there are leaks, wind noises will be caused. Holes can also be present at the transition to other components.

### **Remedial Action**

If there is inadequate sealing of the foam seals **-2**they must be replaced or supplemented with suitable material. Transitions to other components can be sealed with butyl sealing compound **-1**-.

# Moldings, covers, door handles, windshield wiper arms

Moldings and covers especially tend to cause wind noises because of their location. These components interrupt smooth bodywork surfaces and air turbulence therefore arises at the edges. If there are noise concerns in the area of the doors, check especially for gaps and projections. Moldings must not stand away from the bodywork or the door. There must not be any gaps or discontinuities at the location of joints.


Incorrectly adjusted windshield wiper arms can cause wind noises. Especially if they are too far over the glass surface when in the rest position.

Wind noises in the transition area between the air cowl cover and the wing or the windshield can be caused by an incorrectly installed air cowl cover. At high air speeds the air cowl cover may lift and noises will then occur.


Because of their necessary mechanical features, door handles have a range of openings and edges which allow noise to be generated. The door handle can be masked off for testing purposes. If a reduction in wind noises is noticed, inadequate sealing may be the reason for the noises.

### **Remedial Action**

Openings which are used to secure trim panels must be checked for leaks. Any leaks found can be rectified using butyl strips.



Loose or damaged outer trim on the pillars **-arrow-** must be secured or replaced.



A butyl sealing strip **-1**- can be laid underneath the cover in the transition area between the air cowl cover and the wing or windshield.

The sealing of the door handles must be renewed when required. In addition, noise absorbing material can be applied to the back of the door handles.

### Noise, Vibration and Harshness

**Noise**, coming from the vehicle and which can be heard inside and outside the vehicle.

**Vibrations**, oscillations that are felt and noticeable inside the vehicle.

**Harshness**, noises which come from the vehicle and which can be heard, felt and noticed inside and outside the vehicle.

These terms are grouped together under the title Noise, Vibration, Harshness, or NVH for short.

The task of vehicle development and production is to ensure that noises caused by the vehicle do not disturb the driver and passengers. Moreover, the the external noises emitted by the vehicle must not exceed the thresholds set by law.

**NOTE:** Basic and advanced training courses are offered for the following contents. For an overview of all courses offered, please refer to the Ford Service Organisation's training course brochure.

### Noise types and causes

Noises in and around the vehicle are assigned specific descriptions:

- Humming and droning are perceived as low tones.
- · Buzzing and whirring are middle tones.
- Howling, whistling, squeaking are assigned to the high tones.

Low to middle tones are considered to be unpleasant. They are palpable and noticeable as oscillations and vibrations throughout the body. Loud howling and whistling is painful to the ears.

A noise usually consists of a superimposition of different tones which spread as oscillations.

Each of these oscillations has a specific oscillating time and can be measured in frequencies. The frequency describes the number of oscillations per second. The frequency unit is specified in Hertz (Hz).

The human ear can perceive frequencies between 20 and 20000 Hz.

# Where the different notes come from in a vehicle:

- · Low notes are mostly produced by the engine.
- Low tones can also be produced by the roadbed, particularly on rough surfaces. This is a form of droning which can be felt by the vehicle occupants as vibration or roughness.

- High tones however, which are experienced as howling or whistling noises, are often air currents (wind noises) or come from ancillary components such as the generator, power steering pump or drivebelt.
- There are also clattering noises which can occur when driving over an uneven road. These jerking noises are produced by, for example, the shock absorbers, chassis components or loose articles inside the vehicle.

Noises can already be contained where they occur or, if this is not possible, can be confined with suitable measures.

The basic procedures here are the damping of oscillating parts, the insulation of components or the absorption of the noises through appropriate materials.

### Damping

If a damper is installed next to an oscillating mass, the characteristic of the damper will reduce the movement of this mass accordingly (e.g. bumper on chassis).

Damping affects the resonance of an object or system.

### Isolation

In oscillation technology, the term isolation means decoupling (separation) of components and systems. An engine is mounted in sprung elements, so that as little oscillation as possible is passed to the vehicle.

In automotive technology, the isolation technique used is nearly always rubber mounting. Rubber has a large internal damping capacity. The elasticity of the rubber acts like a spring.


### Absorption

Sound waves are reflected from hard surfaces Through the use of absorption material, sound waves hit soft surfaces and are absorbed by them.

The composition and thickness of the material used plays an important role here. A soft surface, depending on its composition, absorbs the sound waves and reduces their energy.

### **NVH elements**

NVH elements are installed to prevent airborne sound transfers to the passenger compartment in different body cavities.



E54912


ltem	Description
1	C-pillar area
2	B-pillar area
3	A-pillar area

On the Focus 2004.75 (07/2004-) these elements are located in the cavities of the A, B and C pillars. On the estate version, they are also located in the D pillars.

The NVH material consists of a carrier plate which has compressed isolation material at the edges. In the drying system of the painting equipment used in production, the body is heated to approx. 170°

C. At this temperature the isolation material expands to seal the gap between the carrier plate and the bodywork.

NOTE: NVH elements must not be damaged during work on the vehicle body. NVH elements deformed through impact must always be replaced. PU adhesive must always be applied to the edges of new and reused NVH elements during repair work.



ltem	Description
1	NVH element
2	PU adhesive

For the exact installation position of an NVH element, please refer to the vehicle-specific repair instructions.

If an NVH element is to be reused, the bonding on the body panel must be detached. To do this, the body panel must be heated in the area around the NVH element. The bonding can be detached at approx. 170° C. The damaged panel part can now be carefully dismantled.

Before installing the new panel part, a PU adhesive must be applied to the contact areas between the panel and the NVH element.

### Test techniques, measuring devices

The shortest route to an accurate diagnosis results from:

- general information on the problem vehicle and a comparison test with a vehicle of the same construction, without NVH problems.
- vehicle history, including repair history and usage patterns.
- condition history, especially any relationship to repairs or sudden change.
- knowledge of probable causes.
- application of diagnosis procedures in which the vehicle is split into corresponding areas.

The diagnosis and correction of noise, vibration and harshness concerns requires:

- general information on the problem vehicle and a comparison test with a vehicle of the same construction, without NVH problems.
- vehicle history, including repair history and usage patterns.

- condition history, especially any relationship to repairs or sudden change.
- knowledge of probable causes.
- application of diagnosis procedures in which the vehicle is split into corresponding areas.

**NOTE:** The diagnosis of droning problems is one of the most difficult tasks in the NVH area. With the exception of installed components under stress, a certain diagnosis of droning problems (or boom) on customer vehicles makes great demands on the automotive technician. The performance of measuring equipment and their practice-orientated application can only be obtained through suitable instruction (NVH training). The successful use of these devices requires a great deal of experience on the part of the user.

The diagnosis and correction of noise, vibration and harshness concerns requires:


• a road or system test to determine the exact nature of the concern.

Analysis of possible causes:

- checking of the cause and elimination of the faults found.
- a road test or system test to make sure the concern has been corrected or brought back to within an acceptable range.
- It is often very difficult to locate noises that are audible in the passenger compartment based on the problem description provided by the customer and the road tests performed. The direction of the noise can be detected subjectively, but the source of the noise cannot be found.

**NOTE:** For a selection of simple test tools, see the wind noises section.

### **Electronic NVH tester**



**NOTE:** Before using the NVH tester in the service, the service technician should take part in an NVH training course to ensure effective use of this device during the road test. A description of the function and application of the NVH tester is enclosed with the device.

The measuring device described below is used for diagnosis of the solid-borne sound and solid-borne sound transmission paths. The device is particularly suitable for medium and high frequency noise analyses. It principally enables noise diagnosis in the area of solid-borne sound and helps to identify solid-borne sound transmission routes.

In order to obtain a positive diagnosis of droning problems (low frequency noises) and their sources, you must have sufficient experience of how to use this measuring device.

The device works according to the following operating principle: Accelerometers (transmitters) are fitted on various vehicle components or body areas. The signals recorded here can be listened to one after the other on headphones or speakers via the different channels. Simultaneous illustration of several or all measuring channels (for comparison) is only possible visually on the display of the measuring device.

Layout and operation:


- The test device has six different channels for noise diagnosis.
- Each channel is marked in color on the terminal, cable and test device.
- The solid-borne sound recorded is transmitted to the test device or the headphones by the magnetic accelerometers (transmitters).

- There is an amplifier on the test device with which the signal strength and the corresponding channel can be set.
- Only the noises from a transmitter are transferred to the headphones.
- All connected cables can be visually illustrated individually or simultaneously on the display.
- · The test device saves the recorded data.
- The recorded data can be imported to a PC and evaluated.

The NVH tester is equipped in addition with mobile magnetic sensors which are particularly suitable for the following noise tests:

- · Internal noises at the dashboard
- Engine noise
- Electrical noises (sparking/voltage transmissions)
- Wind noises
- Vacuum leaks

### Chassis noise tester (chassis ear)



Used to diagnose solid-borne sound and its transmission routes. The device is particularly suitable for medium and high frequency noise analysis and principally enables noise diagnosis in the area of solid-borne sound and helps to identify solid-borne sound transmission routes.

In order to obtain a positive diagnosis of droning problems (low frequency noises) and their sources, you must have sufficient experience of how to use this measuring device.

Layout and operation:

The test device has six different channels for noise diagnosis. This means that six microphones equipped with clamps can be attached to different components on the vehicle. The emitted or transmitted solid-borne sound will be transferred from microphone to the headphones. There is an amplifier between the microphone and the headphones at which the signal strengths and the corresponding channel can be set.

Only the noises from one microphone are transferred to the headphones. Each channel is color-coded on the clamp, cable and amplifier.

**NOTE:** In order to be able to relate the positions of the different microphones during the test process, they are entered in a special test sheet according to their colors. Microphones, clamps and cables must be carefully routed and attached.

### Test process (example for transmission noise):

- Attach microphones to various positions on the transmission or mountings. This first allows the source of the noise to be determined, and then the possible transfer routes.
- A road test can be performed after all the clamps have been attached to the vehicle and all the cables connected to the amplifier.
- Firstly, all the channels are switched through one after the other in neutral, to check the operation of the different channels as well as the noise level in neutral.
- During the road test, all channels are listened to in the different gears, engine speeds, vehicle speeds and loads. This procedural method permits unambiguous diagnosis of the cause of the noise and the route of the noise until it enters the bodywork structure.
- The characteristics of the noise which is the cause of the concern should match those of the noise which is heard. This means compare the sound.
- Depending on the input signal level, there may be a great deal of difference in the noise level in the individual channels.
- Always set the amplifier volume to zero before switching to another channel.
- In order to be able to make any comparisons, the volume settings of the different channels must be recorded on the test sheet.

PAGE

# **SECTION 501-26 Body Repairs - Vehicle Specific** Information and Tolerance Checks

### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

### **DESCRIPTION AND OPERATION**


Body and Frame (Component Location)	501-26-2
Body and Frame (Overview)	501-26-7
Introduction	501-26-7
High-strength and super-high-strength steels	501-26-7
Usibor steel	501-26-8
Crash elements	
Sheet metal parts for quarter panel partial replacement	501-26-11
Anti-corrosion protection	501-26-12
Laser weld seams on the front side members	501-26-14

### **GENERAL PROCEDURES**


Underbody Tolerance Check	501-26-15
Frame Tolerance Check	501-26-17

# Body and Frame – Component Location

## Body, 3-door version




Body, 5-door version




Location of the VIN plate



## Lifting Points



Air Bag and Safety Belt Pretensioner Supplemental Restraint System (SRS)




ltem	Description
1	Front crash sensor
2	Front passenger airbag
3	PAD (passenger air bag deactivation) deactivator switch <b>Comments:</b> optional
4	Seat occupant sensor (passenger side only)

ltem	Description
5	Side airbag (driver and passenger side) Comments: optional
6	Crash sensor (driver and passenger side) Comments: optional
7	RCM (restraints control module)
8	Safety belt buckle switch (driver and passenger side)

Item	Description
9	Head airbag (driver and passenger side) Comments: optional
10	Belt pretensioner in the retractor (driver and passenger side)
11	PAD indicator light Comments: optional

ltem	Description
12	Driver air bag
13	Knee air bag <b>Comments:</b> optional
14	Instrument cluster with airbag indicator light and safety belt warning light

## NVH expandables




# Body and Frame – Overview

## Introduction

With the 2008.75 model year, the Ford Fiesta is superseded by a completely new vehicle. The Fiesta is based on the B2e platform which has been developed in co-operation with Mazda. 3-door and 5-door body versions are offered. Within the company the model designation is B299. Overall the vehicle weighs less than its predecessor. However, it offers increased occupant safety through the use of high-strength and super-high-strength steels. The high-strength and super-high-strength steels used make extra demands on the tools to be employed for some body repairs.

### High-strength and super-high-strength steels




### Yield strength

Item	Description
1	UHSS (> 800 MPa)
2	EHSS (380 - 800 MPa)

ltem	Description
3	VHSS (280 - 380 MPa)
4	HSS (180 - 280 MPa)
5	MS (< 180 MPa)

## **Usibor steel**




The reinforcements at the A- and B-pillars are made of Usibor steel. This material has a yield strength of 1300 MPa.

- Sectional repairs must **NOT** be performed on components made of Usibor !
- The required continuous MIG weld seam in the cut area would cause structural changes in the steel and lead to a significant loss in strength.
- In the event of damage, the complete component must therefore always be renewed.
- Also, because of the strength of these components, it is not always possible to work them with conventional body repair tools.

- For welding work (resistance spot welding and inert gas puddle welding), additional preparation work and/or special welding equipment are required.
- Refer to: Body Sheet Metal (501-25 Body Repairs - General Information, Description and Operation)
- / Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation)
- / Joining Techniques (501-25 Body Repairs -General Information, Description and Operation).


## **Crash elements**

### Front crash module



Item	Description
1	Crash element (ZStE260; 1,6 mm)
2	Bumper (DP100; 2 mm)

#### Rear crash module




ltem	Description
1	Crash element (DP600; 1,6 mm)
2	Bumper (QStE340; 1,4 mm)

On each of the side members at the front and rear of the vehicle there is a crash element attached by threaded connections. These crash elements can absorb light impacts of up to about 15 km/hr. Because of the threaded connections, a crash element can be changed relatively quickly. The crash elements are joined to each other by a transverse mounted bumper. This forms a connection between the ends of the two side members and therefore contributes to an increase in passive safety.

**NOTE:** Deformed crash elements must not be straightened or repaired.


Heavier impacts which can no longer be absorbed by the crash element must be absorbed by the side members or the floor pan structure.

# Sheet metal parts for quarter panel partial replacement




## Anti-corrosion protection

## Underbody



Item	Description
1	Underbody PVC stone chip protection
2	Injection points for cavity wax protection


### Door cavity wax protection



All vehicle variants (shown on the 5-door)

### Laser weld seams on the front side members

#### **Tailored blank**



ltem	Description
1	DP600 - 1,4 mm
2	DP600 - 1,6 mm

There are laser weld seams on the front side members. These laser weld seams are used to join body components of different quality and/or different material thickness (tailored blanks).

Cut locations exactly on the laser weld seams are not permitted, as at present no joining techniques are approved for use in repair procedures that would re-create joins of the same quality.

Refer to: Front Side Member Section (501-27 Front End Sheet Metal Repairs, Removal and Installation)

/ Front Side Member and Fender Apron Panel LH (501-27 Front End Sheet Metal Repairs, Removal and Installation).

# Underbody Tolerance Check

# 1. Body dimensions, all versions (quick measurements using the Allvis system)


• All dimensions are measured from the middle of the hole or bolt head or from the edge of

the panel, using the Allvis system, with component assemblies installed.

 A tolerance of ± 3 mm applies to all measurements given. All detailed illustrations correspond to the left-hand side of the vehicle.

Point of measurement	Adapter	Height setting of the test probes
1	15 mm (Socket)	200 mm
2	25 mm (Probe)	240 mm
3	25 mm (Probe)	70 mm
4	25 mm (Probe)	190 mm
5	25 mm (Probe)	320 mm
6	25 mm (Probe)	320 mm

### Allvis specifications



# Frame Tolerance Check

### 1. Front end body dimensions, all models

 All dimensions with tolerance ± 3 mm. All dimensions were determined starting from the centre of each hole or panel edge using a symmetrically adjusted measuring gauge.

### Messpunkte und Maße

1 - 2 = 196 mm	1 - 7 = 1009 mm
----------------	-----------------

1 - 3 = 320 mm	1 - 8 = 1189 mm
1 - 4 = 495 mm	1 - 9 = 1204 mm
1 - 5 = 1132 mm	1 - 10 = 1512 mm
1 - 6 = 1202 mm	




### 2. Body dimensions, side view (3-door version)

 All dimensions with tolerance ± 3 mm. All dimensions were determined starting from the edge of the steel panel using a symmetrically adjusted measuring gauge.

- Measuring points 1, 2, 4 and 5 are measured in the curve and represent the greatest distance to the measuring point opposite.
- The detailed views of measuring points 3 and 6 are shown looking from the vehicle interior outwards.

### Measuring points and dimensions

1 - 4 = 1469 mm	
2 - 5 = 1142 mm	
3 - 6 = 1028 mm	



### 3. Body dimensions, side view (4-door version)

All dimensions with tolerance ± 3 mm. All dimensions were determined starting from

the edge of the steel panel using a symmetrically adjusted measuring gauge.


• Measuring points 1, 2, 3, 4, 6, 7, 10 and 11 are measured in the curve and represent the

greatest distance to the measuring point opposite.

• The detailed views of measuring points 5, 8, 9 and 12 are shown looking from the vehicle interior outwards.

### Measuring points and dimensions

1 - 10 = 920 mm	4 - 7 = 1077 mm
2 - 11 = 1306 mm	5 - 8 = 711 mm
3 - 6 = 958 mm	9 - 12 = 797 mm



### 4. Body dimensions, side view (5-door version)

All dimensions with tolerance ± 3 mm. All dimensions were determined starting from

the edge of the steel panel using a symmetrically adjusted measuring gauge.


• Measuring points 1, 2, 3, 4, 6, 7, 10 and 11 are measured in the curve and represent the

greatest distance to the measuring point opposite.

• The detailed views of measuring points 5, 8, 9 and 12 are shown looking from the vehicle interior outwards.


### Measuring points and dimensions

01	
1 - 10 = 923 mm	4 - 7 = 1092 mm
2 - 11 = 1305 mm	5 - 8 = 710 mm
3 - 6 = 985 mm	9 - 12 = 795 mm



### 5. Body dimensions, rear (3-door version)

 All dimensions with tolerance ± 3 mm. All dimensions were determined starting from the center of the welded flange using a symmetrically adjusted measuring gauge.




- 6. Body dimensions, rear (4-door version)
- All dimensions with tolerance ± 3 mm. All dimensions were determined starting from

the center of the welded flange using a symmetrically adjusted measuring gauge.

## Measuring points and dimensions

1 - 6 = 985 mm 4 - 10 = 1089 mm

2 - 7 = 502 mm	5 - 9 = 992 mm
3 - 8 = 986 mm	




### 7. Body dimensions, rear (5-door version)

 All dimensions with tolerance ± 3 mm. All dimensions were determined starting from the center of the welded flange using a symmetrically adjusted measuring gauge.

### Measuring points and dimensions


1 - 5 = 1062 mm	3 - 7 = 1062 mm
2 - 6 = 774 mm	4 - 8 = 1024 mm



- 8. Body dimensions, interior (3-door version)
  - All dimensions with tolerance ± 3 mm. All dimensions were determined starting from the center of the welded flange using a symmetrically adjusted measuring gauge.
- The detailed views of measuring points 1, 2, 3 and 4 are shown looking from the vehicle interior outwards.

### Measuring points and dimensions

1 - 2 = 1366 mm 3 - 4 = 1365 mm
---------------------------------



### 9. Body dimensions, interior (4-door version)


1. All dimensions with tolerance ± 3 mm. All dimensions were determined starting from

the center of the welded flange using a symmetrically adjusted measuring gauge.

• The detailed views of measuring points 1, 2, 3, 4, 5 and 6 are shown looking from the vehicle interior outwards.

### Measuring points and dimensions






### **10.** Body dimensions, interior (5-door version)

- All dimensions with tolerance ± 3 mm. All dimensions were determined starting from the center of the welded flange using a symmetrically adjusted measuring gauge.
- The detailed views of measuring points 1, 2, 3, 4, 5 and 6 are shown looking from the vehicle interior outwards.

### Measuring points and dimensions

1 - 4 = 1366 mm	5 - 6 = 1288 mm
2 - 3 = 1365 mm	



# **SECTION 501-27 Front End Sheet Metal Repairs**

#### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE


#### **REMOVAL AND INSTALLATION**

Front Fender	501-27-2
Fender Apron Panel Reinforcement	501-27-4
Front Side Member Section	501-27-9
Front Side Member and Fender Apron Panel LH	501-27-17


# **Front Fender**


### Removal

**NOTE:** Removal steps in this procedure may contain installation details.




#### 2. Torque: <u>6 Nm</u>







4. Torque: <u>6 Nm</u>




- **5.** Refer to: Fender Splash Shield (501-02 Front End Body Panels, Removal and Installation).
- 6. Torque: <u>6 Nm</u>




7. Torque: <u>6 Nm</u>



8. Torque: <u>6 Nm</u>



9. A CAUTION: Take extra care not to scratch the bumper cover.



## Installation

**1.** To install, reverse the removal procedure.

## Fender Apron Panel Reinforcement

#### **General Equipment**

#### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment

Spot weld drill Bit

## Removal


8 mm Drill Bit

Air Body Saw


1. •	Refer to: Front Fender (501-27 Front End Sheet Metal Repairs, Removal and
	Installation).
	Refer to: Fog Lamps (417-01 Exterior
	Lighting, Diagnosis and Testing).
	Refer to: Headlamps (417-01 Exterior
	Lighting, Diagnosis and Testing).
	Refer to: A-Pillar Trim Panel (501-05 Interior
	Trim and Ornamentation, Removal and
	Installation).
	Refer to: Front Bumper Cover (501-19
	Bumpers, Removal and Installation).
•	Door

- Door
- Hood
- Bumper
- Hood Closing Panel
- 2. Partial Replacement
  - Possible cut line.


General Equipment: Air Body Saw




3. • Grind out the MIG brazed joints.




4. • Mill out the spot welds.General Equipment: Spot weld drill Bit



5. • Mill out the spot welds.General Equipment: Spot weld drill Bit



6. • Mill out the spot welds.General Equipment: Spot weld drill Bit




#### Installation

- 1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.
  - Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs - General Information, Description and Operation).

- **3. NOTE:** Replacement of MIG brazed joints by MIG welds.
  - The factory-installed MIG brazed joints must be replaced by MIG welds in a different position.
  - These MIG welds must not be carried out on or in the immediate vicinity of existing MIG brazed seams as even the smallest amount of brazing solder can result in a reduction in the strength of the weld seam.
  - Refer to: Joining Techniques (501-25 Body Repairs - General Information, Description and Operation).
- 4. General Equipment: 8 mm Drill Bit




**5.** • Resistance spot weld - Panel thickness 3


mm and greater!




6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



7. • Resistance spot weld - Panel thickness 3 mm and greater!







## Front Side Member Section

#### **General Equipment**

8 mm Drill Bit	
Air Body Saw	

Removal

**NOTE:** Equipment:

Measurement and alignment angle system

#### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment

Spot weld drill Bit

1. • Refer to: Front Fender (501-27 Front End Sheet Metal Repairs, Removal and Installation).

> Refer to: Fog Lamps (417-01 Exterior Lighting, Diagnosis and Testing). Refer to: Headlamps (417-01 Exterior

Lighting, Diagnosis and Testing). Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Front Bumper Cover (501-19 Bumpers, Removal and Installation).

- Door
- Hood
- Bumper
- Hood Closing Panel
- 2. 🔺 WARNING: Cut line positions
  - Due to the positions of inner reinforcements, it is very important that the dimension quoted for the separating cuts is accurately met.
- 3. NOTE: The cut shown is the final cut for the inner part.

Separating cut through outer and inner part of the front side member.

E108679

General Equipment: Air Body Saw


4. • General Equipment: Spot weld drill Bit



#### 5. • A CAUTION: Do not cut into inner part or reinforcements of the side member!

Separating cut through outer part of the front side member.

General Equipment: Air Body Saw



#### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.


Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -

General Information, Description and Operation).

3. • General Equipment: Air Body Saw




4. • General Equipment: Air Body Saw




5. • Resistance spot weld - Panel thickness 3 mm and greater!


General Equipment: Metal Inert Gas (MIG) Welding Equipment



6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 7. General Equipment: Metal Inert Gas (MIG)
- Welding Equipment




 6. General Equipment: 8 mm Drill Bit General Equipment: Metal Inert Gas (MIG) Welding Equipment



9. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



**10.** • General Equipment: Metal Inert Gas (MIG) Welding Equipment



## Front Side Member and Fender Apron Panel LH

#### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment

#### **General Equipment**


Spot weld drill Bit

### Removal


NOTE: Equipment:

Measurement and alignment angle system


- **1.** Refer to: Fender Apron Panel Reinforcement (501-27 Front End Sheet Metal Repairs, Removal and Installation).
- 2. General Equipment: Spot weld drill Bit




 Equipment: Spherical cutter General Equipment: Spot weld drill Bit




4. • Equipment: Spherical cutter




5. • Equipment: Spherical cutter



6. • General Equipment: Spot weld drill Bit



- 7. Equipment: Spherical cutter
  - Grind out from inside.



#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).


2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).


- 3. Equipment: 10 mm drill bit
- <image><image><text>
- 4. Equipment: 10 mm drill bit




- 5. General Equipment: Metal Inert Gas (MIG) Welding Equipment
- <image>
- 6. General Equipment: Metal Inert Gas (MIG) Welding Equipment




- 7. General Equipment: Metal Inert Gas (MIG)
- Welding Equipment




8. • Resistance spot weld - Panel thickness 3 mm and greater!



9. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



**10.** • Resistance spot weld - Panel thickness 3 mm and greater!



**11.** Refer to: Fender Apron Panel Reinforcement (501-27 Front End Sheet Metal Repairs, Removal and Installation).

# **SECTION 501-28 Roof Sheet Metal Repairs**

VEHICLE APPLICATION: 2011 Fiesta	
CONTENTS	PAGE
REMOVAL AND INSTALLATION	
Roof Panel	501-28-2

# **Roof Panel**

Materials		
Name	Specification	
Windshield Adhesive Kit	WSS-M11P57-A5	

#### Removal

- 1. Front and Rear Door
  - Refer to: Windshield Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).
  - Refer to: Headliner 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - A- B- and C-Pillar Trim

Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: C-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Refer to: Rear Window Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).
- 2. General Equipment: Spot weld drill Bit


#### General Equipment

Hot Air Gun

Spot weld drill Bit



3. • General Equipment: Spot weld drill Bit



4. • General Equipment: Hot Air Gun



#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

#### Authoring Template

- Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- **2. NOTE:** Sealer or adhesive must be applied with a minimum height of 20 mm.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • Material: Windshield Adhesive Kit (WSS-M11P57-A5)




4. • Resistance spot weld - Panel thickness 3 mm and greater!



**5.** • Resistance spot weld - Panel thickness 3

mm and greater!



- 6. Front and Rear Door
  - Refer to: Windshield Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).
  - Refer to: Headliner 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - A- B- and C-Pillar Trim
    - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - Refer to: Rear Window Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).

# **SECTION 501-29 Side Panel Sheet Metal Repairs**

### **VEHICLE APPLICATION: 2011 Fiesta**

#### CONTENTS

PAGE

#### **REMOVAL AND INSTALLATION**

A-Pillar Outer Panel	501-29-2
A-Pillar Assembly	501-29-9
Rocker Panel — 4-Door	501-29-13
Rocker Panel — 5-Door	501-29-19
Rocker Panel Inner Reinforcement	501-29-25
B-Pillar and Reinforcement — 4-Door	501-29-29
B-Pillar and Reinforcement — 5-Door	501-29-40
B-Pillar Outer Panel — 4-Door	501-29-51
B-Pillar Outer Panel — 5-Door	501-29-56

# A-Pillar Outer Panel

Materials		
Name	Specification	
Windshield Adhesive Kit	WSS-M11P57-A5	
General Equipment		
6 mm Drill Bit		

### Removal

- 1. Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- 2. Windshield

Refer to: Windshield Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).

- Front Door
   Refer to: Front Door Alignment (501-03 Body
   Classing Congress)
  - Closures, General Procedures).
- Door Hinges
- Weatherstrip
- A-pillar Trim

Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Rocker Panel Trim
- Driver or passenger seat

Refer to: Front Seat (501-10 Seating, Removal and Installation).

- Refer to: Fender Apron Panel Reinforcement (501-27 Front End Sheet Metal Repairs, Removal and Installation).
- Reposition the carpeting and the wiring harness away from the working area.
- 3. General Equipment: Air Body Saw

#### General Equipment


Air Body Saw

Hot Air Gun


Metal Inert Gas (MIG) Welding Equipment

Resistance Spotwelding Equipment


Spot weld drill Bit




4. • General Equipment: Spot weld drill Bit



5. • General Equipment: Spot weld drill Bit



#### 6. • General Equipment: Hot Air Gun



#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment

instructions and sub-section 501-25 must be followed.


Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation). 3. • General Equipment: 6 mm Drill Bit



 Material: Windshield Adhesive Kit (WSS-M11P57-A5)




5. • General Equipment: Resistance Spotwelding Equipment




6. • General Equipment: Resistance Spotwelding





7. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



501-29-8

# **REMOVAL AND INSTALLATION**

Refer to: Windshield Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).

- Front Door
   Refer to: Front Door Alignment (501-03 Body Closures, General Procedures).
- Door Hinges
- Weatherstrip
- A-pillar Trim

Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Rocker Panel Trim
- Driver or passenger seat

Refer to: Front Seat (501-10 Seating, Removal and Installation).

• Refer to: Fender Apron Panel Reinforcement (501-27 Front End Sheet Metal Repairs, Removal and Installation).

# A-Pillar Assembly

Materials	
Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5
General Equipment	
6 mm Drill Bit	

Removal

### **General Equipment**

Hot Air Gun

Metal Inert Gas (MIG) Welding Equipment

Resistance Spotwelding Equipment

Spot weld drill Bit


- **1.** Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs General Information, Description and Operation).
- 2. Refer to: A-Pillar Outer Panel (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).
  - Windshield

Refer to: Windshield Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).


Front Door

Refer to: Front Door Alignment (501-03 Body Closures, General Procedures).

- Door Hinges
- Weatherstrip
- A-pillar Trim
  - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Rocker Panel Trim
- Driver or passenger seat
  - Refer to: Front Seat (501-10 Seating, Removal and Installation).
- Refer to: Fender Apron Panel Reinforcement (501-27 Front End Sheet Metal Repairs, Removal and Installation).
- Reposition the carpeting and the wiring harness away from the working area.
- 3. General Equipment: Spot weld drill Bit



4. • General Equipment: Hot Air Gun



#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).


2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • General Equipment: 6 mm Drill Bit




 Material: Windshield Adhesive Kit (WSS-M11P57-A5)




E115409

5. • General Equipment: Resistance Spotwelding Equipment



6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 7. Refer to: A-Pillar Outer Panel (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).
  - Windshield

Refer to: Windshield Glass (501-11 Glass, Frames and Mechanisms, Removal and Installation).

Front Door

Refer to: Front Door Alignment (501-03 Body Closures, General Procedures).

- Door Hinges
- Weatherstrip
- A-pillar Trim
  - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Rocker Panel Trim
- Driver or passenger seat
  - Refer to: Front Seat (501-10 Seating, Removal and Installation).
- Refer to: Fender Apron Panel Reinforcement (501-27 Front End Sheet Metal Repairs, Removal and Installation).

# Rocker Panel — 4-Door

Materials	
Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5
General Equipment	

Air Body Saw

#### Removal

- 1. Door Hinges
  - Front and Rear Door
  - Front Wheel Arch Trim
  - Rear Wheel Arch Trim
  - A- B- and C-Pillar Trim

Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: C-Pillar Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Rocker Panel Trim
- Refer to: Front Seat (501-10 Seating, Removal and Installation).
   Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
   Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
- Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Air Body Saw


#### **General Equipment**

Hot Air Gun


Metal Inert Gas (MIG) Welding Equipment

Resistance Spotwelding Equipment


Spot weld drill Bit




3. • General Equipment: Spot weld drill Bit



4. • General Equipment: Hot Air Gun



5. • General Equipment: Hot Air Gun




#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.
  - Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).
- Material: Windshield Adhesive Kit (WSS-M11P57-A5)




4. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



5. • General Equipment: Resistance Spotwelding Equipment



6.



- 7. Door Hinges
  - Front and Rear Door
  - Front Wheel Arch Trim
  - Rear Wheel Arch Trim
  - A- B- and C-Pillar Trim

Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: C-Pillar Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Rocker Panel Trim
- Refer to: Front Seat (501-10 Seating, Removal and Installation).
  - Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).

Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).

# Rocker Panel — 5-Door

Materials	
Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5
General Equipment	

Air Body Saw

#### Removal

- **1.** Front and Rear Door
  - Door Hinges
  - Front Wheel Arch Trim
  - Rear Wheel Arch Trim
  - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - Rocker Panel Trim
  - Refer to: Front Seat (501-10 Seating, Removal and Installation).
     Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
     Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Air Body Saw


#### **General Equipment**

Hot Air Gun


Metal Inert Gas (MIG) Welding Equipment

Resistance Spotwelding Equipment


Spot weld drill Bit




3. • General Equipment: Spot weld drill Bit



4. • General Equipment: Hot Air Gun



5. • General Equipment: Hot Air Gun




#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.
  - Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).
- Material: Windshield Adhesive Kit (WSS-M11P57-A5)




4. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



5. • General Equipment: Resistance Spotwelding Equipment



6.



- 7. Front and Rear Door
  - Door Hinges
  - Front Wheel Arch Trim
  - Rear Wheel Arch Trim
  - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - Rocker Panel Trim
  - Refer to: Front Seat (501-10 Seating, Removal and Installation).
     Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
     Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).

# Rocker Panel Inner Reinforcement

#### **General Equipment**

Air Body Saw

Metal Inert Gas (MIG) Welding Equipment

#### Removal

- **1.** Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- 2. Refer to: A-Pillar Assembly (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).
  - Refer to: A-Pillar Outer Panel (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).
  - Rocker Panel
  - Door Hinges
  - Front and Rear Door
  - Front Wheel Arch Trim
  - Rear Wheel Arch Trim
  - A- B- and C-Pillar Trim

Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).


Refer to: C-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Rocker Panel Trim
- Refer to: Front Seat (501-10 Seating, Removal and Installation).
   Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
   Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
- Reposition the carpeting and the wiring harness away from the working area.
- 3. General Equipment: Air Body Saw

#### General Equipment

**Resistance Spotwelding Equipment** 

Spot weld drill Bit



4. • General Equipment: Spot weld drill Bit



#### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.


Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation). 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • General Equipment: Resistance Spotwelding Equipment



4. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 5. Refer to: A-Pillar Assembly (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).
  - Refer to: A-Pillar Outer Panel (501-29 Side Panel Sheet Metal Repairs, Removal and Installation).
  - Rocker Panel
  - Door Hinges
  - Front and Rear Door
  - Front Wheel Arch Trim
  - Rear Wheel Arch Trim
  - A- B- and C-Pillar Trim
    - Refer to: A-Pillar Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - Rocker Panel Trim
  - Refer to: Front Seat (501-10 Seating, Removal and Installation).
     Refer to: Rear Seat Curbion (501, 10 Sector)

Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).

Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).

# B-Pillar and Reinforcement — 4-Door

Materials	
Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5
General Equipment	
Air Body Saw	

#### Removal

**NOTE:** Equipment:

#### Measurement and alignment angle system

- 1. A WARNING: High-strength steel (Usibor 1500)
  - A suitably powerful resistance spot welding device with inverter technology must be used for this repair. Observe the manufacturer's welding equipment instructions and sub-section 501-25.
  - The B-pillar reinforcement is made of high-strength steel plate (Usibor 1500).
  - A partial replacement of the B-pillar reinforcement is not permissible. The required continuous MIG weld seam in the area of the cut causes structural changes which result in significant loss of strength in the B-pillar reinforcement.

#### **General Equipment**

11.4	A ·	~	
Hot	Air	Gun	

Metal Inert Gas (MIG) Welding Equipment

Resistance Spotwelding Equipment

Spot weld drill Bit

- Due to its strength, the B-pillar reinforcement can not always be worked on with conventional body tools.
- Additional preparations are required for MIG puddle welding.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).


2. • Rocker Panel Trim

Refer to: Front Seat (501-10 Seating, Removal and Installation). Refer to: Rear Seat Cushion (501-10 Seating,


Removal and Installation).

Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation). Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Front and Rear Door
- Reposition the carpeting and the wiring harness away from the working area.
- General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



4. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit




5. • General Equipment: Hot Air Gun

E113406


6. • General Equipment: Spot weld drill Bit

E113407	


7. • General Equipment: Air Body Saw




8. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



9. • General Equipment: Spot weld drill Bit



#### 10. General Equipment: Spot weld drill Bit



#### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or


sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).


- 3. The holes need to be pre-milled with a spherical cutter with a small diameter. Afterwards these holes are then milled out to the required diameter with a spindle milling cutter. This method is essential in order to ensure that the material in the edge area of the milled holes is not weakened.
  - Equipment: Spherical cutter
  - Equipment: spindle milling cutter



4. • A WARNING: The B-pillar reinforcement is covered with a hot-dip aluminized coating on its entire surface. This coating needs to be fully ground off on the welding flanges on the front and rear using a fibre grinding disc. Any contamination due to parts of the coating in the welding bath will weaken the welded joint.



5. • A WARNING: The A-pillar reinforcement is covered with a hot-dip aluminized coating on its entire surface. This coating needs to be fully ground off on the welding flanges on the front using a fibre grinding disc. Any contamination due to parts of the coating in the welding bath will weaken the welded joint.




6. • Resistance spot weld - Panel thickness 3 mm and greater!

General Equipment: Resistance Spotwelding Equipment




 General Equipment: Metal Inert Gas (MIG) Welding Equipment




E113416

 Material: Windshield Adhesive Kit (WSS-M11P57-A5)




- 9. Puddle weld 2 panel layer.
  - General Equipment: Metal Inert Gas (MIG) Welding Equipment

#### E113417




**10.** • Puddle weld **3** panel layer.

General Equipment: Metal Inert Gas (MIG) Welding Equipment




**11.** • Resistance spot weld - Panel thickness 3 mm and greater!

General Equipment: Resistance Spotwelding Equipment




12 • General Equipment: Metal Inert Gas (MIG) Welding Equipment



**13.** • General Equipment: Resistance Spotwelding Equipment

General Equipment: Metal Inert Gas (MIG) Welding Equipment



14. Rocker Panel Trim

Refer to: Front Seat (501-10 Seating, Removal and Installation).
Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Front and Rear Door

# B-Pillar and Reinforcement — 5-Door

Materials	
Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5
General Equipment	
Air Body Saw	

#### Removal

**NOTE:** Equipment:

#### Measurement and alignment angle system

- 1. A WARNING: High-strength steel (Usibor 1500)
  - A suitably powerful resistance spot welding device with inverter technology must be used for this repair. Observe the manufacturer's welding equipment instructions and sub-section 501-25.
  - The B-pillar reinforcement is made of high-strength steel plate (Usibor 1500).
  - A partial replacement of the B-pillar reinforcement is not permissible. The required continuous MIG weld seam in the area of the cut causes structural changes which result in significant loss of strength in the B-pillar reinforcement.

#### **General Equipment**

Hot	۸ir	Gun
HΟL	AI	Gun

Metal Inert Gas (MIG) Welding Equipment

Resistance Spotwelding Equipment

Spot weld drill Bit

- Due to its strength, the B-pillar reinforcement can not always be worked on with conventional body tools.
- Additional preparations are required for MIG puddle welding.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. • Rocker Panel Trim


Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Front Seat (501-10 Seating, Removal and Installation).


Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).

Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).

- Front and Rear Door
- Reposition the carpeting and the wiring harness away from the working area.
- General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



4. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit




5. • General Equipment: Hot Air Gun

E111971


6. • General Equipment: Spot weld drill Bit

E111972	


7. • General Equipment: Air Body Saw




8. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



9. • General Equipment: Spot weld drill Bit



### 10. General Equipment: Spot weld drill Bit



### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or


sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).


- 3. The holes need to be pre-milled with a spherical cutter with a small diameter. Afterwards these holes are then milled out to the required diameter with a spindle milling cutter. This method is essential in order to ensure that the material in the edge area of the milled holes is not weakened.
  - Equipment: Spherical cutter
  - Equipment: spindle milling cutter



4. • A WARNING: The B-pillar reinforcement is covered with a hot-dip aluminized coating on its entire surface. This coating needs to be fully ground off on the welding flanges on the front and rear using a fibre grinding disc. Any contamination due to parts of the coating in the welding bath will weaken the welded joint.



5. • A WARNING: The A-pillar reinforcement is covered with a hot-dip aluminized coating on its entire surface. This coating needs to be fully ground off on the welding flanges on the front using a fibre grinding disc. Any contamination due to parts of the coating in the welding bath will weaken the welded joint.




6. • Resistance spot weld - Panel thickness 3 mm and greater!

General Equipment: Resistance Spotwelding Equipment




 General Equipment: Metal Inert Gas (MIG) Welding Equipment




E111979

8. • Material: Windshield Adhesive Kit (WSS-M11P57-A5)




- 9. Puddle weld 2 panel layer.
  - General Equipment: Metal Inert Gas (MIG) Welding Equipment

#### E111980




**10.** • Puddle weld **3** panel layer.

General Equipment: Metal Inert Gas (MIG) Welding Equipment




**11.** • Resistance spot weld - Panel thickness 3 mm and greater!

General Equipment: Resistance Spotwelding Equipment




12 • General Equipment: Metal Inert Gas (MIG) Welding Equipment



**13.** • General Equipment: Resistance Spotwelding Equipment

General Equipment: Metal Inert Gas (MIG) Welding Equipment



### 14. Rocker Panel Trim

Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
Refer to: Front Seat (501-10 Seating, Removal and Installation).
Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
Front and Rear Door

• Reposition the carpeting and the wiring harness away from the working area.

# B-Pillar Outer Panel — 4-Door

Μ	at	er	ial	S

Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5

### Removal

**1.** • Rocker Panel Trim

Refer to: Front Seat (501-10 Seating, Removal and Installation). Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Front and Rear Door
- Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Air Body Saw General Equipment: Spot weld drill Bit


### **General Equipment**

Air Body Saw


Hot Air Gun

Metal Inert Gas (MIG) Welding Equipment


Spot weld drill Bit



3. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



4. • General Equipment: Hot Air Gun




### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.


Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).  Material: Windshield Adhesive Kit (WSS-M11P57-A5)








5. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



6. • General Equipment: Metal Inert Gas (MIG)

Welding Equipment



### 7. • Rocker Panel Trim

Refer to: Front Seat (501-10 Seating, Removal and Installation). Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

• Front and Rear Door

# B-Pillar Outer Panel — 5-Door

### **Materials**

Name	Specification
Windshield Adhesive Kit	WSS-M11P57-A5

### Removal

- **1.** Rocker Panel Trim
  - Refer to: B-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Front Seat (501-10 Seating, Removal and Installation).

- Front and Rear Door
- Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Air Body Saw General Equipment: Spot weld drill Bit


### General Equipment

Air Body Saw


Hot Air Gun

Metal Inert Gas (MIG) Welding Equipment


Spot weld drill Bit



3. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



4. • General Equipment: Hot Air Gun




### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.


Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).  Material: Windshield Adhesive Kit (WSS-M11P57-A5)








5. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



6. • General Equipment: Metal Inert Gas (MIG)

Welding Equipment



### 7. • Rocker Panel Trim

Refer to: B-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Front Seat (501-10 Seating, Removal and Installation).

- Front and Rear Door
- Reposition the carpeting and the wiring harness away from the working area.

# **SECTION 501-30 Rear End Sheet Metal Repairs**

### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

PAGE

### **REMOVAL AND INSTALLATION**

Quarter Panel LH — 4-Door	501-30-2
Quarter Panel LH — 5-Door	501-30-15
Water Drain Panel	501-30-23
Water Drain Panel — 4-Door	501-30-29
Water Drain Panel Reinforcement	501-30-32
Rear Wheelhouse Outer — 4-Door	501-30-38
Rear Wheelhouse Outer — 5-Door	501-30-43
Inner Quarter Panel and Wheelhouse — 4-Door	501-30-48
Inner Quarter Panel and Wheelhouse — 5-Door	501-30-56
Back Panel and Reinforcement — 4-Door	501-30-63
Back Panel and Reinforcement — 5-Door	501-30-67
Rear Lamp Mounting Panel — 4-Door	501-30-76
Rear Floor Panel	501-30-81
Rear Side Member Section	501-30-90

# Quarter Panel LH — 4-Door

Materials		
Name	Specification	
Windshield Adhesive Kit	WSS-M11P57-A5	
General Equipment		

6 mm Drill Bit

### Removal

### 1. • Liftgate

- Rear Lamp
- Rocker Panel Trim
- Front and Rear Door
- Rear Wheel Arch Trim
- Tank Filler Flap and Tank Filler
- Refer to: Liftgate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).

Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).

Refer to: Rear Bumper Cover - 4-Door (501-19 Bumpers, Removal and Installation).

Refer to: Rear Quarter Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: C-Pillar Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Loadspace Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Reposition the carpeting and the wiring harness away from the working area.
- 2. Partial Replacement Quarter Panel Cut Line Options

### **General Equipment**


Air Body Saw

Hot Air Gun


Metal Inert Gas (MIG) Welding Equipment

Resistance Spotwelding Equipment

Spot weld drill Bit




3. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



4. • General Equipment: Spot weld drill Bit




- 5. Equipment: Spherical cutter
- 6. General Equipment: Spot weld drill Bit




7. • Equipment: Spherical cutter



8. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



9. • General Equipment: Hot Air Gun



### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • General Equipment: 6 mm Drill Bit



4. • General Equipment: 6 mm Drill Bit




5. • General Equipment: Resistance Spotwelding Equipment



6. • Material: Windshield Adhesive Kit (WSS-M11P57-A5)




7. • General Equipment: Resistance Spotwelding Equipment General Equipment: Metal Inert Gas (MIG) Welding Equipment




8. • General Equipment: Resistance Spotwelding Equipment



9. • General Equipment: Metal Inert Gas (MIG) Welding Equipment




**10.** • General Equipment: Resistance Spotwelding Equipment




**11.** • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 12 General Equipment: Resistance Spotwelding Equipment
  - General Equipment: Metal Inert Gas (MIG) Welding Equipment



13.



### 14. · Liftgate

- Rear Lamp
- Rocker Panel Trim
- Front and Rear Door
- Rear Wheel Arch Trim
- Tank Filler Flap and Tank Filler
- Refer to: Liftgate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).

- Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
- Refer to: Rear Bumper Cover 4-Door (501-19 Bumpers, Removal and Installation).
- Refer to: Rear Quarter Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Refer to: C-Pillar Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Loadspace Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

# Quarter Panel LH — 5-Door

Materials		
Name	Specification	
Windshield Adhesive Kit	WSS-M11P57-A5	
General Equipment		

6 mm Drill Bit

### Removal

- 1. Liftgate
  - Tank Filler Flap and Tank Filler
  - Rear Lamp
  - Rear Wheel Arch Trim
  - Rocker Panel Trim
  - Front and Rear Door
  - Refer to: Rear Bumper Cover (501-19 Bumpers, Removal and Installation).
     Refer to: Loadspace Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Rear Quarter Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).
    - Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. Partial Replacement Quarter Panel Cut Line Options

### **General Equipment**


Air Body Saw

Hot Air Gun


Metal Inert Gas (MIG) Welding Equipment

**Resistance Spotwelding Equipment** 


Spot weld drill Bit




3. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



- 4. General Equipment: Spot weld drill Bit
  - T1112
- 5. General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



6. • General Equipment: Hot Air Gun



#### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.


Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation). 3. • General Equipment: 6 mm Drill Bit




 Material: Windshield Adhesive Kit (WSS-M11P57-A5)




5. • General Equipment: Resistance Spotwelding Equipment




6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



 General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 8. General Equipment: Resistance Spotwelding Equipment
  - General Equipment: Metal Inert Gas (MIG) Welding Equipment



9.



- 10. Liftgate
  - Rear Lamp
  - Rear Wheel Arch Trim
  - Rocker Panel Trim
  - Front and Rear Door
  - Rear Bumper

Refer to: Rear Bumper Cover (501-19 Bumpers, Removal and Installation).

Refer to: Loadspace Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: C-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Rear Seat Cushion (501-10 Seating, Removal and Installation).

Refer to: Rear Seat Backrest (501-10 Seating, Removal and Installation).

# Water Drain Panel

#### **General Equipment**

**General Equipment** 

Metal Inert Gas (MIG) Welding Equipment

Spot weld drill Bit


3. • General Equipment: Air Body Saw General Equipment: Spot weld drill Bit


Air Body Saw

Locking Pliers


#### Removal

- 1. Liftgate
  - Rear Bumper
    - Refer to: Rear Bumper Cover (501-19 Bumpers, Removal and Installation). Refer to: Loadspace Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation,
    - Removal and Installation). Refer to: C-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Quarter Panel LH 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit





4. • General Equipment: Spot weld drill Bit



#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).


3. • General Equipment: Locking Pliers General Equipment: Spot weld drill Bit




4. • General Equipment: Locking Pliers



5.




6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment




7. • General Equipment: Metal Inert Gas (MIG)

Welding Equipment




8. • Puddle weld 3 panel layer.

General Equipment: Metal Inert Gas (MIG) Welding Equipment



9. • Puddle weld 3 panel layer.

General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 10. · Liftgate
  - Rear Bumper

Refer to: Rear Bumper Cover (501-19 Bumpers, Removal and Installation).

- Refer to: Loadspace Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
- Refer to: Quarter Panel LH 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
- Reposition the carpeting and the wiring harness away from the working area.


# Water Drain Panel — 4-Door

#### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment

#### Removal

- 1. Liftgate
  - Rear Bumper
    - Refer to: Quarter Panel LH 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Rear Bumper Cover 4-Door (501-19 Bumpers, Removal and Installation).
    - Refer to: Loadspace Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit




#### **General Equipment**

Resistance Spotwelding Equipment

Spot weld drill Bit

3. • General Equipment: Spot weld drill Bit





#### 4. • General Equipment: Spot weld drill Bit

#### Installation

**1. NOTE:** Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment

instructions and sub-section 501-25 must be followed.


- Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • General Equipment: Spot weld drill Bit




4. • General Equipment: Resistance Spotwelding Equipment



5. • General Equipment: Resistance Spotwelding Equipment



6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 7. Liftgate
  - Rear Bumper
    - Refer to: Quarter Panel LH 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Rear Bumper Cover 4-Door (501-19 Bumpers, Removal and Installation).
    - Refer to: Loadspace Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

# Water Drain Panel Reinforcement

#### **General Equipment**

Air Body Saw

Locking Pliers

#### Removal

 Refer to: Back Panel and Reinforcement - 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
 Refer to: Water Drain Panel (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
 Perfer to: Operation Panel 111, 5 Deep (501-20)


Refer to: Quarter Panel LH - 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

- Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit


#### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment

Spot weld drill Bit




3.



4. • A CAUTION: Do not cut into Inner Quarter Panel!

General Equipment: Air Body Saw




#### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).


- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.
  - Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).
- **3.** Resistance spot weld.

General Equipment: Locking Pliers




4. • Resistance spot weld - Panel thickness 3 mm and greater!


General Equipment: Locking Pliers



- 5. Resistance spot weld.
  - General Equipment: Locking Pliers



6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- Refer to: Back Panel and Reinforcement - 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
   Refer to: Water Drain Panel (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Refer to: Quarter Panel LH 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.

# Rear Wheelhouse Outer — 4-Door

#### **General Equipment**

Air Body Saw

Metal Inert Gas (MIG) Welding Equipment


#### Removal

- 1. Refer to: Quarter Panel LH 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit


#### **General Equipment**


**Resistance Spotwelding Equipment** 

Spot weld drill Bit



- 3. General Equipment: Air Body Saw General Equipment: Spot weld drill Bit
- 4. General Equipment: Air Body Saw





#### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment

instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

#### 501-30-40


### **REMOVAL AND INSTALLATION**

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation). 

 E112345

#### 4. • General Equipment: Air Body Saw




5. • General Equipment: Resistance Spotwelding Equipment




6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment

MIG	
E112348	· · · · · · · · · · · · · · · · · · ·

7. • General Equipment: Resistance Spotwelding Equipment



8. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



9. • General Equipment: Resistance Spotwelding Equipment



**10.** • Refer to: Quarter Panel LH - 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

# Rear Wheelhouse Outer — 5-Door

#### **General Equipment**

Air Body Saw

Metal Inert Gas (MIG) Welding Equipment


#### Removal

- 1. Refer to: Quarter Panel LH 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit


#### **General Equipment**


**Resistance Spotwelding Equipment** 

Spot weld drill Bit



- 3. General Equipment: Air Body Saw General Equipment: Spot weld drill Bit
- 4. General Equipment: Air Body Saw





#### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment

instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

#### 501-30-45


### **REMOVAL AND INSTALLATION**

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation). 

 E112345

#### 4. • General Equipment: Air Body Saw




5. • General Equipment: Resistance Spotwelding Equipment




6. • General Equipment: Metal Inert Gas (MIG) Welding Equipment

MIG	
E112348	

7. • General Equipment: Resistance Spotwelding Equipment



8. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



9. • General Equipment: Resistance Spotwelding Equipment



**10.** • Refer to: Quarter Panel LH - 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

# Inner Quarter Panel and Wheelhouse — 4-Door

#### **General Equipment**


Air Body Saw

Hot Air Gun

Measurement and Alignment Angle System

#### Removal

- 1. Refer to: Quarter Panel LH 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Refer to: Water Drain Panel 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - General Equipment: Measurement and Alignment Angle System
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit




#### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment


Resistance Spotwelding Equipment

Spot weld drill Bit


3. • General Equipment: Spot weld drill Bit




4. • General Equipment: Air Body Saw




5. • General Equipment: Spot weld drill Bit



6. Do not cut in panel below.General Equipment: Air Body Saw



7. • General Equipment: Hot Air Gun



#### Installation


1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).


2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).


- **3.** Continuous MIG weld seam on C-Pillar.
  - General Equipment: Metal Inert Gas (MIG) Welding Equipment




4. • General Equipment: Resistance Spotwelding Equipment




5. • General Equipment: Resistance Spotwelding Equipment




 6. Continuous MIG weld seam on C/D-Pillar.
 General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 7. Resistance spot weld Panel thickness 3 mm and greater!
  - General Equipment: Resistance Spotwelding Equipment



8. • General Equipment: Resistance Spotwelding Equipment



9. • Refer to: Quarter Panel LH - 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

Refer to: Water Drain Panel - 4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

# Inner Quarter Panel and Wheelhouse — 5-Door

#### **General Equipment**

Air Body Saw

Hot Air Gun


Measurement and Alignment Angle System

### Removal

- 1. Refer to: Quarter Panel LH 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Refer to: Water Drain Panel (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

General Equipment: Measurement and Alignment Angle System

- Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit




#### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment


Resistance Spotwelding Equipment

Spot weld drill Bit



4. • Cut all panel layers.


General Equipment: Air Body Saw General Equipment: Spot weld drill Bit




## **Rear End Sheet Metal Repairs**

## **REMOVAL AND INSTALLATION**

5. Do not cut in panel below.General Equipment: Air Body Saw




6. • General Equipment: Hot Air Gun



7. • Do not cut in panel below.

General Equipment: Air Body Saw General Equipment: Spot weld drill Bit



### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or


sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).


**3.** • Continuous MIG weld seam on C-Pillar.

General Equipment: Metal Inert Gas (MIG) Welding Equipment

- Puddle weld.
  - General Equipment: Metal Inert Gas (MIG) Welding Equipment




4. • General Equipment: Resistance Spotwelding Equipment




5. • General Equipment: Resistance Spotwelding

Equipment




6. • Resistance spot weld - Panel thickness 3 mm and greater!


General Equipment: Resistance Spotwelding Equipment



 Continuous MIG weld seam on C-/D-Pillar.
 General Equipment: Metal Inert Gas (MIG) Welding Equipment



8. • General Equipment: Resistance Spotwelding Equipment



 Refer to: Quarter Panel LH - 5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
 Refer to: Water Drain Panel (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

# Back Panel and Reinforcement — 4-Door

#### **General Equipment**

**Resistance Spotwelding Equipment** 

## Removal

- 1. Liftgate
  - Rear Bumper

Refer to: Rear Bumper Cover - 4-Door (501-19 Bumpers, Removal and Installation).


• Refer to: C-Pillar Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).


Refer to: Loadspace Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

- Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit


#### General Equipment


Spot weld drill Bit





4. • General Equipment: Spot weld drill Bit






### Installation


- 1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.
  - Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).


3. • General Equipment: Resistance Spotwelding Equipment



4. • General Equipment: Resistance Spotwelding Equipment



5. • General Equipment: Resistance Spotwelding Equipment



- 6. Liftgate
  - Rear Bumper
    - Refer to: Rear Bumper Cover 4-Door (501-19 Bumpers, Removal and Installation).
  - Refer to: C-Pillar Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Loadspace Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

# Back Panel and Reinforcement — 5-Door

### **General Equipment**

6 mm Drill Bit


### **General Equipment**

Metal Inert Gas (MIG) Welding Equipment


Spot weld drill Bit


### Removal

- 1. Liftgate
  - Rear Bumper
    - Refer to: Rear Bumper Cover (501-19 Bumpers, Removal and Installation).
  - Refer to: Loadspace Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit




E108815






5. • General Equipment: Spot weld drill Bit






7. • General Equipment: Spot weld drill Bit



8.




### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation). 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.


Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • General Equipment: 6 mm Drill Bit




4. • A CAUTION: 4 Panel puddle weld! Fit in both replacement panels exactly and drill holes for puddle welding.

General Equipment: 6 mm Drill Bit




5.




6. • General Equipment: Metal Inert Gas (MIG)


Welding Equipment



7.



8. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 9. Liftgate
  - Rear Bumper

Refer to: Rear Bumper Cover (501-19 Bumpers, Removal and Installation).

• Refer to: Loadspace Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: C-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

# Rear Lamp Mounting Panel — 4-Door

### **General Equipment**

6 mm Drill Bit

Metal Inert Gas (MIG) Welding Equipment


### Removal

- 1. Liftgate
  - Rear Bumper
    - Refer to: Rear Bumper Cover 4-Door (501-19 Bumpers, Removal and Installation). Refer to: Loadspace Trim Panel - 4-Door

(501-05 Interior Trim and Ornamentation, Removal and Installation). Refer to: Back Panel and Reinforcement -

4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

- Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Spot weld drill Bit



### **General Equipment**

Resistance Spotwelding Equipment

Spot weld drill Bit



4. • General Equipment: Spot weld drill Bit



5. • General Equipment: Spot weld drill Bit



### Installation

- 1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.
  - Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.
  - Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • General Equipment: 6 mm Drill Bit




4. • General Equipment: Resistance Spotwelding Equipment




5. • General Equipment: Resistance Spotwelding Equipment



- General Equipment: Resistance Spotwelding Equipment General Equipment: Metal Inert Gas (MIG)
  - Welding Equipment



 General Equipment: Resistance Spotwelding Equipment General Equipment: Metal Inert Gas (MIG)



- 8. Liftgate
  - Rear Bumper

Refer to: Rear Bumper Cover - 4-Door (501-19 Bumpers, Removal and Installation).

Refer to: Loadspace Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Back Panel and Reinforcement -4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

# Rear Floor Panel

### **General Equipment**

6 mm Drill Bit

Air Body Saw

Measurement and Alignment Angle System

### Removal

- 1. Liftgate
  - Rear Door
  - Rear Lamp
  - Rear Bumper
  - Rocker Panel Trim
  - Rear Seat Cushion
  - Rear Bumper Cover
  - Rear Wheel Arch Trim
  - Refer to: Liftgate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Rear Quarter Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: C-Pillar Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Loadspace Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Loadspace Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Back Panel and Reinforcement -4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation). Refer to: Back Panel and Reinforcement -

5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

- General Equipment: Measurement and Alignment Angle System
- Reposition the carpeting and the wiring harness away from the working area.
- 2. NOTE: Cut out inner part for better access.

General Equipment: Air Body Saw

### **General Equipment**


Metal Inert Gas (MIG) Welding Equipment

**Resistance Spotwelding Equipment** 


Spot weld drill Bit



3. • General Equipment: Air Body Saw




4. • NOTE: Left side shown. Operate similar at right side.



5. • **NOTE:** Left side shown. Operate similar at right side.

General Equipment: Spot weld drill Bit





### Installation

1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.

Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).

2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or

sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

3. • **NOTE:** Cut out the small part to adjust the spare part.


General Equipment: 6 mm Drill Bit General Equipment: Air Body Saw

	Ø 6 mm
E116038	

4. • General Equipment: Metal Inert Gas (MIG) Welding Equipment

MIG	
-	
E116039	

 General Equipment: Resistance Spotwelding Equipment
 General Equipment: Metal Inert Gas (MIG) Welding Equipment




6. • General Equipment: Resistance Spotwelding Equipment

The second	1	A TON	and the second second		
1 - Contraction	de la	formain M.	and the second second		
THE		•••	• •	• •	•
	••	• • •	• • •	• •	

7. • NOTE: Left side shown. Operate similar at right side.

General Equipment: Resistance Spotwelding Equipment



8. • **NOTE:** Left side shown. Operate similar at right side.

Welding Equipment

General Equipment: Metal Inert Gas (MIG)

9. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 10. · Liftgate
  - Rear Door
  - Rear Lamp
  - Rear Bumper
  - Rocker Panel Trim
  - Rear Seat Cushion
  - Rear Bumper Cover
  - Rear Wheel Arch Trim
  - Refer to: Liftgate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Rear Quarter Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: C-Pillar Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Loadspace Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Loadspace Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Back Panel and Reinforcement -4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
    - Refer to: Back Panel and Reinforcement -5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - General Equipment: Measurement and Alignment Angle System
  - Reposition the carpeting and the wiring harness away from the working area.

### **Rear Side Member Section**

#### **General Equipment**

Air Body Saw

Metal Inert Gas (MIG) Welding Equipment


#### Removal


#### **General Equipment**


Resistance Spotwelding Equipment

Spot weld drill Bit

- 1. Liftgate
  - Rear Lamp
  - Rear Bumper
  - Rear Wheel Arch Trim
  - Tank Filler Flap and Tank Filler
  - Refer to: Liftgate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Rear Quarter Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Loadspace Trim Panel 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Loadspace Trim Panel 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).
    - Refer to: Back Panel and Reinforcement -4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation). Refer to: Back Panel and Reinforcement -5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).
  - Reposition the carpeting and the wiring harness away from the working area.
- 2. General Equipment: Air Body Saw







4. • General Equipment: Air Body Saw



 General Equipment: Metal Inert Gas (MIG) Welding Equipment



#### Installation

- 1. NOTE: Before resistance spot welding of body panels with a total panel thickness of 3 mm and greater, the manufacturer's welding equipment instructions and sub-section 501-25 must be followed.
  - Refer to: Tools and Equipment for Body Repairs (501-25 Body Repairs - General Information, Description and Operation).
- 2. NOTE: Sealer or adhesive must not be applied in welding zones. Areas which were bonded or sealed needs to be thoroughly sealed afterwards.

Refer to: Sealer, Underbody Protection Material and Adhesives (501-25 Body Repairs -General Information, Description and Operation).

4. • General Equipment: Resistance Spotwelding Equipment



5. • General Equipment: Metal Inert Gas (MIG) Welding Equipment



- 6. Liftgate
  - Rear Lamp
  - Rear Bumper
  - Rear Wheel Arch Trim
  - Tank Filler Flap and Tank Filler
  - Refer to: Liftgate Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Rear Quarter Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Loadspace Trim Panel - 4-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Loadspace Trim Panel - 5-Door (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: Back Panel and Reinforcement -4-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

Refer to: Back Panel and Reinforcement -5-Door (501-30 Rear End Sheet Metal Repairs, Removal and Installation).

## **SECTION 501-36 Paint - General Information**

#### **VEHICLE APPLICATION: 2011 Fiesta**

CONTENTS

PAGE

### PAGE 1 OF 2

#### **DESCRIPTION AND OPERATION**

Description and Usage of Paint Literature	501-36-3
Symbols	501-36-4
General	501-36-4
Hazardous materials designations	501-36-4
Instructions on measures to be taken for personal protection	501-36-6
lcons	501-36-6
Health and Safety Precautions	501-36-9
General instructions for the paint shop and handling paint materials	501-36-9
Personal protection	501-36-9
Environmental Regulations	501-36-11
Waste disposal in the repair paint shop	501-36-11
The new VOC (Volatile Organic Compounds) solvent regulation	501-36-11
Factory Paint Application	501-36-12
General fundamentals of paint technology	501-36-12
Painting process and corrosion protection	501-36-12
The structure of an original paint finish	501-36-13
Colored fillers applied in production	501-36-13
Paintwork Defects and Damage	501-36-14
Diagnosis and Damage Assessment	501-36-14
Paint damage guide	501-36-14
Paint damage caused by environmental factors	501-36-14
Mechanical damage	501-36-18
Damage due to corrosion	501-36-18
Damage caused by faults in treatment	501-36-18
Tools and Equipment for Paint Repairs	501-36-28
General work equipment	501-36-28
Filler and spray guns	501-36-28
Hand and machine sanding tools	501-36-30
Polishing and finishing tools	501-36-33
Infrared drying technology	501-36-33
Air dryers	501-36-33
Paint mixing system	501-36-34
Painting cabin	501-36-34
Refinishing Materials	501-36-35
Stopper materials	501-36-35
Primers	501-36-36
HS primer filler and HS tinted filler	501-36-37
Paint	501-36-37
Additional Materials	501-36-39
Adhesive sealants	501-36-39
Underbody protection	501-36-39
Paint additives	501-36-40
Additive materials	501-36-42
Paint Repairs	501-36-43

#### PAGE 2 OF 2

General information	501-36-43
Pre-treatment of the surface	501-36-43
Top coat application	501-36-45
Repair stages for repair painting	501-36-46
Polish	501-36-47
Aids	501-36-48
Painting Plastic Parts	501-36-49
General	501-36-49
Plastic groups	501-36-49
Painting new components	501-36-50
Unknown primer	501-36-50
Paint faults on plastic substrates	501-36-51
Spot Repairs	501-36-52
General	501-36-52
Repair process	501-36-53
Dirt inclusions	501-36-54
Corrosion Prevention	501-36-56
General	501-36-56
Operations after painting	501-36-56
Definition of the degree of rust	501-36-56
Color Identification and Chromatics	501-36-58
Basic color theory	501-36-58
Metallic and pearl pigments	501-36-59
Color codes and their determination on Ford vehicles	501-36-60
Matching tinted filler to the color code	501-36-63
Tips and Tricks	501-36-64
Comparing paint structures	501-36-64
Etching substrate	501-36-64
Masking the vehicle	501-36-64
Color shade problems	501-36-66
Isopropanol and water	501-36-66
Temperature reduction spray	501-36-66
Paint plane	501-36-66
Shading	501-36-66
Sanding marks	
Improving touch-up work	501-36-67

## Description and Usage of Paint Literature

Vehicle paints are subject to severe demands caused by external influences. Moisture, air-borne deposits in the form of various chemicals and UV light constantly affect a paint surface. Furthermore, mechanical damage occurs through grit, stones and sand. Bird droppings, insect residues, pollen and tree sap also attack the paint surface.

The present literature not only informs the specialist about current repair painting techniques, but also provides tips and instructions on modern and economical repair processes.

High quality bodywork paints require the use of the most modern technologies and regular updating of the technician's knowledge of painting techniques, because of the constantly new developments in paint technology.

Information about different materials is listed under Specification.

Furthermore, information on the fundamental principles of repair painting and paint materials is provided in several chapters. The safety instructions indicate the possible health hazards and other sources of danger. There are also notes about tools and materials as well as on basic painting methods.

In the model specific repair instructions, only the most important repair steps or special features are referred to. Detailed information on the generally applicable painting procedures is given in this paint manual.

Direct supply of repair paints by Ford has been discontinued. There is however an agreement with many paint manufacturers, which ensures fast and problem-free supply to the dealer undertakings.

Paint suppliers:

- DuPont
- Glasurit
- PPG
- Sikkens
- Spies Hecker
- Standox

When using painting materials, it should be taken into account that the manufacturers have exactly matched their products between each other. In order to avoid quality defects, difficulties in working and losses in corrosion protection, these may not be substituted with other products. **NOTE:** The Ford Service Organization organizes basic and more in-depth training on much of the content of this paint manual. As well as the practical part of the training, a further component is the Student Information document, which offers supplementary information in the form of a brochure.


During all work it must always be ensured that personal safety and the operational capability of the vehicle are not threatened by the choice of methods, tools and components.

The information given in the diagrams in the chapter "Paint Damage" is provided by the repair paint manufacturer.

### Symbols

#### General

Various symbols, signs, instructions and illustrations are used in this literature. Warnings and cautions have different meanings and require different ways of proceeding. Diagrammatic representations are provided with instructional signs for improved clarity. These are briefly explained below:



CAUTION: This caption is used when incorrectly following the test procedures or instructions or failure to follow them at all could lead to damage to the vehicle or components. **NOTE:** This caption is used when attention needs to be drawn to special or extra information.

When reading this handbook, you will come across the points WARNING, CAUTION AND NOTE. These instructions are always given immediately before the corresponding job steps.

#### Hazardous materials designations

Many accidents occur because of ignorance. In the area of personal health protection, it is particularly important to clearly emphasize sources of danger and their effects on human organs.

Only with knowledge of hazardous material designations can it be certain that the necessary precautions are taken when handling substances which are harmful to health.

**NOTE:** Pay attention to the manufacturer's data on the containers and given in the Safety Data Sheet.

#### Hazardous material symbols



E59393

ltem	Description
1	Very poisonous, T+ (extremely toxic), small quantities can be fatal.
2	Poisonous, T (toxic), causes serious damage to health
3	Corrosive, C (corrosive), destroys living tissue.
4	Harmful to health, Xn (noxious).
5	Irritant, Xi (irritant), can cause inflammation.

ltem	Description
6	Explosive
7	Highly flammable, F+ (extremely flammable), already flammable at temperatures below 0° C.
8	Flammable, F (flammable), forms a flammable mixture with air.
9	Oxidizing, O (oxidizing), reacts with combustible substances.

As well as the danger symbols, there is more comprehensive manufacturer's information to be

found on the containers and in the Safety Data Sheets, and you must pay attention to this information.

## Instructions on measures to be taken for personal protection.

As well as the information about sources of danger, there are mandatory instructions which draw your attention to the personal protection measures to be taken.

#### Mandatory symbol




ltem	Description
1	Breathing protection must be worn
2	Eye protection must be worn
3	Ear protection must be worn
4	Protective gloves must be worn
5	Protective footwear must be worn

#### lcons

So that the necessary information for optimal handling is clear, unambiguous and can be quickly understood, the leading paint manufacturers have

agreed a standard symbolic language. Language independent representations in the form of icons provide handling instructions which are supplemented with quantity or time information.


#### Pretreatment



#### E59395

ltem	Description
1	Clean
2	Sand

#### Mix




ltem	Description
1	2 component mixture
2	3 component mixture

### **Paint - General Information**

### **DESCRIPTION AND OPERATION**


ltem	Description
3	Use a measuring rod
4	Addition of hardener
5	Addition of additives

#### Process



E59397

ltem	Description
1	Flow-beaker spray gun
2	Suction-beaker spray gun
3	Spray passes
4	Filler
5	Coat
6	Underbody protection spray gun



Item	Description
1	Ventilate
2	Drying time
3	Drying time with infra-red dryer

#### Further processing




E59399

ltem	Description
1	Hand abrade (wet)
2	Hand abrade (dry)
3	Eccentric sander (wet)
4	Eccentric sander (dry)

ltem	Description
5	Oscillating sander (wet)
6	Oscillating sander (dry)

#### Store



ltem	Description	
1	Protect from moisture	
2	Store in a frost-free environment	
3	Store in a cool place	
4	Close the container	

#### Other



Item	Description	
1	Stir by hand	
2	Stir using a mixing machine	
3	Polish	
4	Roll	

### Health and Safety Precautions

## General instructions for the paint shop and handling paint materials

Hazardous areas in repair paint shops:

- Danger from fires, explosions and hot surfaces.
- Dangers to health and safety from the effects of harmful substances because of their absorption through the skin and/or inhalation.
- Dangers caused by electricity, compressed air, power tools and noise.

WARNING: During painting work there is an increased danger of fire or explosion. Prevent any sparks being created. Fire, naked lights and smoking are forbidden.

Measures:

- Wear protective footwear made from anti-static material.
- Only use tools made of wood, brass or copper to clean stands and extraction ducts. Do not use tools made of steel.

Only fill or decant paint materials in a specially marked area.

As well as these general instructions on the dangers in repair paint shops, all national and international regulations must be observed:


- Health and Safety at Work Act
- Ordinance on Hazardous Substances
- Technical Rules for Hazardous Substances
- Regulations for the Prevention of Industrial Accidents
- EU Directive on Hazardous Substances, 98/24/EU
- EU Directive on Noise, 2003/10/EU
- EU Directive on Volatile Organic Compounds (VOC), 1999/13/EU, 2001/81/EU, 2004/42/EU
- Safety instructions of equipment and tool manufacturers

#### **Personal protection**

Besides the body and limbs, several organs vital to life are in very particular danger. Because damage is mostly irreparable, special attention and comprehensive protection are necessary.



eyes or on the skin can cause bodily harm. When working with solvents, always use suitable means of protection.



ltem	Description	
1	Protective hood with fresh air supply	
2	Protective clothing	
3	Protective gloves	
4	Protective footwear	

#### **Breathing protection**

During painting work and in the preparations for painting, gases, vapors, mists or dusts can appear in dangerous concentrations in the areas where fellow employees breath.

For short periods of work or minimal concentrations of hazardous substances, breathing protection devices with a combination filter are suitable as breathing protection equipment.



ltem	Description
1	Activated charcoal filter
2	Coarse filter

For higher concentrations of harmful substances, breathing protection devices which are independent of the local atmosphere are suitable.

In these types of isolation systems, a compressed air hose carries natural air from the compressor line into the protective mask. During supply, the air undergoes pressure reduction, water removal, fine filtration and usually warming to natural breath temperature.

WARNING: Vapor or spray mist containing isocyanate as a paint base or hardener can cause toxic respiratory disease (conditions similar to asthma) leading to permanent damage, even when inhaled in the lowest concentrations.

Filter masks with wadding, sponge or colloid filters and also paper masks are all unsuitable for working with coating materials because they do not stop solvent vapors.

The instructions for use provided by the manufacturer must be observed when working with breathing protection equipment.

#### **Skin protection**

Spray painters who are subject to considerable exposure to coating materials must wear suitable protective work clothing (flame-proof and anti-static).

**NOTE:** Also, when working with water based materials, comprehensive skin protection must be worn, because these materials are very easily absorbed through the skin.

The protective clothing must be changed at the proper intervals. Items of clothing which are contaminated with coating materials can easily catch fire.

When selecting protective clothing, it must be taken into account that cloth containing a high proportion of easily melted plastic thread considerably increases the degree of burns injury (melted plastic on the skin!). This must also be taken into account in the choice of underwear.

For areas of skin which are not covered by protective clothing, suitable skin protection, skin cleaning and skin care agents must be used.

#### Eye protection


Working with portable hand sanding machines on which the tools move unguarded, at speed and with power is fundamentally dangerous.

Goggles must be worn not only when sanding, but also when working with paints and their additives. These contain substances which are harmful to the eyes. Damage ranging from irritation of the cornea to incurable illnesses are possible.

The protective goggles must be inert toward splashes of solvent, and fully enclose the areas at the side of the eyes on both sides. The best protection during spray painting is offered by full mask respirators or helmet respirators with a built-in visor.

#### Ear protection

Noise disturbance in repair paint shops caused by various sources is particularly high. Sanding and compressed air machines, paint cabin extractor fans (compressors) and extractor ducts in the work rooms are the causes of the high levels of noise.



Suitable ear protection is offered by ear plugs or ear defenders.

### **Environmental Regulations**

#### Waste disposal in the repair paint shop

More than ever before, since the introduction of EU directives, rigorous attention is paid to the avoidance of waste materials and to recycling in repair paint shops. In this respect, repair paint shops must take into account and comply with the following requirements:

- Separate waste according to its recycling and disposal methods.
- Produce evidence for the correct transport and disposal of waste.

**NOTE:** The organization of disposal in the plant must comply with the requirements of the Waste Avoidance and Management Act: The avoidance and recycling of waste must always take priority.

However, despite all measures which may be taken, waste cannot be completely avoided.

**NOTE:** Waste which is not allowed in household rubbish, and which can no longer be utilized, must be disposed of as special waste.

Paint residues containing solvent, application residues, sanding dust, waste containing peroxides, solvents, soiled cleaning cloths and paint slurry all count as special waste. Each of these must be collected in a separate, sealed and suitably labeled metal container and properly disposed of using a specialist company.

Careful separation allows some waste to be usefully re-used.

- Empty metal containers can be sent for scrap instead of being disposed of as waste.
- Contaminated cleaning thinners can be separated by distillation.
- Packing material and masking paper can be added to the recycled paper collection.

Residues which cannot be used must be correctly disposed of.

All remaining waste must be treated as commercial waste and disposed of according to the local regulations.

## The new VOC (Volatile Organic Compounds) solvent regulation

Keeping the air clean protects the environment and the population from the heath-damaging effects of air pollutants.

In certain atmospheric conditions, volatile organic compounds contribute to summer smog.

**NOTE:** For comprehensive information, please refer to the European VOC Directive, 1999/13/EU. Furthermore, the effective national regulations must be complied with.

The European VOC (Volatile Organic Compounds) Directive has controlled the limits for such compounds since August 2001. It applies to production coating companies and those which undertake repair painting of private and commercial vehicles.

Not least because of the VOC legislation, modern, low solvent and solvent-free lacquers and paints are finding greatly increased distribution across industry and the trade. Up to the year 2007, emissions from painting work will drop by at least 40%.

At the same time, the paint manufacturers guarantee for example that they will produce a ready-to-spray product consisting of base paint + hardener + thinners, with a permitted VOC level.

A company in business today can conform with the stipulated requirements by introducing water-based paints and using the other necessary products from the relevant paint manufacturers.

For more detailed information, please refer to the EU VOC Directive.

### **Factory Paint Application**

## General fundamentals of paint technology

Paint is a pigment-containing liquid which undergoes chemical and/or physical processes after it has been applied to a surface, so changing into a solid film covering.

Repair paint consists of binder, pigments, filler and solvent.

**NOTE:** Organic solvent is being replaced by solvent based on water.

Constituents of paint

- Binder
  - Mostly semi-fluid resins which bind together the other components of the paint when it dries.
  - Makes the paint durable.
  - Ensures good surface coverage.
- Pigments
  - Fine, colored powders, which give color to the paint.
  - Cover the components below (covering power).
- Additives
  - Additives give the paint special properties.
  - e.g. flow improver, softener, drying accelerator, thickener.
- Solvent
  - Thins the paint and allows it to flow more freely.
  - Evaporates during drying.

## Painting process and corrosion protection.

In production, painting consists of individual steps which are optimally matched to each other.

Bodywork consists almost entirely of steel panels which have been pre-coated with zinc. The zinc layer is between 5-10  $\mu$ m thick and acts as the first corrosion protection layer of the steel panel.

Production sequence:

- Clean and de-grease
  - In the first step, the bare bodywork is initially dipped in a cleaning bath and cleaned with a degreasing solution.
- Phosphatising
  - The cleaned bodywork is dipped in a bath containing various phosphate salt solutions. This creates a crystalline metal-phosphate layer which offers the optimal prepared surface and also corrosion protection.
- CDP base
  - The cataphoretic dip paint (CDP) base acts as a further corrosion protection layer.
  - In this process the bodywork is completely immersed in a bath consisting of a paint and electrolyte solution.
  - By application of an electric voltage, an electric field is created.
  - Positively charged paint particles settle on the negatively charged bodywork and form a protective layer up to 20 µm thick.
  - Next the bodywork is placed in a dryer, where the CDP base is hardened at 180°C.
- Sealing, stone-chip protection
  - Edges, seams and but joints are sealer with a sealing compound.
  - Vulnerable areas are coated with stone-chip protection.
- Filler
  - Filler protects the body panels from stone impacts. Furthermore, any unevenness of the metal surface is flattened out, in order to create the most homogenous and fault-free undersurface possible.
  - Once the filler is dry, it serves as the base on which paint is applied.
- Top coat
  - The top coat is applied as a single layer or two layers of paint.
  - When working with two layer paint, in the first job step the initial colored base paint is applied. In the second job step, a clear lacquer is applied, giving the base paint shine and hardness.


#### The structure of an original paint finish

During construction of the original paint, a total surface thickness of between 120 and 130  $\mu$ m is achieved. The thicknesses of the layers may vary however, because they are greater for horizontal surfaces than vertical ones.

Not every exterior paint has its own matching filler. It is more that the tones of the filler are color compatible, i.e. they have similar intensity to the top coat.

During repair painting the filler color tones must be used according to the manufacturer's instructions.

#### **Paint layers**



ltem	Description
1	Steel panel
2	Phosphate layer 2.9 g/m <sup>2</sup> , corresponding to 2 $\mu$ m.
3	Cathodic dip paint 30-35 µm
4	Filler 30-35 µm
5	Base paint 15-20 µm
6	Clear varnish 55 µm

#### Colored fillers applied in production

Filler which gives color is used in production. Its use makes the base paint and clear varnish unnecessary on certain vehicle interior surfaces (engine, doors).

### Paintwork Defects and Damage

#### **Diagnosis and Damage Assessment**

Paint concerns, regardless of their causes, are part of the everyday work in the paint shop. Correct damage assessment and determination of the cause are preconditions for a professional resolution of a paint concern.

Paint concerns can still occur through a variety of causes, despite improved paint materials and new spray methods.

**NOTE:** A first appraisal of the paint damage should be done before cleaning. External factors such as rust, droppings, incorrect or insufficient paint care can then be more easily detected.

Diagnosis is best done in daylight but not in direct sunlight. Exact evaluation can also be done under artificial light from special luminescent lamps.

#### Paint damage guide

The most important paint damage concerns which make a paint repair necessary are:

- Damage from biological paint contamination such as bird or insect droppings, tree resin and aphids.
- Chemical paint damage caused by industrial contaminants such as smoke, fuel, acids, oils.
- Mechanical damage caused by stone impact during operation, scratches in the car wash and parking.
- Damage caused by faults in treatment. Application defects such as paint runs or orange peel.
- Dirt inclusions in the paint layer, e.g. caused by dust in top coat or textile lint.
- Damage due to corrosion.

Before repair of such paint concerns, exact diagnosis must be performed to determine the cause exactly. On the spot diagnoses using simple aids and processes are often enough.

Diagnosis without disturbing the paint is done by:

- Optical inspection without visual aids, under suitable light conditions from a suitable angle and correct distance.
- Optical inspection with the help of a magnifying glass.

- pH paper.
- Measurement of the thickness using FE / NFE coating thickness meters for ferrous (FE) and non-ferrous metals and non-magnetic steel (NFE) - magnetic process on steel panels, eddy current process on non-metals.

A test method where the traces of testing can be easily removed again is the finger nail test. With suitable experience the existing hardness of the paint can be determined.

Test methods where the paint is partially destroyed are:

- Pencil hardness test.
- · Adhesion test using adhesive tape.
- Lattice cut test process to check the strength of adhesion.

Under certain circumstances these test methods are not enough for a certain diagnosis. In this case, paint diagnosis under laboratory conditions must be performed.

## Measuring and testing equipment for painted surfaces

Coating thickness measuring devices

Magnifying glass

pH paper (together with water)

Suitable photographic equipment with macro lens

Shine measuring equipment

## Paint damage caused by environmental factors

- Bee droppings
- Bird droppings
- Insects
- · Tree resin and sap
- · Aphid secretions
- Tar spots
- Cement, plaster and slaked lime
- Rust film/deposits from industrial fallout
- · Battery acid
- Brake fluid


In all the cases of paint damage described below, if the damage is irreversible a new paint finish must be applied.

#### Paint damage cause by bee droppings

Bee droppings can be recognized on a paint surface through its yellow or brown color and sausage or drop-like shape with a diameter of 3-4 mm.

Cause/damage pattern:

- In combination with heat and high air humidity, bee droppings leave discolorations and cause paint decomposition.
- The paint can be destroyed down to the filler.



Repair of damage:

• If the damage is light, perform a polishing repair.

#### Paint damage caused by bird droppings

Bird dropping damage appears most often as matt, etched topcoat areas of various sizes. If left on the vehicle for a long time, crack formation and etching down to the filler will occur.

Cause/damage pattern:

- Bird droppings are particularly harmful in combination with heat and moisture. The urea (white part) has a very high salt content and is very aggressive.
- The intensity of the damage varies depending on the type, quantity, contact time and extent.
- Cracks, etching, marks up to dissolution of the top coat are the results.



Repair of damage:

• If the damage is light, perform a polishing repair.

#### Paint damage caused by insects

At insect impact locations on the hood, roof and bumper, small etched or etched through paint marks with partially visible spots of filler.

Cause/damage pattern:

- The top coat layer is destroyed in a short time by surface swelling and etching.
- Colliding insects stick to the paint surface. In combination with moisture and heat, because of the resulting acids the insect bodies sink into the paint top coat.
- The corrosion is G, C, U or O shaped and is only a few millimeters thick.



Repair of damage:

- Wash the vehicle, treat the affected area with insect remover. Clean the paint surface several times.
- Protect with hard wax.

#### Paint damage caused by tree resin or sap

Small yellow-brown marks or drops on the horizontal parts of the vehicle. The drops melt in sunlight. Resin damage only occurs in the warm summer months.

Cause/damage pattern:

• Because of their chemical composition, tree resins combine with or adhere very well to paint top coats and cause them to swell. The higher the temperature, the more intensive is the chemical bonding between the resin and the paint topcoat surface.



Repair of damage:

• Soak several times using a cloth saturated with a petrol & paraffin mixture.

**NOTE:** After successful cleaning the top coat must be preserved.


• Swellings can be removed by warming.

#### Paint damage from aphid secretions

Small, round, matt marks about 1 mm diameter and etching with small islands down to the filler. Fresh aphid excrement looks like small drops of honey.

Cause/damage pattern:

- Aphids produce a mixture of starch, leaf acid and sugar from sap in leaves. Under the effects of warming and moisture this can turn into alcohol.
- The round shape of the damage and the island of intact paint are typical.



Repair of damage:

- · Remove the excrement as soon as possible.
- Small single matt locations without etching can be repaired using a polishing repair.

#### Paint damage caused by tar spots

Yellow or dark marks.

Cause/damage pattern:

• Firmly stuck spots of tar which lead to discoloration of the surface. In some cases penetration through the clear lacquer into the top coat.



Repair of damage:

• Clean the paint surface with tar remover and polish.

## Paint damage caused by cement, plaster and slaked lime

Damage appears as whitish matt marks on the top coat.

Cause/damage pattern:

 Corrosive alkaline compounds interacting with moisture.



Repair of damage:


- Wash immediately if the contamination is fresh.
- If the contamination has dried on, dissolve and neutralise it with vinegar, then thoroughly wash off with water and rinse.
- Rectify mild damage using a polishing repair.

#### Rust film/deposits from industrial fallout

Small round marks, about 1 mm in size, in all shades from black, grey, blue to reddish, on the horizontal surfaces of the vehicle.

Cause/damage pattern:

- Deposits from oil fired systems and industrial plant, especially at high humidities and inversion weather conditions, cause damage to the paint top coat.
- As the activity time increases so called rust halos form. They spread as long as the deposits corrode.
- Industrial fallout containing iron will no longer be removable after a few days!



Repair of damage:

- Remove the dust using an industrial fallout remover and thoroughly wash.
- Polish the paint surface.

**NOTE:** Never try to remove the particles of industrial fallout by polishing or rubbing!

· Use cleaning dough.

#### Damage caused by battery acid.

Splashes of battery acid caused by carelessly topping up the battery.

WARNING: Batteries contain sulphuric acid. When working near the battery, or where there is battery acid on the vehicle body, protect the skin and eyes from contact with the acid. If battery acid contacts the skin or enters the eyes, flush the affected area immediately with water (flush for at least 15 minutes) and call a doctor without delay. If acid is swallowed, call a doctor immediately. Failure to follow these instructions may result in personal injury.

**NOTE:** High temperatures accelerate the attack on the top coat. At 50°C the top coat layer breaks down after about 15 minutes!

Cause/damage pattern:

• Etching of the paint layer to decomposition of the paint finish.



Repair of damage:

- Flush the acid splashes with plenty of water and neutralize with car washing liquid.
- If the contact time of the acid was short, perform a polishing repair.

#### Paint damage caused by brake fluid.

Careless handling of brake fluid. The glycols contained in the fluid cause swellings.

Cause/damage pattern:

 The temperature and contact time are critical. Splashes lead to loss of shine and lightening of color.



Repair of damage:

- Flush immediately with plenty of water.
- The swellings can often be made to recede completely by treatment with the radiant heater or in the paint drying oven at max. 60°C for about 1 hour.

#### Mechanical damage

## Stone impact damage or mechanical damage

Mechanical damage caused by impact of stones or other hard objects and extending down to the metal panel lead very quickly to corrosion and rusting under the paint on the adjoining surface.

Cause/damage pattern:

• Paint damage caused from the outside, down to filler, primer or metal panel.



Repair of damage:

- Sand or blast out.
- Use anti-corrosion primer.
- Apply top coat.

#### Damage due to corrosion

#### **Blistering/rusting below**

Air or water filled blister-shaped raised areas in the paint film.

Cause/damage pattern:

- Overpainting corroded steel panel.
- · Condensation in the spray air.
- Sanding water not dried out or salt crystal residues.
- Road chippings and road winter grit containing salt.



#### Repair of damage:

- Sand the affected area of damage or the body component and re-create the paint finish.
- More severe and larger areas of rusting below must be repaired using the corresponding repair painting, Repair Level III or IV.

#### Damage caused by faults in treatment

- Craters
- Paint boils
- Adhesion defects
- Adhesion defects clear lacquer
- · Sanding scores
- · Formation of stripes
- · Peeling/blistering on plastic parts
- Blistering on polyester material
- · Peroxide marks in metallic paints


- Crack formation
- Shrinking back/zone edge marks
- Blistering
- Etching
- Paint wrinkles/puckering
- Cloud formation
- Spots/metallics
- Metamerism/color deviations
- · Washing out
- Loss of gloss
- Covering ability/areas of thin paint
- Flow problems/orange peel
- Dirt embedded in metallic base paint
- Dirt embedded in top coat
- Water marks
- Paint runs
- Swirl marks

#### Craters

Crater-like single or extensively occurring depressions with raised edges, in top coat or the intermediate layers.

Cause/damage pattern:

- Substrate not adequately cleaned with silicone remover.
- Spray air contaminated by oil residues and water accumulations.
- Filter ceiling not adequate for requirements.
- Use of polishes, cleaning agents or sprays (e.g. interior sprays) containing silicone.
- Oil, wax, grease, silicone containing residues.
- Working clothes contaminated by materials containing silicone.



Repair of damage:

 Sand paint surface, clean with silicone remover and apply one thin spray pass. Let it begin to dry well, then apply several thin and dry sprayed passes.

#### **Paint boils**

Small, hard, closed or burst blisters in the paint top coat. They appear locally in groups or spread individually across the whole surface. Sanding opens up a larger cavity, under which the primer can often be seen.

Cause/damage pattern:

- Paint applied in layers which were too thick.
- Specified flash-off and drying times between coats were not adhered to.
- Specified working viscosity and spray pressure were not adhered to.
- Use of unsuitable hardener and thinner materials. (Solvent combinations in paint system not optimally matched).
- Poor booth conditions.



#### Repair of damage:

- Single boil blisters can be removed using polishing.
- After thorough drying, sand the top coat at the affected areas, clean with silicone remover and re-paint. Fill any fine pores still present with 2-component acrylic filler.
- On larger areas of damaged topcoat, sand completely away and apply new paint finish.

#### Adhesion defects

Whole coating detached from substrate or individual layers one from another. Sometimes

#### **Paint - General Information**

#### **DESCRIPTION AND OPERATION**

adhesion defects can only be noticed after an external influence such as stone impact.

Cause/damage pattern:

- Substrate not adequately prepared (rust, grease, moisture, sanding, cleaning).
- Unsuitable material used.
- · Drying times, flash-off times too short.
- Base paint not sprayed wet-in-wet, instead the intermediate drying times were too long.
- · Failure to intermediate sand.
- Condensation formed because of temperature fluctuations.
- Unprofessional preparation (especially on plastics).
- Overheated CDP/intermediate filler.



Repair of damage:

• Sand out the damage and recreate the paint finish. Create the paint finish strictly in accordance with the general technical information.

#### Adhesion defects in clear lacquer.

Clear lacquer detched from base paint.

Cause/damage pattern:

- Base paint layer too thick.
- Intermediate and final flash-off times of base paint too long.
- · Incorrect mixture ratio clear lacquer/hardner.



Repair of damage:


• Refinish sanding and recreate the paint finish.

#### Sanding scores

Single or wide area clusters of scoring or sanding marks, often with raised edges. Noticeable on metallic paints as light-dark stripes.

Cause/damage pattern:

- · Stopper sanded too coarsely.
- · Filler sanded too coarsely.
- Filler not thoroughly dried bfore sanding.
- · Old paint sanded too coarsely.
- Soft elastic substrates, e.g. TPA base, treated with thinners which was too aggressive and therefore etched.
- Top coat applied too thinly.



Repair of damage:

- If the damage pattern is minimal, after the top coat has dried fine sand the paint surface and refurbish by polishing.
- If the damage is great or on metallic paints, sand the paint surface or substrates and if necessary remove them, then cover the bare metal and re-paint.

#### **Formation of stripes**

Differing, stripe shaped color/effect formations in dark/light areas of a metallic paint finish.

Cause/damage pattern:

- Spray gun (nozzle) not perfect.
- Incorrect spray pressure.
- Thinners not suitable.
- · Incorrect spray viscosity.
- Flash-off time too short.
- Unsuitable working temperature.



Repair of damage:

- Apply base paint evenly.
- · Repair spray gun.
- After clear lacquer has thoroughly dried, sand surface and paint again.

#### Peeling/blistering on plastic parts

Paint adhesion insufficient between top coat and filler and/or primer layer. It often happens that the whole of the paint finish detaches from the plastic.

Cause/damage pattern:

- Plastic item not cleaned sufficiently, not or inadequately tempered.
- Unsuitable cleaning agent used.
- Unsuitable materials used.
- Moisture.
- · Paint finish underbaked or overbaked.
- · Poor or lack of intermediate sanding.



Repair of damage:

- Sand away faulty paint coats and re-apply paint finish.
- In extreme cases use a new part.

#### Blistering on polyester material

Color shade differences or marks in paintwork subsequently applied to previously unpainted plastic material.

Cause/damage pattern:

- Plastic material is not suitable for painting.
- Incorrect bonding agent.
- Paint used not solvent resistant.

Repair of damage:


- Repaint using suitable materials.
- Install unpainted new part (after consulting customer).

#### Peroxide marks in metallic paints

After longer period of drying, abnormal marks where the color shade varies.

Cause/damage pattern:

- Too much hardener added to polyester stopper (over 3% can cause this damage pattern).
- Polyester stopper not well enough mixed.



Repair of damage:

• Sand, fill with polyester or epoxide filler and re-paint.

#### **Crack formation**

Cracks of different lengths and depths running in all directions.

Cause/damage pattern:

- Layers too thick.
- Painted several times.
- Temperature fluctuations.
- Mechanical effects e.g. distortions.
- Substrate not thoroughly hardened.
- Old paint not completely dried out.
- No or insufficient hardener added.
- 2-component materials used on nitro or TPA.



Repair of damage:

• Sand away layers until sound substrate is reached and create new paint finish (prime, fill, apply topcoat).

#### Shrinking back/zone edge marks

Lifting or dropping in of edge zones (edges which accentuate themselves in the top coat), flow problems and loss of shine in top coat.

Cause/damage pattern:

- Old paintwork not rubbed down to a seamless transition.
- Stopper and filler on a viscoplastic base primer.
- Filler sanded and overpainted when not thoroughly hard.
- Previous materials overworked too early, substrate not sufficiently hardened.
- Primer applied in layers which were too thick, and not dried for long enough.
- Sanding paper too coarse.
- Top coat thinned too much.



Repair of damage:

 After hardening off the top coat, fine sand the surface and polish up, apply filler if necessary and paint once more.

#### Blistering

Small, spot-like, air-filled or water-filled blister shaped high-spots in the paint construction. Their dimensions can range from pin-head to pin-point size in a closed paint film. Arrangement and accumulation very variable. In the advanced stages, circular flaking of the paint from the substrate. These are neither boils nor corrosion.

Cause/damage pattern:

- Moisture absorption by substrate.
- Insufficient drying of the substrate after wet sanding (especially on polyester material).
- Humidity too high before painting; condensation formation because of temperature fluctuations.
- Pores/sink holes in substrate not sanded out.

- Polyester material not covered.
- Sweat from hands.
- Salts and minerals in sanding water.
- Spray air contaminated.



Repair of damage:

• Sand away damage, matt sand remainder of surface, clean with silicone remover, fill and re-paint.

#### Etching

The base paint is etched by the clear lacquer. This causes the aluminum pigments to change their alignments. The color of the etched base paint seems more grey than that of normal base paint. Result is that the surface structure of the clear lacquer becomes increasingly more matt.

Cause/damage pattern:

- Base painted too wet.
- No intermediate flash-off time.
- Layers too thick.



Repair of damage:

• Sand and re-paint.

#### Paint wrinkles/puckering

Lifting/puckering of the paint surface.

Cause/damage pattern:

- First paint not hardened through or can be etched.
- Areas of clear lacquer which were sanded through to base paint have not been not isolated with filler, or with unsuitable filler.
- Unsuitable substrate (e.g. spray can painting with TPA or nitro).
- Use of unsuitable primer, paint and thinner materials.
- Paint systems not matched to each other.
- In wet-in-wet process, specified flash-off times not adhered to.
- Synthetic resin top coat (alkyd resin) worked over too soon.



Repair of damage:

- After thorough drying, completely remove the top coat together with the attacked substrate at the affected areas and re-create a new paint finish.
- Before applying top coat, rub down the complete surface.

#### **Cloud formation**

Differing, blotchy color/effect formations in dark/light areas of a metallic paint finish.

Cause/damage pattern:

- Spray gun, spray nozzle, spray pressure not perfect.
- Varying spray viscosity, spraying method, flash-off times, spray booth temperature.
- Thinners not suitable.



Repair of damage:

- Droplet method before clear lacquer application.
- After clear lacquer has thoroughly dried, sand surface and re-paint.

#### Spots

Points rising up from the paint film.

Cause/damage pattern:

 Metallic base paint sprayed too dry, so that the metal particles could not incorporate into the paint. The clear lacquer could not cover these vertical standing particles because the spray air was too hot or the booth temperature was too high.



Repair of damage:


• After the paint surface has dried, lightly sand it with grade P800 sanding paper, clean with silicone remover and re-apply clear lacquer.

#### Metamerism/color deviations

Noticeable when identical color shades undergo a change of hue as the light source changes (daylight/artificial light). Different pigment composition between original and repair paint.

Cause/damage pattern:

- Use of paints with pigmentation which was not compatible with the standard, e.g. a green can be formulated from yellow and blue, or directly from green.
- Use of an unsuitable mixed or ready made paint to re-tone.



Repair of damage:

• Repaint using the correct paint.

#### Washing out

On paint which has been newly applied but not yet dried, the interaction of surface tension and very different specific gravities of the different pigments can lead to swirl-like turbulence which results in separation of the pigments.

Cause/damage pattern:

· Layer too thick, paint not stirred enough.



Repair of damage:

· Sand and re-paint.

#### Loss of gloss

Milky, dreary tarnishing of the paint with more or less even loss of gloss.

Cause/damage pattern:

- Cold with low air humidity.
- Heat with high air humidity.
- Substrate can be etched.
- Hardener fault or wrong hardener used.
- Paint thinned too much.
- Proportion of pigment too high because of poor stirring.
- Not optimum drying.



Repair of damage:

• After drying, remove the matt effect by polishing. If unsuccessful, rub down complete area and paint again.

#### Covering ability/areas of thin paint

Different color shades in the surface. The minimum layer thickness is not achieved here. The effects range from local minor shade variations through mottled spray zones to completely missing top coat.

Cause/damage pattern:

- No correct, uniform substrate (effect paint).
- On three-layer systems, wrong filler.
- Insufficient top coat application.



Repair of damage:

• Sand surface and recreate the paint finish.

#### Flow problems/orange peel

Surface structure bumpy, grained. The surface is similar to the peel of an orange.

Cause/damage pattern:

- Paint viscosity too high.
- Use of fast evaporating, highly volatile thinners.
- Booth temperature too high.
- Spray gun distance too great, too little material applied.
- Nozzle too large.
- Incorrect spray pressure.



Repair of damage:

- Small surfaces: fine sand and polish.
- Sand out the surface and recreate the paint finish.

#### Dirt embedded in metallic base paint.

Inclusions of contamination in metallic base paint, of different sizes and shapes (grains or lint).

Cause/damage pattern:

- Dust was not properly removed from the surface to be painted.
- Paint material not sieved.
- Function of the painting facilities not optimum.
- Filter contaminated.
- Wearing unsuitable clothing.

Repair of damage:

· Sand and repaint.

#### Dirt embedded in top coat

Inclusions of contamination in top coat or under paint layers, of different sizes and shapes (grains or lint). Optical adverse effect.

Cause/damage pattern:

- Dust was not properly removed from the surface to be painted.
- Paint material not sieved.
- Function of the painting facilities not optimum.
- Filter contaminated.
- Wearing unsuitable clothing.



Repair of damage:

- Single inclusions: after thorough hardening, sand out using 1200 1500 grade paper and repolish using a suitable silicone-free sanding or painting paste.
- · Large area contamination: sand and repaint.

#### Water marks

Ring shaped marks appearing on the paint surface.

Cause/damage pattern:

- Evaporation of water droplets on freshly painted and not yet fully hardened paint finishes (mostly only found on horizontal surfaces).
- · Layer too thick.
- Drying time too short.
- Hardening faults or hardener no longer useable.
- Use of unsuitable thinners.



Repair of damage:


- Rub down only slight marks with sanding paper grade P1000 P1200 and then polish.
- For heavy marking, sand the surface matt, clean with silicone remover and repaint.

#### Paint runs

Wave-like paint run tracks in top coat or in an intermediate layer on vertical surfaces. Mostly in the area of swage lines, seams or openings (there they are paint runs, otherwise curtains).

Cause/damage pattern:

- Uneven paint application.
- The specified viscosity was not complied with.
- Use of unsuitable thinner materials.
- Air, material or room temperature too low.
- · Layers too thick.
- · Spray gun (nozzle) not perfect.



Repair of damage:

- After thorough drying, sand unevenness flat, if necessary leave to dry afterwards.
- Small areas of damage can be equalised using the paint plane, then sand, polish or repaint.

#### Swirl marks

Three dimensional appearance in the paint surface in the form of smears or blotches. This effect is intensified in direct sunlight.

Cause/damage pattern:

- Polishing using polishing machine on paint which has not yet hardened throughout.
- Polishing intervals too long or none at all.
- Pressure too high while polishing.
- Incorrect polishing material or polishing tool.



Repair of damage:

- Allow the paint to harden completely and then polish.
- If the damage is irreversible, rub down and apply new clear lacquer.

## Tools and Equipment for Paint Repairs

#### **General work equipment**

In the repair paint shop there is a range of painting tools which make the work of the painter easier and improve the quality of the repair paintwork.

Among these are small tools which are used for the following work:


- **Measuring beakers** to measure and mix various paint materials.
- **Measuring rods** with which the required combination amounts of paint and primer filler are gauged and mixed.
- Viscosity measuring beaker with a calibrated opening of 4mm, used to set the correct paint viscosity.
- **Paint filter/paint sieve** for filtering foreign bodies out of mixed paint or primer. Care must be taken that the correct filter is used for each paint.
- Color sample plates onto which the mixed paint is applied, and the shade is then compared to that of the vehicle. Other aids which should help the painter to find the correct shade are color sample cards and color panels, which are offered by many paint manufacturers.
- **Dust bonding cloths** which are impregnated with a tacky resin and which pick up dust particles particularly well. A surface to be painted must be cleaned with a dust binding cloth immediately before paint is applied.
- **Compressed air guns** are used to remove sanding residues and to dry sanded surfaces.

#### Filler and spray guns

**NOTE:** Regular maintenance, cleaning after use and careful handling of all individual parts of the spray gun are essential for a high-quality paint finish.

The spray gun is the most important implement in the paint shop. Application of paint using the spray gun can produce a layer with absolutely constant thickness and a smooth paint surface.

#### **Principle of operation**



ltem	Description	
1	Air supply	
2	Paint supply	
3	Nozzle needle	

Because of the construction design and with the aid of compressed air, a spray-ready paint mixture is dragged out of the container to the nozzle by the venturi effect, and is applied to the surface being worked.

When the trigger of the spray gun is pressed to the first pressure point, only the compressed air passage opens. If the trigger is pressed further, the nozzle needle displaces and the air stream drags paint with it at high speed. This produces a spray mist consisting of micro-droplets of paint.

#### Types of spray gun

# 1 2 2 59529

ltem	Description
1	Suction-beaker spray gun
2	Flow-beaker spray gun

In the flow-beaker spray gun, the paint container is mounted above the spray gun. On the suction-beaker spray gun, it is below.

Furthermore, spray guns are categorized by their air pressure requirement into high and low pressure guns.

High pressure guns have the disadvantage that they exhibit high consumption of energy and materials. The spray pressure they require is between 1 - 6 bar.


Because of the high air pressure and the large amount of air needed, the result is a powerful paint mist formation (paint transfer rate approx. 35%).

Current practice is mainly to work with reduced mist spray systems (RP and HVLP systems).

Reduced pressure (RP) guns are optimized high pressure guns which have an input pressure at the gun of approx. 2.5 bar and an atomization pressure at the air cap of 1 - 2 bar. In practice this spray technology is preferred for spraying clear lacquer because of the finer atomization.

Low pressure guns have the advantage that they exhibit minimal paint mist formation and because of this the paint transfer rate rises to approx. 65%. The spray pressure required in this case is between 1 - 5 bar. Nozzle sizes from 1 - 2.2 mm can be used.

#### **HVLP** spray guns



ltem	Description	
1	Quantity control	
2	Working pressure control	
3	Spray pattern control	

The high volume low pressure (HVLP) spray gun is a high performance spray gun which forms a soft, fine and homogenous spray pattern. The atomization pressure at the air cap is 0.7 bar when the input pressure at the gun is 2.0 bar.

The low atomization pressure of 0.7 bar together with greatly reduced spray mist provide high material ejection. The low nozzle internal pressure minimizes rebound of the paint droplets from the object and thus the proportion of overspray.

This spray technology has a very high application efficiency. By matching the size of the nozzle, the HVLP spray gun can be used for all repair painting materials.

HVLP spray guns are often used in practice for the application of water based paints.

Mini spray guns are often used for small, localized touching-up work. Use of HVLP spray technology and nozzle sizes of 0.3 - 1.2 mm permits very fine

work, so that the area of the repair can be kept as small as possible.

In order to ensure that a spray gun operates efficiently for a long time, careful cleaning is absolutely vital after use.

**NOTE:** During cleaning you must distinguish between water based and solvent based materials.


Cleaning by hand:

- Empty the paint beaker immediately after use.
- Flush the gun with cleaner.
- Clean it inside and outside with a brush.
- Dismantle the gun to clean it thoroughly.
- Clean the air cap using a suitable brush.
- Use nozzle cleaning needles to clean bores and nozzles.

A spray gun washing machine is recommended if the painting work is highly intensive.

New types of paint processing systems are replacing the conventional mixing beaker, filter and spray gun flow beaker. This reduces the amount of solvent required for cleaning and the amount of routine waste which remains.

#### Paint preparation system (PPS)



lte	em	Description	
,	1	Beaker	
	2	Color bag	

With this system, which is suitable for both suction and flow beaker spray guns, only one beaker is required for mixing and painting.

A bag is inserted in the beaker, in which paint can be mixed, processed and stored after use or completely disposed of.

The small quantity of paint remaining in the gun is removed using a minimum quantity of solvent from the pipette bottle.

The amount of cleaner used is reduced because only the spray gun needs to be cleaned.

#### Hand and machine sanding tools

Sanding is used to prepare a surface for application of a paint layer, enabling it to adhere well. Sanding materials have a great influence on the quality of a repair paint finish. The correct sanding medium must therefore be chosen for every material.

During sanding, material is mechanically removed from a surface.


In the paint shop, carborundum or silicon carbide abrasive on a substrate of paper or cloth are the most common sanding materials used.

Carborundum is a very hard mineral consisting mostly of aluminum oxide. During use carborundum becomes blunt and wears away. Silicon carbide has a very high degree of hardness, but is more brittle than carborundum. When silicon carbide is used, the mineral grains break. New long and pointed profiles are formed.

Use of the correct sanding paper depends on the application, the substrates and the tools used. The following table can be used as a guideline, but the recommendations of the supplier of the auxiliary materials and additive materials must be followed.

Application	Working area	Grade	Sanding system
Body work, corrosion damage	Equalizing paint system transition	to P150	Orbital sander, dry
			Hand sanding, dry
Stopper	Rough sand	P80 - P150	Orbital sander, dry
	Fine sand	P240 - P320	Orbital sander, dry
			Hand sanding, dry
Spray stopper	Rough sand	P120 - P180	Orbital sander, dry
	Fine sand	P240 - P320	Orbital sander, dry
			Hand sanding, dry
Filler sanding work	Filler fine sand	P400 - P500	Orbital sander, dry
		P800 - P1200	Hand sand, wet
Top coat	Old paint	P400 - P500	Orbital sand, dry
		P800 - P1200	Hand sand, wet
	Touch-up paint surfaces	P1000 - P2000	Hand sand, wet
Paint damage	Sanding out faults	P2000 - P3000	Hand sand, wet

Soft Pads are recommended for manual refinishing of contours, curves and difficult to reach areas. On a Soft Pad the abrasive is found on a coarse structured fleece. Because of this, it is very flexible, does not kink and does not slip in the hand. This enables a fine and even finish to be achieved.



Item	Description	
1	Extraction bores	
2	Connection for extraction equipment	

Notes on working with sanding tools:

- Tools with a rigid backing pad do not adjust to fit the surface. They are used for flat surfaces.
- Tools with a flexible backing pad are used for fine sanding of a surface because they adjust to the shape of the surface.
- Build up an even working pressure over the sanding surface.
- Keep the sanding paper tight on the tool (use self-gripping systems).
- Align the extraction holes in the sanding paper with the holes in the tool.
- Guide the tool flat over the surface to be worked. Do not tilt it.

Hand sanding can be carried out dry but also wet. Wet and dry paper with particle size P 80 to P 1200 is used for this in the paint field.

#### Ways of sanding

Sanding tools are driven either by electricity or compressed air.



ltem	Description	
1	Sanding machine	
2	Polishing machine	
3	Orbital sander	

The disadvantage of electrically driven machines is that their own weight is high compared with pneumatic systems. They also become warm during work. They do not however need any special operating equipment for their energy supply.

Sanding machines are categorized by their type of sanding movement.

#### **Rotational sanders**

On these machines the sanding paper turns.

- Advantage:
  - Ideal for heavy sanding work.
  - Fast and aggressive sanding possible.
- Disadvantage:
  - Large amount of heat developed.
  - Difficulty sanding flat surfaces.
- Application:
  - Removal of old paint layers.
  - Preparation of panel for stopper.
  - Removal of rust.

#### **Oscillating sander**

On these machines the sanding paper oscillates. The backing pad is rectangular.

- Advantage:
  - Large sanding surface.
  - Ideal for large and flat surfaces.
- Disadvantage:
  - Hardly useable on rounded surfaces.
  - Flexible backing pad not possible.
  - Vibrations because of the poor support of the backing pad.
- Application:
  - Sanding of polyester stopper.
  - Sanding processes on flat surfaces.

#### **Orbital sander**

On these machines the sanding paper turns and oscillates.

- Advantage:
  - Easy to handle and good sanding power.
  - Minimal heat development.
- Disadvantage:
  - Not suitable for sanding stopper on flat surfaces.
  - Smooth guidance important, otherwise sanding marks will occur.
- Application:
  - Sanding of paint layers.
  - Well suited for final preparation of a primer.

**NOTE:** Comply with the manufacturer's recommendations when setting the orbital sander.

On the orbital sander, stroke settings of approx. 3 mm for fine sanding work and approx. 5 - 7 mm for coarse sanding work have been established.

#### Polishing and finishing tools

The term polishing in the context of paint repairs means the elimination of paint flaws and high shine polishing of neighboring parts.

During polishing the fine sanded surface is returned to a high shine using a special abrasive polish.

Before the actual polishing, all flaws in the paint surface must be removed and the following working procedures must be adhered to:

- Thoroughly clean the vehicle.
- Remove spray mist from all surfaces.
- Sand out and polish particle inclusions.
- Sand down paint runs and polish them out.
- Examine the exactness of the color match in daylight.
- Remove masking edges.
- Remove sanding water, sanding dust and polish residues.

After the polishing process the results must be tested using a special test spray.

#### Infrared drying technology

The drying process in a painting/drying cabin occurs through heat conductance (convection). When an infrared dryer is used, the drying process is through heat radiation.



The infrared rays penetrate the air and the paint layer without warming them. Because the infrared rays are reflected from the steel panel, the paint coat is warmed from the inside outwards.

Advantages of infrared drying:

- The drying process occurs from the inside to the outside.
- The drying time is shorter than for warm air systems.
- Because the infrared dryer consists of several cassettes which can be switched on independently, the drying area can be optimally controlled.

Independent of the manufacturer's instructions, pay attention to the following:

- Flash-off time of the paint before switching on the infrared dryer.
- Distance between the infrared dryer and the surface.
- Duration of the irradiation.

The most common use of the infrared dryer is to dry stopper and primers. The wait time between the job steps is shortened without having to use the painting/drying cabin.

The painting/drying cabin can then be used exclusively for application and drying of topcoat.

There are two types of infrared dryer:

- Infrared dryer with short wavelength radiation.
- Infrared dryer with medium wavelength radiation.


As an indication, the following drying times are listed for some materials (at 80 cm distance):

**NOTE:** Observe the material manufacturer's and supplier's specifications.

- Polyester stopper 2 minutes.
- Spray stopper 2 to 7 minutes.
- Water based primer-filler 7 to 9 minutes.
- Primer 3 to 8 minutes.
- Top coat 7 to 10 minutes.

#### Air dryers

The air dryer is suitable in places where drying needs to be done, but without great outlay (painting/drying cabin or infrared dryer).



**NOTE:** Air from the compressor is often too cold for effective drying.

Air dryers use the venturi effect to blow the warm ambient air over the paint surface in a gentle air flow.

#### Paint mixing system

Because of the many different color variants, it is now seldom possible to store all color shades as ready-made mixtures.

For this reason, vehicle manufacturers make the mixture proportions of their paints available as color codes. The required color shade can be obtained from the paint mixing system using this color code.

All the color components are combined according to their proportions by weight using a precise computer scales to produce a finished color shade.

#### **Painting cabin**

The air requirement in a painting cabin is large. The outside air which is drawn in must be passed through filtering and warming equipment. This particularly applies during colder times of the year and especially for combined types of building where the painting cabin is also used as a drying cabin.

It is primarily used to keep the air free of dust. At the same time, explosive solvent-air mixture concentrations are prevented

**NOTE:** Vacuum will lead to contamination of the newly applied paint. The outside air flows through door gaps, wall joints and other openings and as it does so, brings dust deposits with it.

The air supply quantity depends on the size of the painting space and the quantity of extracted air. Enough air must be supplied to cause positive pressure in the painting space. An air extraction : air supply ratio of about 1 : 1.05 is sufficient.

The filters should have a dust-removal grade of not less than 99.8% and must always be kept clean.

It is especially important that the air supply does not cause strong air currents in the painting cabin. If not, the following problems could occur:

- Paint contamination cause by paint mist, which persists in air eddies and gradually falls on the fresh paintwork.
- Flow problems in the paint because of the high speed of the air, causing the paint to thicken very quickly on the surface.
- Loss of gloss and wrinkle formation because the surface dries too fast.
- Painter disturbance while working.

In modern paint cabins the air supply is provided from the complete surface of the ceiling. The air speed should be 0.3 m/sec (measured in the unrestricted cross-section of the spray cabin). At the same time, the air in the cabin should change about 350 times per hour.

Air extraction is best achieved through extraction channels in the floor of the painting cabin.

**NOTE:** Refer to the manufacturer's specifications for the operating instructions, safety instructions and notes on the maintenance of a paint cabin.

Smooth walls in the paint cabin should prevent dust deposits. Regular cleaning is necessary however.

Special easily washed adhesive-bonding paint can be applied to the walls to protect the cabin from paint mist.

# **Refinishing Materials**

The manufacturer's instructions must always be followed when dealing with all materials! The information given in the following text is data which is independent of the manufacturer, and it should only be used as an indication.

#### **Stopper materials**

- 1-component nitro-combination stopper
- 2-component polyester stopper
- 2-component plastic stopper

Use suitable primer to protect from corrosion areas which have been sanded bare before applying stopper.

#### 1-component nitro-combination stopper

# Nitro-combination stopper has mostly been superseded by 2-component polyester stopper.

Fast drying fine stopper for the smoothing of irregularities.

The working properties of 1-component nitro-combination stopper can be improved by the addition of nitro thinners.

Drying time increases with thickness of the layer.

Application	1-component nitro- combination stopper
Layer thickness	Max. 80 µm
Drying time	up to 2 hours at 20°C
Sand	P240 - P400

#### 2-component polyester general stopper

#### CAUTIONS:

Do not exceed the quantity of hardener specified by the manufacturer, excess peroxide can cause staining of the paint top coat.

Mix the stopper base and the hardener well to avoid a marble-like effect.

Check that the manufacturer permits use on the substrate to which it will be applied.

2-component polyester stopper is available in coarse and fine grades. The coarse stopper can

be used for very uneven areas and surfaces and fine stopper or spray stopper should be applied afterwards.

Application	2-component polyester coarse stopper
Use	Rough equalization of unevenness
Hardener quantity	approx. 3 - 5%
Working time	approx. 4 - 6 minutes
Drying	20°C approx. 12 minutes
	Short wavelength infrared approx. 4 minutes
	Medium wavelength infrared approx. 5 - 10 minutes
Sanding tool	Eccentric, sanding disk by hand
Grade	P80 - P150
<b>A 11</b> /1	1
Application	2-component polyester fine stopper
Use	
	fine stopper Equalization of uneven-
Use	fine stopper Equalization of uneven- ness
Use Hardener quantity	fine stopper Equalization of uneven- ness approx. 3 - 5%
Use Hardener quantity Working time	fine stopper Equalization of uneven- ness approx. 3 - 5% approx. 4 - 6 minutes
Use Hardener quantity Working time	fine stopper Equalization of uneven- ness approx. 3 - 5% approx. 4 - 6 minutes 20°C approx. 12 minutes Short wavelength infrared
Use Hardener quantity Working time	fine stopper Equalization of uneven- ness approx. 3 - 5% approx. 4 - 6 minutes 20°C approx. 12 minutes Short wavelength infrared approx. 4 minutes Medium wavelength infrared approx. 5 - 10
Use Hardener quantity Working time Drying	fine stopper Equalization of uneven- ness approx. 3 - 5% approx. 4 - 6 minutes 20°C approx. 12 minutes Short wavelength infrared approx. 4 minutes Medium wavelength infrared approx. 5 - 10 minutes Eccentric, sanding disk

Application	2-component polyester glass fiber stopper
Use	Equalization of uneven- ness; blending in of vehicle extensions; repair of GRP components
Hardener quantity	approx. 3 - 5%

Application	2-component polyester glass fiber stopper
Working time	approx. 4 - 6 minutes
Drying	20°C approx. 12 minutes
	Short wavelength infrared approx. 4 minutes
	Medium wavelength infrared approx. 5 - 10 minutes
Sanding tool	Eccentric, sanding disk by hand
Grade	P80 - P150

2-component polyester fine stopper should always be applied after 2-component polyester glass fiber stopper.

Application	2-component polyester spray stopper
Use	Equalization of uneven- ness
Hardener quantity	approx. 3 - 5%
Working time	approx. 25 - 30 minutes
Layer thickness	200 µm or 4 - 8 spray passes
Drying	20°C approx. 3 hours
	Short wavelength infrared approx. 10 minutes
	Medium wavelength infrared approx. 15 - 20 minutes
Sanding tool	Eccentric, sanding disk by hand
Grade	P80 - P150; fine sand - P280

Application	2-component plastic stopper for flexible thermoplastic
Use	Equalization of scratches or unevenness
Hardener quantity	approx. 3 - 5%
Working time	approx. 25 - 30 minutes
Drying	20°C approx. 15 - 30 minutes

Application	2-component plastic stopper for flexible thermoplastic
	60°C approx. 15 min
	(Short wavelength infrared approx. 8 minutes)*
	(Medium wavelength infrared approx. 8-10 minutes)*
Sanding tool	Eccentric, sanding disk by hand
Grade	P80 - P150; fine sand - P280

#### \*Infrared drying may adversely affect adhesion, therefore check the manufacturer's instructions.

Plastic stopper has a very great tendency to shrink back, so that the edge of the stopper repair becomes visible.

Plastic stoppers are flexible and universally applicable on all types of plastic (except for pure PE and PP, these are plastics which cannot be painted). The manufacturer's instructions must be very exactly followed in order that no adhesion problems occur. A special plastic etch primer is specified for some materials.

#### **Primers**

Application	1-component primer
Use	Isolation of bare sanded areas.
Spray gun	HVLP 1.3 mm
Spray pressure	2.0 bar
Drying	20°C approx. 15 - 20 minutes
	60°C approx. 10 min
Coat application	Wet on wet, no interme- diate sanding
Application	2-component primer
Use	Corrosion protection and bonding agent (steel sheet, zinc coated steel sheet, aluminum)

Application	2-component primer
Spray gun	HVLP 1.3 mm
Spray pressure	2.0 bar
Drying	20°C approx. 15 - 20 minutes
	60°C approx. 10 min
Coat application	Wet on wet, no interme- diate sanding

#### HS primer filler and HS tinted filler

Note:

- Primer filler is available as 1-component and 2-component water based and solvent based forms.
- 1-component products are only suitable for isolation of sanded through bare areas and new painting.
- Water based products are also used for the skinning of thermoplastics and substrates which are sensitive to solvents.
- Tinted fillers can be individually matched to the top coat color and therefore find uses in effect paints and paints with poor covering power.
- Use dry sand or wet sand filler according to application in order to avoid unnecessary sanding work.
- On critical substrates the use of epoxy resin base filler is recommended in order to avoid adhesion problems.

Application	HS primer filler and HS tinted filler
Use	Equalization of uneven- ness, edge zones, sanding scores
Spray gun	HVLP 1.6 - 1.9 mm
Spray pressure	2.0 bar
Layer thickness	50 - 70 μm to 150 μm possible
Drying	20°C approx. 2.5 hours
	(60°C approx. 25 min)*
	(Short wavelength infrared approx. 8 minutes)*

Application	HS primer filler and HS tinted filler
	(Medium wavelength infrared approx. 10-15 minutes)*
Coat application	Wet on wet, no interme- diate sanding

\*In order to avoid boiling out, drying should be performed slowly.

#### Paint

The base and the clear lacquer must be matched to one another.

Application	Water based paint
Use	Two layer metallic effect paint and Uni-paint finishes
Spray viscosity	At 20°C 18 - 20 s
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 bar
Layer thickness	15 - 20 μm
Drying	20°C approx. 2.5 hours
	60°C approx. 25 min
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes
Coat application	Wet on wet
Ventilation time	approx. 5 minutes

The base paint must be dried matt before the clear lacquer is applied.

Application	2-component HS clear lacquer
Use	Gloss providing protective coat for base coat substrate
Spray viscosity	At 20°C 18 - 20 s
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 bar
Layer thickness	50 - 70 µm

Application	2-component HS clear lacquer
Drying	20°C approx. 10 hours
	60°C approx. 30 min
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes

Application	2K HS Uni top coat
Use	Color and gloss providing paint layer
Spray viscosity	At 20°C 20 - 22 s
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 bar - 3.0 bar
Layer thickness	50 - 70 μm
Drying	20°C approx. 8 hours
	60°C approx. 30 min
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 -15 minutes

## **Additional Materials**

The manufacturer's instructions must always be followed when dealing with any materials! The information given in the following text is data which is independent of the manufacturer, and it should only used as an indication.

#### Adhesive sealants

Adhesive sealants are permanently elastic, long-lived, can be painted and accept filler.

Application: Sealing of visible and normal seams.

Can be over-painted with 2-component paint, primer and fillers after having dried throughout.

Contamination can be removed using cleaner and thinner.

#### 1-component PUR adhesive sealant

Note:

• Hardens using oxygen from the air. For that reason, it must only be stripped after it has completely dried through.

#### 2-component MS polymer adhesive sealant

2-component MS polymer adhesive sealant is free of isocyanate, solvent and silicones and can be spot-welded.

#### MS polymer adhesive sealant

Can be over painted with water-based paints.

Suitable for spraying and brushing to obtain a composition true to the original.

MS polymer adhesive sealant is free of isocyanate, solvent and silicones and can be spot-welded.

#### **Underbody protection**

Underbody protection products are immune to abrasion, permanently elastic, adhere well and are suitable for a true to original texture.

#### Underbody protection based on solvent

Application:

Underbody protection for visible areas.

Properties:

- Can be over-painted, also with 2-component paint.
- Can be colored with a proportion of up to 40% paint.

Note:

• Contamination can be removed using cleaner and thinner.

#### Water based underbody protection

Can be over-painted with water based paint. Can be colored with water based paint.

Contamination can	be removed	using water.

Application	Water based underbody protection
Use	Underbody protection for visible areas
Spray viscosity	ready to use
Spray gun	Suction beaker HVLP gun 3 - 4 mm
Spray pressure	4 - 6 bar
Layer thickness	500 - 1000 μm
Drying	approx. 6 hours at 20°C
	approx. 45 - 60 minutes at 60°C
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes
Application	Water based underbody protection
Use	<b>Isolation primer</b> for peroxide marks, bloomed old paintwork and thermo- plastics.

Application	Water based underbody protection
Spray viscosity	Thin as necessary with distilled water
Spray gun	HVLP gun 1.9 mm
Spray pressure	2.0 - 3.0 bar
Layer thickness	40 - 50 µm
Drying	approx. 2 hours at 20°C
	approx. 30 minutes at 60°C
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes

#### **Paint additives**

Application	Sanding test color
Use	To test sanding results
Spray gun	HVLP 1.7 - 1.9 mm
Spray pressure	2.0 bar
Layer thickness	Spray drifted

Application	Fixer additive
Use	Converts solid top coat into two layer solid; multi- color painting
Spray viscosity	18 - 20 secs at 20°C
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 - 3.0 bar
Layer thickness	max. 30 µm
Coat application	Wet on wet
Ventilation time	approx. 15 - 30 minutes

Maintain maximum layer thickness without fail. Must always next be overpainted with clear lacquer.

Application	Drying accelerator
Use	Accelerates drying with only minimal reduction in working life
Working life	approx. 5 hours at 20°C

Application	Drying accelerator
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 bar
Layer thickness	50 - 70 μm
Drying	approx. 6 hours at 20°C
	approx. 25 minutes at 60°C
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes

Cannot be used in all paints, read the manufacturer's instructions.

Particularly suitable for partial painting.

Application	Elastifier additive in primer material
Use	Elastifies the complete paint structure on plastics.
Addition	Up to 25%
Spray gun	HVLP 1.7 - 1.9 mm
Spray pressure	2.0 - 3.0 bar
Layer thickness	50 µm
Drying	approx. 4 hours at 20°C
	approx. 40 minutes at 60°C
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes
Application	Elastifier additive in top coat
Use	Elastifies the complete paint structure on plastics.
Addition	Up to 25%
Spray gun	HVLP 1.7 - 1.9 mm
Spray pressure	2.0 - 3.0 bar
Layer thickness	50 - 60 μm

Application	Elastifier additive in top coat
Drying	approx. 16 hours at 20°C
	approx. 45 minutes at 60°C
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes

Application	Matting additive in solid paint
Use	Elastifies the complete paint structure on plastics.
Semi-gloss addition	Up to 25% in the paint without hardener and thinner
Silk gloss addition	Up to 35% in the paint without hardener and thinner
Silk matt addition	Up to 45% in the paint without hardener and thinner
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 - 3.0 bar
Layer thickness	50 - 70 μm
Drying	approx. 8 hours at 20°C
	approx. 30 minutes at 60°C
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes

## CAUTION: Do not dry using infrared.

Application	Matting additive in clear lacquer
Use	Elastifies the complete paint structure on plastics.

Application	Matting additive in clear lacquer
Semi-gloss addition	Up to 25% in the paint without hardener and thinner
Silk gloss addition	Up to 35% in the paint without hardener and thinner
Silk matt addition	Up to 45% in the paint without hardener and thinner
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 - 3.0 bar
Layer thickness	50 - 70 μm
Drying	approx. 8 hours at 20°C
	approx. 30 minutes at 60°C

#### Note:

- When mixing, first put in the matting additive, then the hardener and thinners.
- Stir immediately after adding the matting additive.
- Do not store after addition of the matting additive, storage will change the degree of gloss.
- Also suitable for use on plastics without addition of elastifier additive.

Application	Matting paste
Use	Matts, elasticizes and gives structure to solid paint and clear lacquer during painting of bumpers or hard plastic.
Addition	1:1 or 2:1 depending on manufacturer in solid paint without hardener or thinners.
Spray gun	HVLP 1.2 - 1.3 mm
Spray pressure	2.0 - 3.0 bar
Layer thickness	50 - 70 μm
Drying	approx. 6 - 10 hours at 20°C
	approx. 30 minutes at 60°C

Application	Matting paste
	Short wavelength infrared approx. 8 minutes
	Medium wavelength infrared approx. 10 - 15 minutes

Note:

• The paint must not be filtered.

Application	Anti-silicone additive
Use	Prevents silicone craters
Addition	2% to maximum 5%

Note:

- Only add away from the paint cabin and immediately remove contaminated cloths.
- If anti-silicone additive is used in the first coat, then it must be used in the following coats, and in at least the same proportions.

#### **Additive materials**

#### Variety of adhesive tapes

For profile, fine and large area masking work.

Properties:

• Withstands heat.

- Withstands water-based paint.
- · Accepts paint.
- Easily removed without leaving adhesive residues.

#### Masking film.

For masking of large areas on vehicles.

Properties:

- Accepts 2-component and water-based paints.
- · Withstands heat.
- Withstands water spray and condensation.
- Withstands solvent.
- Easily cut.
- Environmentally friendly and can be recycled.

#### Polishing materials.

Polishing means microfine sanding. For this reason, polishes must only contain abrasives, and no silicones.

During polishing repair, a good shine is achieved through the step-by-step use of polishes, starting with a highly abrasive polish and ending with a polish having very slight abrasive action.

Polishes are available in graduations from coarse to fine.

#### Abrasives

Please refer to the "Tools" chapter for information on abrasives.

## **Paint Repairs**

#### **General information**

There is a great difference between painting in production and repair painting.

In production, only the bodyshell is painted, it has no trim, upholstery or assemblies. Because of this, other paints, tools and processing techniques can be used.

In contrast to that used in production, paint used in the workshop must dry at low temperatures. Plastics and the vehicle electronics must not be subjected to temperatures greater than 70°C.

The painting process in the case of repair work consists of two phases:

- Pre-treatment of the surface for corrosion protection and the smoothing of irregularities.
- Top coat application.

The precondition for a professional paint finish on a vehicle is the permanently maintained cleanliness of work spaces, tools and equipment,

Original materials must be worked according to the manufacturer's instructions, so that no problems arise in the processing nor during drying.

The room temperature must be 20 - 25°C and the humidity must be low. Temperatures which are too low or too high can lead to porosity, poor flow and boiling. High humidity leads to paint damage such as tarnishing of the paint film (matt film), adhesion problems and craters.

#### Pre-treatment of the surface

Perfect preparation of the subsurface is the precondition for a brilliant paintwork result. Faults in the preliminary stages delay completion and cause unnecessary extra work. The working steps described here demonstrate how important it is to follow these instructions step by step.

**NOTE:** Thorough cleaning of the vehicle and especially of the area being repaired is particularly important because of the danger of contamination of the paint.

#### Clean the area of the damage



Clean the damaged surface thoroughly, to allow the extent of the damage to be seen. Use silicone remover to produce a grease-free surface.

**NOTE:** The treated surface must be rubbed with a clean dry cloth before the solvent evaporates, otherwise there will be no cleaning effect.

Effective de-greasing is important not only before the application of paint, but also before all sanding stages, for two reasons:

- During sanding of grease contaminated surfaces, globules may form with the sanding dust. Sanding marks will occur and the sanding medium quickly becomes unuseable.
- Oil and grease are embedded by the action of the abrasive particles, and are then very difficult to remove.

Establish the area of damage and the repair stages. In doing so, establish how much disassembly work must be undertaken. Perform a color test at this stage.

Mask off the area of the repair ready for preparatory work.

#### Sand out the damage location



When sanding, produce smooth transitions from the painted area to the bare metal.

Use an eccentric sander and P80 or P120 abrasive sheets. Finish off sanding with P150 or P180. The remaining adhering sanding dust must be completely removed.

#### Cleaning, de-greasing



Use silicone remover to thoroughly clean the surface in order to remove grease residues, sweat from the hands and other contamination.

**NOTE:** Use a solvent test to establish whether the old paint can be etched. Apply 2-component thinners to the damaged area using a clean cloth and rub lightly for about 1 minute. If the subsurfaces can be etched away, special pre-treatment is necessary. See "Tips and Tricks"

#### Apply primer filler




Before applying stopper, apply primer to the sanded and bare surface.

Allow the primer to dry and then lightly sand by hand using P220 - P400 dry.

**NOTE:** Most stopper can be applied directly to bare metal. But application of a primer filler provides better corrosion protection.

**NOTE:** Avoid sanding through to the bare metal. Points which are sanded through must be retreated with primer filler.

#### **Stopper application**



Pre-sand the hardened stopper using an eccentric sander and P80 dry, then final-sand using P120 - P140 dry. Clean the sanded surface using silicone remover.

Apply 2-component stopper to the filled surface. The stopper compound must only be applied thinly.

**NOTE:** Use of a testing powder is recommended so that the sanding process can be more easily checked.

#### Apply filler



Filler can now be applied to the dried repair area. Choose the correctly toned filler according to the manufacturer's instructions.

**NOTE:** Alternatively, filler with the correct tone can be mixed with the aid of colour matching cards.

Sand the filler.



The working area is expanded by applying new masking. This makes it possible to even out the transition from the damage area to the vehicle paintwork.

**NOTE:** The primer filler must be carefully sanded. Faults in the primer filler layer will be visible in the top coat.

The sanding process consists of two stages. Coarse sanding levels out the surface of the filler primer. Fine sanding ensures the necessary surface structure which allows the top coat to adhere well and cover sanding marks.

Sand the filler using the eccentric sander and P400 - P500 used dry. Clean the sanded filler finished surface using silicone remover.

The painted area is matted using a fine matting sponge, and then thoroughly cleaned.

#### Surface ready for paint



The surface which has been repaired and then prepared according to the manufacturer's instructions is now ready for basic paint application.

#### **Top coat application**

It is important for a good paint result that the recommended process data is adhered to, i.e.

mixture proportions, layer thickness, viscosity, drying time etc.

First of all the work area is carefully masked ready for paint application. The correct adhesive materials and techniques must be used so that no hard transitions and edges are created during painting.

**NOTE:** The chapter "Tips and Tricks" gives in-depth information on masking work.

Thoroughly check the surface once more and rub-off with a dust-bonding cloth.

**NOTE:** Once more check the paint material and that the spray gun is correctly adjusted before applying the paint.

#### **Paint application**



The base paint is applied in two or three steps. First of all only the repair area is painted with the first paint application.

#### Flash off



Allow the paint application to flash off until the surface has a matt appearance. So that the transition to the original paint is optimally created, the next paint application is applied to a wider area.

After the base paint has dried for the specified time, the clear lacquer is applied. Next the transitions to the original paintwork are treated with fade-out

remover. This removes the spray mist and forms an ideal paint surface.

#### Repair stages for repair painting

The required time and material data is divided into four painting levels for calculations concerning repair painting. Proceed according to these divisions for every calculation.

#### Level 1 - Painting of new components

On new components, all inner surfaces, seams and edges which will no longer be seen after assembly must be primed and pre-painted.

**NOTE:** The cathodic dip primer must not be sanded away. Cleaning with silicone remover or light sanding of the primer is all that is required.

Job steps:

- Wash off, prime and pre-paint inner surfaces, seams and edges which cannot be reached at all or only partly after the component is installed.
- Sand new component with P280 P320 or a fine sanding pad.
- Clean subsurface with silicone remover.
- Carry out masking work (when painting an installed component).
- · Apply one spray run of filler, dry.
- Sand the filler. P1200 wet or P500 dry.
- · Clean filler application with silicone remover.

Then the prepared surface can be painted with solid or 2-component paint.

If the new part has mild transport damage, this must be rectified beforehand.

To do so, add the following steps:

- Grind out the scratch.
- Finely sand the surrounding surfaces.
- Use a steel cleaning agent to thoroughly clean and then rub dry.
- Apply corrosion protection primer to the bare areas.

#### Level II - Top surface painting (color tone matching)

Complete bodywork surfaces which are to be painted without the need to apply stopper belong to this group. In addition, surfaces with faults in the top coat surface which cannot be removed by polishing. The following faults are included:

- Loss of gloss.
- Sanding scores.
- Heavy paint runs.
- Large dust and dirt inclusions.

The scope of the work is as follows:

- · Sand the surface.
- · Sand out paint damage and faults.
- Treatment of small areas which have been sanded through.
- Masking work (when painting an installed component).
- Apply top coat according to the painting process (one or several coat process).
- Dry the top coat and perform finishing work.

# Level III - Repair painting with stopper applied to up to 50% of the surface.

If in addition to painting, work with stopper application must be performed, then the repair levels III or IV must be used.

In repair level III, apart from painting the complete bodywork surface, partial stopper work is carried out on up to 50% of the surface to be painted. The necessary primer and filler work are also included.

The following damage must be rectified in this level:

- Slight panel unevenness.
- · Damage due to corrosion.
- Dented body surfaces.
- · Weld locations.
- Deep scores or scratches.

The scope of the work is as follows:

- Fine sand pre-treated bodywork surfaces (e.g. lead-loaded areas).
- Sand out existing damage.
- Perform all necessary masking operations on the vehicle.
- · Apply primer.
- Partial stopper application on up to 50% of the surface to be painted (two to a maximum of three stopper applications).
- · Fill the repair area.
- Apply stone chip protection (when present in production).
- Apply top coat according to the painting process (one or several coat process).
- Dry the top coat and perform finishing work.

# Level IV - Repair painting with stopper applied to more than 50% of the surface.

In repair level IV, apart from painting the complete bodywork surface, partial stopper work is carried out on more than 50% of the surface to be painted. The necessary primer and filler work are also included.

The following damage must be rectified in this level:

- Damage due to hail.
- More extensive stone chip damage.
- · Extensively dented body panels.
- Sectional repairs with large weld seams.
- Surfaces with severe corrosion damage.


The scope of the work is different to level III because of the partial application of stopper to more than 50% of the area to be painted. In addition, more extensive sanding work is usually required.

#### Polish

In order to achieve faultless quality, it is sometimes necessary afterwards to polish a newly painted surface.

Even after the most careful painting, it sometimes happens that dirt inclusions and paint runs occur in work with top coat or clear lacquer. Before polishing, such paint faults must be removed with the sanding cylinder ("Finiball") and hand sanding or eccentric sander in a wet sanding process.

#### Sanding cylinder



The special sanding compound **-1-** (sanding bloom) for the sanding cylinder is self-adhering and available in grades from P1000 to P2500.


- P1000 P1500 for pre-sanding of runs and large imperfections in the paint.
- P1500 P3000 for subsequent sanding of runs and sanding out of dust inclusions.

A small eccentric sander can be used for more extensive working areas. When doing so, first of all put the eccentric sander in place and then switch it on, so that the danger of sanding through on edge is reduced.

Finally polish the sanded area to a high gloss with suitable polish. To this end the various manufacturers recommend materials and process techniques which are specially suited to their products.

**NOTE:** The polishing is to be done in the same way as that used to remove swirl marks.

Polish



**NOTE:** Before using the nap sponge for the first time and after any long pauses in working, dampen the nap sponge with polish.

Job steps:

- Clean and degrease the area to be polished using silicone remover.
- Apply the polish to the polishing disc and spread it.
- Place the polishing machine down flat on the area to be polished and before switching it on, gently distribute the polish over the underlying surface.
- Polish out the location for 10 15 seconds with the edge, working with a criss-cross motion.
- Subsequently polish the location for about 10 seconds with the machine laid down flat.
- Wash off and clean the polished location using the professional polishing cloth and then clean the polished surface.
- It is absolutely vital to carry out a visual check after finishing the polishing procedure. If any swirl marks are not completely removed by the first polishing procedure, then process must be repeated.

#### Aids

#### **Cleaning putty**

Cleaning putty allows deposits on the paint surface to be removed easily and gently. The following paint faults can be removed using cleaning putty:

- Metal deposits and iron dust.
- Paint or color mist.
- Tree resin and tar.
- Insect residues.

The surface to be worked must be thoroughly cleaned before the cleaning putty can be applied. Then the surface is sprayed with soapy water. Now the cleaning putty can be slid over the surface until all unevenness is removed.

## Painting Plastic Parts

#### General

Although these days plastics can be produced in all colors and with a matt or gloss surface, painting is often necessary.

**NOTE:** Manufacturer's limitations concerning the feasibility of painting certain components must always be observed.

Reasons in favor of applying paint to plastic are:

- Individual coloring, matching the body paint.
- More gloss and color brilliance through painting.
- Removal of production imperfections.
- Protection from atmospheric exposure.

Nowadays painting plastic presents no problems because the materials are known and matched to the paint. In order that the painter can use the correct painting materials, the type of plastic must first be correctly determined.

To allow this, plastics are marked on the rear in accordance with the recommendations of the Association of Vehicle Manufacturers.

Once the type of plastic is determined it is an easy matter to assign special paint recommendations, matched to that particular plastic. Unmarked plastics require knowledge of materials so that a correct choice of paint materials can be made and the component can be reliably painted.

#### **Plastic groups**

#### Thermoplastics

When warmed these undergo a reversible transformation into a plastic deformable state and once cooled they maintain their shape. They consist of string-like (linear) or only slightly branched molecular chains.

#### Thermosets

Thermosets are hard and have the form of a close-meshed network in all directions. They do not undergo plastic deformation, are especially resistant to chemicals, are difficult to swell and are insoluble. At normal temperatures they are hard to brittle. At first the material does not undergo any change when heated, but when it reaches a critical point, the thermoset is totally destroyed.

#### Elastomers

Elastomers are characterized by high elasticity over a wide temperature range. They have properties like rubber or a sponge and after compression or distension they return to their original state.

#### **Types of plastic**

The plastics used in the automotive area:

- ABS Acrylonitrile butadiene styrene (polymer)
- PA Polyamide
- PC Polycarbonate
- · PE Polyethylene
- · PP Polypropylene
- PP/EPDM Polypropylene/ethylene propylene diene copolymer
- PC/PBT Polycarbonate/Polybutylene
   terephthalate
- PBT/PC Polybutylene
   terephthalate/Polycarbonate
- PUR Polyurethane
- GRP Glass reinforced plastic

**NOTE:** PE and PP are plastics which cannot be painted, or can only be painted using special techniques.

As well as the pure plastics, so-called 'blends' are also used. This means combinations of different plastics. If we were dealing with metals they would be called alloys.

#### **Plastic identification**

Normally the identifier is marked on the plastic components used in vehicle construction.

One method to determine the plastic group is the sanding test. In this a place is chosen which will not be visible later, and the finger belt sander is used to sand the plastic.

The plastic group can be determined using the pattern left by the sanding and the dust:

- Thermosets produce a white dust.
- Thermoplastics smear and do not produce dust.

The plastic group can be determined by a sound test:

- Degree of hardness the higher-pitched the sound, the harder the plastic.
- Elasticity the more muffled the sound, the higher the elasticity of the plastic.

#### **Cleaning plastic**

Plastic components are manufactured using complicated moulds and presses or other highly engineered tools, mostly using an injection moulding process or reactive injection moulding process.

In order to be able to remove the component from a particular tool, a separating agent is used, which in some cases adheres very strongly to the plastic.

This separating agent on the plastic components must be completely removed before any surface coating is applied.

Warm storage (tempering) before actual cleaning brings the following advantages:

- The separating agent sweats out of the plastic.
- Tensions in the plastic are released.
- Air inclusions can be recognized and removed.

Intensively clean the item several times using a pad and fresh cleaning agent.

**NOTE:** A single wipe, even with cleaning agent, is not usually sufficient in most cases. Clean textured components with the aid of a soft brush.

After cleaning, it is absolutely vital that cleaning agent absorbed by the plastic should be expelled by tempering again. If the ventilation is good and the room temperature is about 20°C the solvent can be evaporated away by overnight storage.

#### Painting new components

It is absolutely vital that the substrate of an unpainted new component is free of separating agent. Paint can only be applied directly to very few plastics. The plastic must first be identified exactly and then worked with a repair system which is matched to the type of plastic. In most cases a plastic etch primer must be applied as adhesion base to all plastics which can be painted.

**NOTE:** Plastics have a tendency to become electrostatically charged. This can easily cause contamination during painting. Special antistatic cleaning cloths prevent electrostatic charging.

Work process for thermoplastics:

- Thoroughly clean the surface.
- Temper the plastic.

- Afterwards clean with antistatic cleaner or antistatic cloths.
- Apply the bonding agent.
- Apply elastic filler. After it has dried, sand and clean.
- Apply one coat Uni-paint with elasticizer additive. For two layer painting the elasticizer additive is in the clear lacquer.

**NOTE:** Follow the paint manufacturer's guidelines during all work.

Work process for thermosets:

• As a rule, thermosets can be handled in the same way as normal body components.

Work process for PUR soft foam:

- The work process is the same as for thermoplastic.
- Instead of using bonding agent, a filler wash is applied to close the pores of the PUR soft foam.

The primer which has been applied to a primed new component can vary greatly. If no manufacturer's data is available, the composition and suitability for further working must be tested.

Painted components with an already ascertained and intact paint coat present no problems for possible repainting. After sanding and careful cleaning with plastic cleaner or thinners, painting can be done directly.

#### **Unknown primer**

When dealing with unknown substrates it is important to carry out an adhesion test on the existing paint before any repainting is attempted. First of all a mechanical test must be carried out, for instance using a lattice cut and tear-off band. If the adhesion of the old paint is not acceptable, it must be mechanically removed and new paint finish applied.

If the adhesion is acceptable, then an etch test is performed using 2-component thinners. If no etching can be detected in this test, application of the the paint finish can be started directly. Otherwise the old paint must be removed and a new paint finish created.

With the help of universal or special plastic primers and with only a few materials complementary to those previously present anyway, the painter can now apply a long-lasting paint finish to all popular vehicle attachments made of plastic.

#### Paint faults on plastic substrates

**NOTE:** Paint faults are fully described in the chapter Paint Defects and Damage.

The most common paint faults which can occur when painting plastic components and the methods of repair are briefly described.

#### Discoloration

Cause/damage pattern:

- Plastic material is not suitable for painting.
- Incorrect bonding agent.
- Paint used not solvent resistant.

Repair of damage:

- · Repaint using suitable materials.
- Install a new unpainted component.

#### Softening

Cause/damage pattern:

- Substrate not carefully cleaned.
- Air humidity too high or working temperature too low.
- Drying time incorrect (too short).
- Materials for substrate not correctly matched to each other or not mixed correctly.

#### Repair of damage:

- Dry out, sand, re-isolate and paint.
- Sand away faulty paint coats and re-apply paint finish.

# Paint damage caused by detachment, poor adhesion

Cause/damage pattern:

- Insufficient paint adhesion between top coat and filler. The whole of the paint finish detaches from the plastic.
- Plastic not cleaned sufficiently, not or inadequately tempered.
- Unsuitable cleaning agent or materials used.
- Poor or lack of intermediate sanding.
- · Paint finish underbaked or overbaked.

#### Repair of damage:

• Sand away faulty paint coats and re-apply paint finish.

# Paint damage caused by blisters, craters, sink holes

Cause/damage pattern:

- Painting on PUR plastic which was not painted in production.
- Surface of the plastic material too porous.
- Flash-off time not adhered to.
- Drying temperature too high.
- Moisture in plastic material.
- Layers too thick.

Repair of damage:

- Clean the damaged area, sand, re-isolate and paint.
- Remove the paint layers and re-paint.

#### **Crack formation**

Cause/damage pattern:

- Overexpansion of painted PUR plastic components.
- · Use of unsuitable paint materials.
- Paint materials not suited to each other or incorrect mixture ratio.

#### Repair of damage:

- It is not possible to repair overexpanded PUR plastic components.
- On other plastics, sand away damaged layers, isolate and repaint.

## **Spot Repairs**

#### General

In general, partial surface painting at a point is called a spot repair. Using this technique, minor paint damage can be resolved economically and to time.

#### Advantage of this method

Because this application remains confined to the area of the damage, it is often unnecessary to remove components or color match against neighboring components. The material used is very much reduced because only a part of the repair area is coated.

#### **Practical application areas**

Only occasionally can satisfactory results be achieved in the centre of larger surfaces and/or on difficult colors. In addition, unprofessional application may cause tear-off edges to appear in clear lacquer. Only certain application areas are recommended.

**NOTE:** The final decision on whether to spot repair or paint the component must be made by an expert.

Application areas:

- · 2-layer paint.
- Depending on the damage zone, paint damage up to a diameter of 3.5 cm or a length of 10 cm.
- Scratches.
- Clear lacquer application up to an area of DIN A4 max.
- Smaller areas which are optically broken up by other components such as trim strip, tail lights, swage lines and edges.
- Boundary zones and edge areas of larger components.

The best application areas have proven to be optical break lines such as corners, narrow surfaces, fenders and wheel arches.



Because of their locations, the violet colored areas are the most suitable for spot repair painting. The turquoise areas are only marginally suitable and the rest of the areas are not suitable for spot repairs.

#### **Repair process**

Perfect preparation of the subsurface is the precondition for a brilliant paintwork result. Faults in the preliminary stages delay completion and cause unnecessary extra work. The working steps described here demonstrate how important it is to follow these instructions step by step.

#### Illustration of damage



A typical case for spot repair is a small stone chip on the fender.

#### Cleaning



First of all the component is thoroughly cleaned using silicone remover and refurbished using abrading and polishing paste. This re-creates the original degree of shine and ensures exact color matching on the touch-up surface.

#### Sand out



Sand out the damaged location using P180 - P320. Only small sanding blocks and small sanding machines must be used, so that the area of the repair remains as small as possible.

Sanding is completed by rubbing down the surrounding surface with a fine sanding pad or P1000 paper. Remove sanding residues and clean the repair area with silicone remover. The peripheral zone must then be masked for application of the filler.

**NOTE:** The size of the repair area must be kept as small as possible (maximum size DIN A4).

#### Filling



The filler layer is applied in stages. First of all, filler is only applied to the location which has been sanded away. After a wait time for flashing off, the second coat is applied so that it spreads over onto the existing paintwork.

The filler must be dried according to the instructions of the material supplier.

#### Rubbing down



The repair location is now rubbed down with P400 - P500 and the bordering surface with P2000 - P4000. Remove sanding residues and clean the repair area with silicone remover.

#### Paint



Before painting, clean the area for the final time using a dust-bonding cloth. Then apply the basic paint in thin layers using a spray gun until enough coverage is achieved.

After drying, apply clear lacquer in 1 or 2 coats (depending on product). In doing so, spray so that only the newly applied basic paint is completely covered. Finally a touch-up thinners is sprayed over the edge of the clear lacquer to dissolve the clear lacquer spray mist.

Dry



Now dry the clear lacquer according to the manufacturer's instructions using an infrared gun.

#### Polish



Polish the component using a polisher and polish and check the polished area for any swirl marks which may be present. Polish away any swirl marks which are present.

#### **Dirt inclusions**

#### Sand out



Minor damage can be removed with a small sanding machine or preferably with an eccentric sander with P1500 - P2000. Very fine spray mist

can be removed using P2000 - P4000 paper and a larger eccentric sander.

## **Corrosion Prevention**

#### General

Although corrosion protection measures and painting processes in production have reached a very high technical standard and will be continuously developed further, in the long term corrosion on a vehicle cannot be totally avoided. Further demands are therefore made of the paint specialist besides his knowledge of normal repainting of vehicles which have been repaired after an accident, in addition specialist knowledge is required for assessing and rectifying damage due to corrosion.

During repair painting, take care over the maintenance and re-creation of the corrosion protection applied in production, in view of the long-term warranty on Ford vehicles. Only those repair materials which are approved by Ford may be used for body repair work and repair painting.

For detailed information on corrosion protection measures during body repairs, please refer to chapter 501-25.

Furthermore, information on corrosion protection measures is repeated in individual chapters of the paint manual.

In particular, pay attention that the layer thicknesses specified in production are maintained. The complete system of solid one-layer on galvanized steel panels must equal at least 90 µm and the total system of two-layer on galvanized steel panels must equal at least 105 µm.

It is important that sealing operations, as far as they are necessary, should be undertaken after the application of the paint to specification, in order to ensure the best corrosion protection. All components which form hollow cavities such as pillars, rails, side components etc. must be provided with a coating of cavity protection wax.

#### **Causes of corrosion**

Corrosion of steel is an electrochemical process during which the steel combines with oxygen. The following factors lead to corrosion:

• Acidic compounds contained in the air, such as carbonic acid and sulphur dioxide, combined with oxygen from the air and/or water. Salts

such as sodium chloride used as road salt accelerate the corrosion process.

- Mechanical damage such as stone chips and scratches which penetrate through to the steel panel.
- Lack of care by the vehicle owner of the painted and corrosion proofed surfaces or areas on the vehicle.
- Unfavorable weather or environmental conditions, as may occur in areas with high humidity, high salt content in the air or serious air pollution due to aggressive gases and dusts.

In the case of mechanical damage, formation of rust can often be seen, beginning to spread into the painted surface from a point (stone chip) or from a line (scratch). If these faults are not professionally rectified in good time, the result is rusting through from the outside to the inside. Rusting penetration from the inside to the outside occurs when for instance the cavity protection was inadequate.

#### **Operations after painting**

**NOTE:** The manufacturer's instructions must be followed when working with the various corrosion protection materials.

- After painting, treat all cavities in the repair area with cavity protection wax. In doing so, pay particular attention to the weld seams. In dead-end applications with a panel insert, the cavity protection wax must be applied so that it also reaches the area of the panel insert.
- Seals which were applied in production and not over painted must be reapplied. Seals protect vulnerable parts of the bodywork, keep moisture away, reduce wind and road noise and dampen vibrations.
- Apply transparent wax.

#### Definition of the degree of rust

In workshop practice, in order to be able to carry out a consistent and objective evaluation of the scope of the damage, a degree of rust on the scale of 1 to 5 is determined by the DIN 53 210 standard. The main criterion here is the extent to which rust exists under the paint structure. It is determined in millimeters (mm).

#### Underlying rust grade: R1 < 1 mm

Corrosion starting with up to 1 mm of rust underlying (in the form of a spot or a line).

The damage can be rectified by cleaning the defective location and mechanically removing the underlying rust. For a small extent, apply a primer using a brush and allow it to dry. Touch-up the location with a paint pen or provide a new paint coating.

#### Underlying rust grade R2 < 1 - 2 mm

Advanced corrosion with up to 2 mm underlying rust.

Rectifying the damage:

- Clean the defective location.
- Remove the underlying rust mechanically down to the paintwork carrier.
- Apply 1-component filler and then 2-component "Vario" filler.
- Provide the damage location with new paint coat on visible outer surfaces. Only locally touch-up areas which are not optically conspicuous.

#### Underlying rust grade R3 < 2 - 4 mm

More advanced corrosion with up to 4 mm underlying rust. The damage must be rectified in the same way as for R2. A permanent cure of this type of damage pattern is still just possible

#### Underlying rust grade R4 < 4 - 5 mm

Notably advanced corrosion with up to 5 mm underlying rust. The damage must be rectified in the same way as for R2. If it is found that for whole areas this is only possible with a great deal of work, or is not possible at all, then a new component must be used.

#### Underlying rust grade R5 > 5 mm

Extreme corrosion, with more than 5mm underlying rust (panels, flanges or load-bearing components partially rusted or rusted through).

Such damage can no longer be repaired because in many cases the constructional strength of the component can no longer be produced. The risk in making a repair is too great. Install a new component and paint it.

# Color Identification and Chromatics

#### **Basic color theory**


In order to achieve optically perfect painting results it is vital to understand the physical principles of the origin of color impression.

#### Color

Color itself is a sensory perception.

This perception arises through the combined effect of the following components:


- Light (sunlight or artificial light irradiates the object).
- Surface of the object (reflection from the object of certain constituent parts of the light).
- Eye (perception of the reflections from the object).



Because the sensory impression of color is produced by all three of these components, it is dependent on the type, quality and function of the individual components. Practical examples make this clear:

- If a particular article is subjected to artificial light, then it gives a different impression of color to that which it gives in sunlight.
- An object with uniform color but different surface textures appears to have different colors (grained or ungrained dashboard).
- A person with perception disorder (colorblindness) cannot recognize certain colors or distinguish between them e.g. red-green weakness).


In turn the type of color is determined by the light absorption ability of an object. Light shines with all color components (spectral colors) onto an object, certain components of the light are absorbed (taken in) and other components are reflected (sent on). The components which are reflected produce the specific color impression.



The colors as we see them are the result of a combination of reflected colors from the spectrum. Physically speaking, these are electromagnetic waves with different wavelengths (and frequencies). The healthy human eye can recognize wavelengths between 0.36  $\mu$ m (violet) and 0.78  $\mu$ m (red).


If all the perceptible wavelengths of the spectrum impinge on the human eye at the same time, the impression of white light is produced.

#### Additive and subtractive color mixing



Additive color mixing is the combination of light from different sources to give white. Different intensities of the additive primary colors red, green and blue allow millions of different colors to be represented (RGB colors).

Additive color mixing is always therefore used when light should enter the eye directly (without reflection off an object). Such as in the case of computer monitors or overhead beamers.



Subtractive color mixing means mixing the primary colors cyan, magenta and yellow to form a desired color (CMY colors).

Subtractive color mixing is used when light should enter the eye of an observer after reflection from an object. Such as happens with painting or in printing.

#### **Oswald color circle**



The Oswald color circle is based on subtractive color mixing, and enables the behavior of paints when they are mixed together to be represented.

Colors lying opposite each other are complementary colors and should not be mixed together as this will produce a dull (i.e. grey) shade. If green is added to red, the red becomes greyer, not greener.

Color shades which are side by side are partner colors and produce a mixed color shade. For instance, mixing red and blue produces a pure violet. In addition, black and/or white may be necessary to produce a particular color shade.

- White makes the color shade lighter.
- Black makes the color shade darker.
- With black and white the color shade becomes more dreary or greyer.

#### **Metamerism**

Metamerism is the name of the effect which occurs when two colors appear identical in a particular light (e.g. artificial light), but the colors appear different under another light source (e.g. daylight).

The cause is the fact that the human brain, aided by the eyes, does not evaluate the wavelength, instead it evaluates the spectral intensity of the reflected light.


It is for this reason that color matching in practice must only ever be performed in daylight, or under special artificial light which is based on daylight.

#### Metallic and pearl pigments

Colored paints achieve their color effect by the addition of pigments. Pigments are colored, solid, very fine organic and inorganic particles which are insoluble in the binding material.

#### **Metallic pigments**

Aluminum platelets are added as pigment to form metallic paint.




Depending on the size and shape of the aluminum platelets, different metallic effects can be achieved:

- Cornflake aluminum (1) causes very strong dispersion because of rough edges, low brilliance, very low flop and produces grey-silver shades.
- Dollar aluminum (2) causes hardly any dispersion because of the smooth surface, high brilliance, produces very light, almost white silver shades.

With metallic paints however, only a light-dark light reflection effect occurs.

Colored metallic paints are produced by the extra addition of color pigments to the metallic paint.

#### **Pearl pigments**



The basis of pearl pigments is formed by mica, which is metallized with a silver or gold layer.

Depending on the angles of light and observation, the mica platelets reflect different proportions of light. Because of this, the color of the paint appears to the observer to change.

Pearl pigments produce a colored and light-dark reflected light effect.

# Color codes and their determination on Ford vehicles

It is necessary to determine the correct color shade of the original paintwork in order to perform a professional and perfect paint repair.

The original paint color shade can be found by:


- Inspection of the vehicle type plate with the color code stamped on it.
  - Later design
  - Earlier design
- Color shade catalog or color shade system of the manufacturer.
- The bare bodyshell plate with color designation.

#### Type plate

Type plate - location on Ford vehicles:

- Right-hand B-pillar door rebate
- Left-hand B-pillar door rebate
- · Hood lock panel
- · Left-hand vertical edge of inner front wing
- · Right-hand vertical edge of inner front wing
- · Right-hand engine compartment side member
- Left-hand bulkhead
- Right-hand bulkhead


- Luggage compartment interior
- Inner rear panel luggage compartment



The type plate gives the color code in the last row.



On the newer type plates, the color code is given in the left-hand column, at the penultimate position.



# Color shade catalog or color shade system of the repair paint manufacturer.

The repair paint manufacturers offer a variety of possible systems for the determining the production color shade of motor vehicles. There are electronic systems, color card systems and manuals for the determination of color shades.

Most repair paint manufacturers use the following systems:


- A tabular system based on the following parameters:
  - Color code
  - Make
  - Model
  - Build year
  - Color or color name
  - Ancillary codes
- A system with color cards based on the following parameters:
  - Make
  - Color shade
  - Build year



Because of the many parameters used, in a tabular system the color shade can also be determined by the lack of a parameter.

When using the color cards, emphasis is placed on matching of the original color shade with the color shade samples. For this reason this method is very helpful when the other parameters are not available. Comparison of the results of both methods increases the certainty of using the correct original color shade and its formulation.

Additional certainty can be achieved during color shade determination by making a color sample plate. Here it is however important to apply the complete paint structure with base paint and clear lacquer onto a sample plate (1) in order to carry out a color shade and color coverage test.



The color shade comparison is done by comparing the vehicle paintwork with the sample plate (1). The color coverage test is possible by using the black test stripe (2): If the test stripe (2) is still visible after test painting of the sample plate (1), the coverage is not good enough.

By using this determination of the original color shade, the formulation and information on any very slight fine adjustments which may be necessary can be established.

#### Bare bodyshell plate

The bare bodyshell plate is located:

- On the hood lock panel.
- · Near the type plate.

The color name is stamped on in the last row.



#### Matching tinted filler to the color code

**NOTE:** Color samples must always be made from the same materials as the subsequent repair painting. Perform color shade matching in the fully hardened state, in natural light or under suitable artificial light.

Various tinted fillers are used during factory painting. In order to achieve the exact color shade of the factory applied paint, attention should be paid that the correctly matched fillers are used.



The repair paint manufacturers offer suitable precolored primers. The use of filler color cards allows the matching color shade to be determined.

# **Tips and Tricks**

#### **Comparing paint structures**

It may happen that an area remains visible, especially when the area of the repair is small. The reason for this is the structural variation in the paint surface at the repair location compared with the original paint finish. The original paint finish has a slight orange peel effect while the repair areas is extremely smooth.

This effect can be reduced by fine sanding using P3000 of the area around the repair location and then polishing.

#### **Etching substrate**

If the substrate can be etched during the solvent test, suitable preparation must be done.

Job steps:

**NOTE:** Follow the manufacturer specific instructions.

- Sand the damaged area extensively using an eccentric sander and P80 or P120 abrasive sheets. Finish off sanding with P150 or P180.
- Remove the sanding dust and clean the area of the damage using silicone remover.
- Apply polyester stopper to the bare panel and to the damaged area.
- Sand the dried polyester stopper to an even surface using P80 P150. Finish sanding using P180 P240. If required apply more stopper, again only on the bare panel.
- Wet sand the residual old paint finish using P600 P800. Transitions with P400 P600. Clean with silicone remover.
- Prime bare metal areas with acid primer.
- After the acid primer has been left exposed to the air for the correct evaporation time, apply 2-component primer filler in thin layers over the complete repair area, leaving enough air exposure time in between coats.
- After the filler has dried, sand wet with P800 or sand dry with P400. Sanded through areas must be covered again with 2-component Nonstop filler primer.

Another possible method of preventing etching of the substrate is to use waterbased primer and filler materials.

#### Masking the vehicle

Masking and covering work are among the most important preparations required to achieve a high quality paint finish. Paint application onto neighboring components, paint mist and sharp paint transitions are quality faults. For this reason it is extremely important to take special care and to use suitable masking materials.

**NOTE:** When water based paints are used, all materials must be stable towards water.

Plan the masking work:

- Determine the sequence of masking work. Sometimes after masking film has been applied, it is difficult or impossible to reach certain areas.
- Prepare the masking material.
- Start with small difficult areas.

Pay special attention to the areas of profiled seals, edges, openings and paint transitions.

#### Masking tape

Masking tape is available in various widths for special application areas. In practice however, a wide tape has proved best for almost all areas, also taking into account the time required for masking work.

**NOTE:** Use of differing masking materials is often much more time-consuming.

Advantages

- Good coverage. Narrower tapes must often be applied in several layers.
- More resistant to tearing.
- Wide tapes can be applied deep into joints and therefore protect from paint mist and contamination.
- Removal is often easier.

#### Masking film

Transparent plastic film has become accepted as a practical method to mask large areas of a whole vehicle. It can quickly and easily be applied to the vehicle from the roll.

**NOTE:** Only mask the vehicle when it is dry. Moisture under the film can lead to matt paint in the drying process.

Using masking film

- · Clean the vehicle before masking it.
- Pull the film over the vehicle. Because of the static charge, the film lies on the vehicle like a second skin.
- Cut out the repair area using the film knife and then mask it.


Other ways of masking a vehicle are:

- Masking using masking paper.
- Painting cloth (mostly used during filling work).

#### **Profiled seals**

If it is not possible to remove a profiled seal, then it must be masked in such a way that no edges can form due to paint accumulation.

To do this, the seal is lifted slightly and masked. The following techniques are possible:




Item	Description
1	Masking tape with plastic strips
2	Sealing lip
3	Sandpaper with masking tape
• Lavi	ing a string or cord under the seal. Suitable

- Laying a string or cord under the seal. Suitable for soft and elastic seal lips.
- Special masking tape with plastic strips for hard seal lips.
- Instead of using plastic strips, fine sandpaper cut into strips can be inserted and secured using normal masking tape.
- If the seal can be easily displaced, normal masking tape can also be used.

#### **Edges/openings**

Smooth paint transitions can be produced by positioning adhesive tapes.

**NOTE:** Pull the adhesive tapes away immediately after the paint has been applied and check the paint transitions.



ltem	Description
1	Vehicle edge
2	Adhesive surface
3	Masking paper

Possible variations

- At edges apply one strip of masking tape half on the area not to be painted and mask using a second strip.
- On surfaces, two masking strips can be attached, each affixed by half their adhesive surface. The adhesive strip which arises is then applied with one half on the edge of the area to be painted. The other half is aligned and fixed in addition in the curves.
- Affix masking paper on one side over the area to be painted. Double back the masking paper and secure it.
- Affix round profiled foam at the edge of the area to be painted using masking tape.

Foam strips are suitable for affixing to openings such as door gaps.



**NOTE:** Choose a suitable profile diameter. A profile which is too thick will protrude from the opening, one which is too thin will leave a gap.

Clean the door opening well and affix the matching shape.

#### **Color shade problems**

If a vehicle color shade is taken from a vehicle on a hot summer day and the mixed color applied, this may cause color shade problems. Some colors change so much at higher temperatures that it can lead to an incorrect result. Red color shades are particularly prone to this shade behavior.

This means that color determination should always be done on the bodywork when it is at about the same temperature as the later working temperature will be. The best temperature of the item is between 15° and 25° C.

#### Isopropanol and water

Painted surfaces are very easily cleaned using a mixture of 70% water and 30% isopropanol (can be obtained through a laboratory supplies specialist or a pharmacist).

#### **Temperature reduction spray**

If finishing work must be performed on touched-up surfaces and newly painted plastic parts, problems may arise. The paint and the transitions are not yet fully hardened.

**NOTE:** When working with the polishing machine, make certain that each operating run lasts no longer than about 5 - 10 seconds, in order to prevent the paint becoming warm.

Even so, in order to be able to polish over transitions, temperature reduction spray must be

applied to the surface. The transition area is then alternately sprayed and polished until a perfect transition surface is achieved.

Paint faults on soft plastic components where elasticizer additive has been used in painting must be wet sanded using grade P2000 - P2500 paper.

In doing this the sanding location and the surroundings are sprayed with temperature reduction spray and the paint faults sanded out by hand. Afterwards the location is polished as described above.

#### Paint plane

Dirt inclusions and paint runs can be removed with the sanding cylinder ("Finiball") and hand sanding or eccentric sander in a wet sanding process.

Another practical tool for removal of paint faults which lie proud of the surface is the paint plane.

**NOTE:** Guide the tool carefully with the minimum of force. It must not tilt, otherwise more serious damage may easily be caused.



This tool allows paint faults to be carefully removed in shavings. Afterwards the surface must be polished using suitable materials.

#### Shading

Even when all the rules, steps and corresponding instructions have been followed concerning possible shades, it may happen that the mixed color shade does not exactly match the vehicle color.

In these cases, shading must be done. Because there is no fixed formula for this, experience and a trained eye are important. Some rules must be followed for shading.

**NOTE:** Self-made color sample plates of the current colors are very helpful for determining the

color shade. Refer to the chapter Color Determination and Color Theory.

- When shading, if possible only use the paint mixture that is also allotted in the color shade formula.
- Observe the rules concerning contrary colors (complementary colors) and partner colors according to the Oswald color circle.
- Complementary colors are not recommended during shading because they mutually inhibit and lead to muddy mixtures.

#### Sanding marks

In certain circumstances, the recommended sanding methods up to now are no longer suitable for light metallic color shades. Wet sanding with grade P1200 paper or a grey sanding pad can cause sanding scratches which can become very visible under certain lights.

In order to achieve an excellent paint result on difficult color shades, follow these working rules:

- Sand filler as before, rub down area to be painted with 3M ultra fine matting sponge and 3M matting gel.
- Sand filler as before, rub down area to be painted with soaked 3M wet sand paper P1500 - P2000.
- Sand filler as before, rub down area to be painted with 3M 260 L P1000 eccentric (Interface Pad).

#### Improving touch-up work

During application of special effect base paints, the effect particles align themselves exactly parallel to the surface in the paint layer while it is still liquid. This means a particular thickness of the paint layer is required.

Because during painting the layer thickness in the transition zones reduces from normal to zero, the effect particles can no longer align themselves. This leads to lighter, darker or cloudy zones.

If 1-component clear lacquer is sprayed before the base coat, this effect is prevented. An optically perfect transition will result.

# SECTION 502-00 Uni-Body, Subframe and Mounting System

VEHICLE APPLICATION: 2011 Fiesta	
CONTENTS	PAGE
REMOVAL AND INSTALLATION	
Front Subframe	502-00-2

#### **REMOVAL AND INSTALLATION**

# Front Subframe

#### Special Tool(s)




204-605-01 Adapter for 204-605

# Removal

**NOTE:** Removal steps in this procedure may contain installation details.


- **1.** Refer to: Health and Safety Precautions (100-00 General Information, Description and Operation).
- 2. A CAUTION: Make sure that the steering wheel lock is engaged.

**NOTE:** Make sure that the road wheels are in the straight ahead position.



3. WARNING: Make sure that a new bolt is installed.

Torque: <u>26 Nm</u>



#### **General Equipment**


Transmission Jack

4. On both sides.

Refer to: Wheel and Tire (204-04 Wheels and Tires, Removal and Installation).


5. A WARNING: Make sure that a new bolt is installed.

On both sides. Torque: <u>48 Nm</u>



6. On both sides.


Special Tool(s): 204-605-01



7. A CAUTION: Make sure that the ball joint ball does not rotate.


## **REMOVAL AND INSTALLATION**

On both sides. Torque: 51 Nm




8. A CAUTION: Make sure that the ball joint ball does not rotate.


On both sides. Torque: 80 Nm




9. On both sides.




10. Torque: <u>57 Nm</u>








12 Torque: 52 Nm




Uni-Body, Subframe and Mounting System

#### **REMOVAL AND INSTALLATION**

13. General Equipment: Transmission Jack




- **14.** 1. Torque: <u>63 Nm</u>
  - 2. Torque: <u>140 Nm</u>



**15. NOTE:** This step is only necessary when installing a new component.


Torque: <u>90 Nm</u>



#### **REMOVAL AND INSTALLATION**

**16. NOTE:** This step is only necessary when installing a new component.

Torque: <u>55 Nm</u>



# 17. A WARNING: Make sure that new bolts are installed.

**NOTE:** This step is only necessary when installing a new component.

Torque: <u>101 Nm</u>




#### Installation

- 1. To install, reverse the removal procedure.
- 2. Refer to: Front Toe Adjustment (204-00 Suspension System - General Information, General Procedures).

# Jacking and Lifting – Component Location

**NOTE:** Only the specified jacking points may be used for jacking up and supporting the vehicle.




# Supplemental Restraint System (SRS) Health and Safety Precautions

#### WARNINGS:



- INHALED: Exposure to pyrotechnic residue may cause low blood pressure, severe headache, irritation of mucous membranes, fainting, shortness of breath or rapid pulse. Move a victim to fresh air. Seek immediate medical attention.
- **EYE CONTACT: Exposure to unburned** pyrotechnic residue may cause irritation, burning and etching of the eyes. Flush immediately with plenty of cold running water for at least 15 minutes. Seek immediate medical attention.
- **EYE CONTACT: Exposure to burned** pyrotechnic residue may cause irritation, burning and etching of the eyes. Flush immediately with diluted boric acid solution. Seek immediate medical attention.
- **SKIN CONTACT: Unburned pyrotechnic** residue may be rapidly absorbed through the skin in toxic quantities. Wash immediately with plenty of soap and water. Seek medical attention.
- **SKIN CONTACT: Burned pyrotechnic** residue may be rapidly absorbed through the skin in toxic quantities. Wash with plenty of water. Do not use soap. Seek medical attention.
- SWALLOWED: Unburned pyrotechnic residue is extremely toxic. If conscious drink plenty of water then induce vomiting. Seek immediate medical attention. If unconscious, or in convulsions do not attempt to induce vomiting or give anything by mouth. Seek immediate medical attention.
- SWALLOWED: Burned pyrotechnic residue is extremely toxic. Drink plenty of water and seek immediate medical attention.
- The deployment key must only be accessible to authorized personnel.
- Make sure that the deployment key remains removed from the deployment equipment except during deployment.

- If permenantly disabling or enabling the passenger air bag a new seat belt for vehicles without or with a passenger air bag must be installed.
- Undeployed pyrotechnic components must not be deployed in the vehicle.
- Pyrotechnic components must be deployed following local regulations.
- Check thoroughly that no loose objects can be spread during the deployment of pyrotechnic components.
- Pyrotechnic components must be transported following local regulations.
- Never carry out any electrical measurement on disconnected, undeployed pyrotechnic components.
- Pyrotechnic components must not be disassembled.
- Pyrotechnic components are not interchangeable between vehicles.
- Always carry a live air bag module away from the body with the air bag or trim cover pointing upwards.
- Live air bag modules must be placed in a suitable cage when removed from the vehicle. The air bag or trim cover must be facing upwards.



#### **CAUTIONS:**

- Pyrotechnic components must not be subjected to temperatures higher than 110°C.


Never install aftermarket accessories to the vehicle on or adjacent to the supplemental restraint system module.

#### **REMOVAL AND INSTALLATION**


## Wheel and Tire

#### Removal


#### CAUTIONS:



- Do not use power tools on locking wheel nuts.
- 1. Loosen: 360°




**2.** Refer to: Jacking and Lifting (100-02 Jacking and Lifting, Description and Operation).




#### Installation

1. A WARNING: Make sure that the mating faces are clean and free of corrosion and foreign material

**NOTE:** Only tighten the nuts finger tight at this stage.



- 2. Lower the vehicle.
- **3.** Tighten the wheel nuts in the sequence shown. Torque: <u>103 Nm</u>



#### **DIAGNOSIS AND TESTING**

# Generic Electronic Module (GEM)

#### **General Equipment**

Ford diagnostic equipment

#### **Principles of Operation**

A diagnosis of the generic electronic module (GEM) can be performed with the Ford diagnostic equipment. Furthermore, an integrated service mode enables testing of the input and output signals without the need for further tools. To enable activation of service mode:

- Switch off the ignition,
- Switch off all other electrical consumers,
- · Apply the handbrake,
- Shift to neutral
- Close the doors.

#### Activating the service mode

Proceed as follows to activate the service mode:

- OPERATE the switch of the heated rear window and HOLD IT THERE
- Turn on the ignition.
- RELEASE the switch of the heated rear window
- PRESS the heated rear window switch 8 times within 6 seconds

A signal sounds and the turn signal lamps flash to indicate that service mode has been successfully activated.

#### Input signals

SWITCH the wiper switch to the "Off" position to test the input signals. The following is a list of the signals to be tested, in no particular order:

- Turn signals (right, left, hazard warning lights)
- "Lights on" warning (terminal 58)
- Windshield wiper (intermittent wipe)
- Windshield washer system
- · Rear window wiper
- Rear window washer system
- Doors/tailgate open/closed
- Central locking
- Hood open/closed (in vehicles equipped with an anti-theft alarm system)
- Front fog switch (if fitted)
- Rear fog switch

- Heated rear window
- Heated windscreen (if fitted)

An acoustic signal sounds and the turn signal lamps flash to indicate receipt of each input signal by the generic electronic module.

#### **Output signals**

SWITCH the wiper switch to the "Intermittent" position to test the output signals. PRESS the heated rear window switch activates or deactivates the output signals in the following order:

- Windshield wipers (a signal sounds and the direction indicator lamps flash when the "Park" position is reached)
- b. Heated rear window
- c. Interior light(s) (the interior light switch must be in the "ON" position)
- d. Rear window wiper
- e. heated windshield (if fitted, is only activated when engine is running)

If the heated rear window switch is operated again, the sequence restarts with point 'a' and the functions are activated again in this order.

#### Ending the service mode

The GEM automatically ends service mode 20 seconds after the last input. However, service mode can be manually ended at any time by proceeding as follows:

- OPERATE the switch of the heated rear window and HOLD IT THERE
- SWITCH OFF the ignition
- · RELEASE the switch of the heated rear window

3 signals sound and the turn signal lamps illuminate to indicate that service mode has ended.

#### **Inspection and Verification**

- 1. VERIFY customer concern.
- 2. Visually CHECK for any obvious mechanical or electrical damage.

**NOTE:** Make sure that the wiring harness electrical connector is correctly and securely connected.

#### Visual Inspection

**Electrical** Fuses


#### **GENERAL PROCEDURES**

# **Battery Disconnect and Connect**

#### Disconnection


- WARNING: The supplemental restraint system (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.
- **1.** Refer to: Battery and Battery Charging Health and Safety Precautions (100-00 General Information, Description and Operation).
- 2. Obtain and record the audio unit keycode and preset radio frequencies.





#### Connect

4. Torque: <u>15 Nm</u>



- **5.** Enter the audio unit keycode and preset radio frequencies.
- 6. Reset the clock to the correct time.
- **7.** Start and run the engine at idle for three minutes.

- **8.** When the engine reaches normal operating temperature, increase the engine speed to 1200 rpm and maintain for approximately 2 minutes.
- **9.** Drive the vehicle for approximately five miles/eight kilometers of varied driving.

#### GENERAL PROCEDURES

# Air Conditioning (A/C) System Recovery, Evacuation and Charging

#### **General Equipment**

Air Conditioning Service Unit

Automatic Calibration Halogen Leak Detector

Electronic Leak Detector

Refrigerant Identification Equipment


#### UV Leak Detector

- **1.** Refer to: Air Conditioning (A/C) System Health and Safety Precautions (100-00 General Information, Description and Operation).
- 2. A CAUTION: The refrigerant analyzer must be used before recovery, otherwise the refrigerant center may become contaminated. Contaminated refrigerant must be disposed of as hazardous waste. Always follow the manufacturer's instructions when using the refrigerant center and the refrigerant analyzer.


Unscrew and remove the protective caps from the A/C charging connections.

- General Equipment: Air Conditioning Service Unit
- General Equipment: Refrigerant Identification Equipment

- 3. 1. Low-pressure connection
  - 2. High-pressure connection



**4.** Connect the service unit lines to the filling connection of the air conditioning system.



- **5.** Drain the air conditioning system via the low-pressure port in accordance with the service unit manufacturer instructions.
- 6. A CAUTION: Make sure that the specified amount of refrigerant oil is added.

**NOTE:** This step is only required when installing a new component.